

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Lenovo](#) /

> [Lenovo ThinkPad P16s Gen 3 User Manual](#)

Lenovo ThinkPad P16s Gen 3

Lenovo ThinkPad P16s Gen 3 User Manual

Comprehensive instructions for setup, operation, and maintenance.

INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Lenovo ThinkPad P16s Gen 3 mobile workstation. Please read these instructions carefully to ensure proper use and to maximize the performance and longevity of your device.

For additional support and detailed documentation, please visit the official Lenovo support website.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Lenovo ThinkPad P16s Gen 3 Laptop
- 135W Power Adapter
- Quick Start Guide (if included)
- Warranty Information (if included)



Image: The Lenovo ThinkPad P16s Gen 3 laptop, open and displaying a video editing application on its screen, showcasing its powerful processing capabilities.

SETUP

1. Initial Power-Up

1. **Connect the Power Adapter:** Plug the 135W power adapter into the laptop's power port and then into a wall outlet.
2. **Open the Laptop:** Carefully open the display lid.
3. **Power On:** Press the power button, typically located on the top right of the keyboard deck or on the side.
4. **Initial Windows Setup:** Follow the on-screen prompts to complete the Windows 11 Pro setup, including language selection, network connection, and user account creation.



Image: The Lenovo ThinkPad P16s Gen 3 laptop displaying the Windows 11 Pro desktop environment, ready for initial configuration.

2. Connecting Peripherals

Your ThinkPad P16s Gen 3 offers various ports for connecting external devices:

- **USB Ports:** Connect USB devices such as mice, keyboards, or external storage drives. The laptop features multiple USB 3.0 ports.
- **Display Ports:** Use the available display output ports (e.g., HDMI, Thunderbolt/USB-C) to connect external monitors.
- **Audio Jack:** Connect headphones or external speakers to the audio jack.
- **Ethernet Port:** For a wired network connection, use the Ethernet port (if available on your specific model or via an adapter).



Image: Left side profile of the ThinkPad P16s Gen 3, highlighting its various input/output ports for connecting peripherals.



Image: Right side profile of the ThinkPad P16s Gen 3, displaying additional input/output ports.

OPERATING INSTRUCTIONS

Keyboard and TrackPoint/Trackpad

- **Keyboard:** The backlit keyboard provides comfortable typing. Use the Fn key combinations for special functions (e.g., brightness, volume, keyboard backlight).
- **TrackPoint:** The red TrackPoint in the center of the keyboard allows for precise cursor control. Use the associated buttons below the spacebar for left, right, and middle-click functions.
- **Trackpad:** The multi-touch trackpad supports gestures for navigation, scrolling, and zooming.



Image: A top-down view of the Lenovo ThinkPad P16s Gen 3, showcasing its full-sized keyboard, TrackPoint, and large trackpad.

Fingerprint Reader

The integrated fingerprint reader provides secure and convenient login. Configure your fingerprints through Windows Settings > Accounts > Sign-in options.

Display Settings

Your laptop features a 16-inch WQUXGA (3840 x 2400) OLED display. Adjust display settings such as brightness, resolution, and color profiles through Windows Display Settings. The display supports Dolby Vision and HDR 500 True Black for enhanced visual quality.



Image: The Lenovo ThinkPad P16s Gen 3 display showcasing a vibrant, high-resolution image, demonstrating its OLED panel capabilities.

MAINTENANCE

Cleaning the Laptop

- **Screen:** Use a soft, lint-free cloth slightly dampened with water or a screen-cleaning solution. Avoid harsh chemicals.
- **Keyboard and Chassis:** Use a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters openings.
- **Ventilation:** Ensure ventilation openings are clear of dust and debris to prevent overheating. Use compressed air to gently clear dust from vents.

Battery Care

- Avoid extreme temperatures.
- For optimal battery longevity, avoid constantly keeping the laptop at 100% charge or letting it fully discharge frequently.
- Refer to Lenovo Vantage software for battery health management features.

Software Updates

Regularly update your operating system (Windows 11 Pro) and drivers (via Lenovo Vantage or Lenovo Support website) to ensure optimal performance, security, and compatibility.

TROUBLESHOOTING

Common Issues and Solutions

- **Laptop does not power on:**
 - Ensure the power adapter is securely connected to both the laptop and a working power outlet.
 - Try a different power outlet.
 - If the battery is completely drained, allow it to charge for a few minutes before attempting to power on.
- **Screen is blank or black:**
 - Check if the laptop is powered on (indicator lights).
 - Press Fn + F7 (or the appropriate function key for display toggle) to ensure the display is not turned off.
 - Connect an external monitor to check if the issue is with the laptop's internal display.
- **Wi-Fi connection issues:**
 - Ensure Wi-Fi is enabled in Windows settings.
 - Restart your router and modem.
 - Update Wi-Fi drivers.
- **Slow performance:**
 - Close unnecessary applications.
 - Check for background processes consuming high resources (Task Manager).
 - Ensure sufficient free storage space on the SSD.
 - Run a system scan for malware.

For more complex issues, refer to the Lenovo support website or contact technical support.

SPECIFICATIONS

Feature	Detail
Model	Lenovo ThinkPad P16s Gen 3
Processor	Intel Core Ultra 7 155H (E-cores up to 3.80 GHz, P-cores up to 4.80 GHz)
Operating System	Windows 11 Pro 64
Graphics Card	NVIDIA RTX 500 Ada Generation Laptop GPU 4GB GDDR6
Memory (RAM)	64 GB DDR5 (SODIMM)
Storage	1 TB SSD M.2 2280 PCIe Gen4
Display	16" WQUXGA (3840 x 2400) OLED, Anti-Reflection/Anti-Smudge, Dolby Vision, Non-Touch, HDR 500 True Black, 100% DCI-P3, 400 nits, 60Hz
AC Adapter	135W
Dimensions (H x W x D)	21.13mm x 361.50mm x 248.60mm / 0.81" x 14.24" x 10.06"
Weight	Starting at 1.82kg / 4.01lbs

Feature	Detail
Wireless Connectivity	802.11ax
USB Ports	2x USB 3.0 (additional ports may vary by configuration)
Color	Black

WARRANTY INFORMATION

Your Lenovo ThinkPad P16s Gen 3 comes with a **1-Year Courier or Carry-in Warranty**. This warranty covers manufacturing defects and hardware failures under normal use conditions.

For detailed terms and conditions, warranty registration, or to initiate a warranty claim, please visit the official Lenovo support website or refer to the warranty documentation included with your product.

Note: Upgrades to RAM and hard drive performed by authorized service providers will not affect the manufacturer's warranty.

SUPPORT

For further assistance, technical support, driver downloads, or additional documentation, please visit the official Lenovo Support website:

support.lenovo.com

You can also find contact information for Lenovo customer service and technical support in your region on the support website.



© 2024 Lenovo. All rights reserved. ThinkPad is a trademark of Lenovo.


Related Documents - ThinkPad P16s Gen 3

	<p>Lenovo ThinkPad P16v Gen 3 (Intel) Mobile Workstation: Specs & Overview</p> <p>Explore the powerful Lenovo ThinkPad P16v Gen 3 (Intel) mobile workstation. Discover detailed specifications, performance features, and compatible accessories for demanding professional workflows.</p>
	<p>Lenovo ThinkPad P16v Gen 3 (Intel) Mobile Workstation: Specifications, Features, and Accessories</p> <p>Explore the Lenovo ThinkPad P16v Gen 3 (Intel) mobile workstation. This document details its powerful Intel Core Ultra processors, NVIDIA RTX PRO graphics, extensive memory and storage options, vibrant display, and comprehensive connectivity for demanding professional workflows. Includes information on Lenovo services and compatible accessories.</p>
	<p>Lenovo ThinkPad P14s Gen 5 / P16s Gen 3 Setup Guide: Features, Ports, and Specifications</p> <p>This setup guide provides essential information for Lenovo ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 laptops, covering features, connectivity options, regulatory compliance, and quick start instructions.</p>


	<p>Lenovo ThinkPad P16v Gen 2: Powerful AI-Ready Mobile Workstation Specifications</p> <p>Explore the technical specifications and features of the Lenovo ThinkPad P16v Gen 2, an AI-ready mobile workstation designed for professional endeavors, featuring Intel Core Ultra processors, NVIDIA RTX graphics, and a high-resolution display.</p>
	<p>Lenovo ThinkPad P14s Gen 6 (Intel) Professional Mobile Workstation</p> <p>Discover the Lenovo ThinkPad P14s Gen 6 (Intel), a high-performance mobile workstation engineered for business professionals. Featuring advanced Intel Core Ultra processors, NVIDIA RTX graphics, and comprehensive security, it excels in demanding workflows and delivers exceptional reliability.</p>
	<p>Lenovo ThinkPad P15 Gen 2 Technical Specifications</p> <p>Detailed technical specifications for the Lenovo ThinkPad P15 Gen 2 workstation laptop, covering system overview, supported components, CPU, memory, storage, display, I/O, audio, battery, BIOS, security, environmental, and manageability features.</p>

Documents - Lenovo – ThinkPad P16s Gen 3


[\[pdf\]](#) User Manual Quick Start Guide Specifications Documentation Guide Warranty
 ThinkPad P14s Gen 5 and P16s 3 User Guide Product DocumentsLenovo AI Ready 16 Intel Core Ultra 9 185H
 vPro Enterprise 64 GB RAM 1 TB SSD English AS Capital Datortehnika IT risinājumi Servissf3c92cb1 c2f4 4a8a
 995d 8cf5104a19b2capital lv media ows f3c92cb1 8cf5104a19b2 Lenovo Bundle Promo Buy 2 get for free units
 7 155H Mobile workstation 40 6 cm WUXGA 32 DDR5 SDRAM NVIDIA RTX 500 Ada Wi Fi 6E 802 11ax
 Windows 11 Pro Black 24 MBProduct 21KS000GMH B1Lenovo Servissmmo 134034829 1756309748 5571
 618386f3c92cb1 8cf5104a19b2objects icecat biz objects mmo 618386capital MBLenovo Belgian 21KS000GMB
 618386mmo 134034903 1756307430 3609 725392f3c92cb1 618386objects 725392capital Swiss 21KS000GML
 725392mmo 134034902 1756307502 5574 53f3c92cb1 725392objects 53capital 512 French
 21KS000GMBLenovo 134219149 1756306861 2865 762683mmo 762683objects DocumentsDownloadLenovo
 ServissLenovo 21G20020US 14 Workstation WQXGA Keyboard Notebooks COLAMCOmmo
 8cf5104a19b21081069936objects 8cf5104a19b2content etilize Manual 1081069936
 DocumentsDownloadDownloadLenovo COLAMCOLenovo 21G20026US 165H Technology
 8cf5104a19b21081069968objects 1081069936content 1081069968
 DocumentsDownloadDownloadViewLenovo Viewmmo 8cf5104a19b2mmo 120252903 1727345551 0872
 375744objects 1081069968objects 375744 DocumentsUser ManualDownloadDownloadViewLenovo
 21KS001KCA Notebook 125H Caretek SolutionsLenovo 8cf5104a19b21081069987mmo 1081069987content
 ManualUser 21KS001PUS WQXGA 8cf5104a19b210810699871081070000mmo 1081070000content
 21KS001MCA 8cf5104a19b2108106998710810700031081070000mmo 1081070003content 21KS001VCA
 8cf5104a19b21081069987108107000310810700001081070006mmo 1081070006content 36 8
 21G3S59100Lenovo 53mmo 135288287 1759847875 8672 1476865f3c92cb1 53objects 1476865capital
 14768651081069941f3c92cb1 1476865assets grandandtoy assets 10 81 1081069941capital 21KS0027CA
 8cf5104a19b210810699871081070003108107000010810700061081070009mmo 1081070009content
 DocumentsDocumentationUser ServissLENOVO G5 32GB 2TB inch W11P TopSeller Baechler InfoLenovo
 8cf5104a19b2v110810699871081070003108107000010810700061081070009mmo 8cf5104a19b2baechler ch
 2024 21G2000FMZ 1content DocumentsDocumentationDocumentationUser 1TB UMA InformatiqueLENOVO
 8cf5104a19b2v1v110810699871081070003108107000010810700061081070009mmo 21G2000CMZ
 1baechler 21KS001FCA 21KS001FCALenovo
 8cf5104a19b2v1v1108106998710810700031081070000108107000610810700091081069990mmo
 1081069990content 21G2001HCA 21G2001HCALenovo
 8cf5104a19b2v1v11081069987108107000310810700001081070006108107000910810699901081069957mmo
 1081069957content ||| ||| ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 User Guide Read this first Before
 using this documentation and the product it supports, ensure that you read and understand the following: Safety




[\[pdf\]](#) User Manual Quick Start Guide Specifications Documentation Guide Warranty User Guide ManualLenovo ThinkPad P16s Gen 3 21KTS3D200 16 Touchscreen Notebook WUXGA 60 Hz Intel Core Ultra 7 1st 165H vPro Technology 64 GB 1 TB SSD English US Keyboard Black Caretek IT Solutions1086158158content etilize Manual 1086158158 ||| User Guide ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 Read this first Before using this documentation and the product it supports, ensure that you read and understand the following: Safety and Warranty Guide Setup Guide Generic Safety and Compliance Notices Fourth Edition March 2025 Copyrig... lang:en score:46 filesize: 23.22 M page_count: 86 document date: 2025-06-13




[ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 User Guide](#) User guide for Lenovo ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 laptops, covering setup, features, security, advanced settings, CRU replacement, and support. lang:en score:44 filesize: 1.57 M page_count: 86 document date: 2025-07-28




[\[pdf\]](#) User Manual Quick Start Guide Specifications Documentation Guide Warranty ThinkPad P14s Gen 5 and P16s 3 User Guide Lenovo Intel Laptop 21G20048MX user manual 24 MB mmo 122794158 1740366126 222 2272129 objects icecat biz ||| ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 User Guide Read this first Before using this documentation and the product it supports, ensure that you read and understand the following: Safety and Warranty Guide Setup Guide Generic Safety and Compliance Notices Third Edition November 2024 Copyr... lang:en score:44 filesize: 23.87 M page_count: 86 document date: 2024-12-19



[\[pdf\]](#) Quick Start Guide Instructions Documentation Guide Warranty ThinkPad P14s Gen 5 and P16s 3 Linux User Guide 2 days ago — Fast Startup first then disable the built in battery © Copyright Lenovo 2024 31 Page 38 Disable Follow instructions to p14s gen5 p16s gen3 linux ug en lenovo pocbbs mobiles ||| ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 Linux User Guide Read this first Before using this documentation and the product it supports, ensure that you read and understand the following: Safety and Warranty Guide Setup Guide Generic Safety and Compliance Notices First Edition May 2024 Copy... lang:en score:44 filesize: 21.3 M page_count: 62 document date: 2024-05-28




[\[pdf\]](#) User Manual Quick Start Guide Specifications Documentation Guide Warranty
ThinkPad P14s Gen 5 and P16s 3 User Guide Manual Lenovo 21KS001MUS 16 Mobile Workstation WUXGA
Intel Core Ultra 7 155H GB 512 SSD English Keyboard Black antonline 1081069994 content etilize |||
ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 User Guide Read this first Before using
this documentation and the product it supports, ensure that you read and understand the
following: Safety and Warranty Guide Setup Guide Generic Safety and Compliance Notices
First Edition May 2024 Copyright ...
lang:en score:42 filesize: 23.59 M page_count: 86 document date: 2024-06-25



[\[pdf\]](#) Quick Start Guide Specifications Documentation Guide Warranty

ThinkPad P14s Gen 5 and P16s 3 User Guide p14s gen5 p16s gen3 ug en lenovo pccbbs mobiles ||| ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 User Guide Read this first Before using this documentation and the product it supports, ensure that you read and understand the following: Safety and Warranty Guide Setup Guide Generic Safety and Compliance Notices First Edition May 2024 Copyright ...

lang:en score:38 filesize: 23.59 M page_count: 86 document date: 2024-04-23



[\[pdf\]](#) Specifications

ThinkPad P16s Gen 3 Intel Missing pairing Show results with Spec psref lenovo syspool Sys ||| ThinkPad P16s Gen 3 Intel OVERVIEW PSREF Product Specifications Reference 1. Smart card reader * 2. Nano-SIM card slot * 3. USB-A USB 5Gbps 4. Ethernet GbE RJ-45 5. Kensington Nano Security Slot 6. HDMI 7. 2x Thunderbolt 4 8. USB-A USB 5Gbps , Always On 9. 3.5mm headphone jack Notes: lte...

lang:en score:37 filesize: 1.1 M page_count: 7 document date: 2024-05-20



[\[pdf\]](#) User Manual Documentation Borchure

ThinkPad P16s Gen 3 Lenovo Additional 9 LENOVO NB WS P16S G3 ULT7 32G 1T 11P 21KS0026US custom options user manual Available Documentation User ManualManufacturer BrochureAdditional 1Additional 2Additional 3Additional 4Additional 5Additional 6Additional 7Additional 8 1081069978 content utilize ||| Professional machines for advanced users Designed for business users who tackle computeintensive wor ... r mobile workstations and ensures best-in-class reliability even when you re away from the office. ThinkPad P16s Gen 3 Powered by the advanced Intel H Series CoreTM Ultra 9 Processor with up to 16 co...

lang:en score:37 filesize: 4.33 M page_count: 3 document date: 0000-00-00




[\[pdf\]](#) User Manual Quick Start Guide Guide

Download Lenovo ThinkPad P14s Gen 5 Setup Guide Intel 21G2000DGE lap4worx de P16s 3 media 2b a0 cc |||

ThinkPad P14s Gen 5 / ThinkPad P16s Gen 3 Get started Operazioni preliminari Aan de slag Erste Schritte Prise en main * Lenovo USB-C to VGA Adapter * Lenovo USB-C to DisplayPort Adapter * Lenovo HDMI to VGA Adapter * Lenovo USB-C to Ethernet Adapter * For selected models I Per alcuni...

lang:it score:37 filesize: 1.38 M page_count: 14 document date: 2024-03-20



[\[pdf\]](#) Documentation Guide

ThinkPad P14s Gen 5 et P16s 3 Guide d'utilisation p14s gen5 p16s gen3 ug fr lenovo pccbbs mobiles ||| ThinkPad P14s Gen 5 et ThinkPad P16s Gen 3 Guide d'utilisation lire en premier Avant d'utiliser cette documentation et le produit associ, prenez connaissance des informations suivantes : Consignes de securit et dclaration de garantie Guide de configuration Consignes gnrals de securit et de conf...

lang:fr score:36 filesize: 23.64 M page_count: 90 document date: 2024-08-08




[\[pdf\]](#) User Manual Guide

ThinkPad P14s Gen 5 and P16s 3 Hardware Maintenance Manual Click here for Additional 5Lenovo 21KS0027US 16 Mobile Workstation WUXGA Intel Core Ultra 7 155H 32 GB 1 TB SSD English Keyboard Black FireOwls Corporation 1Click 2Click 3Click 41081069982content etilize 1081069982 Lenovo G3 9 185H 64GB RAM 1TB DE ServiceanleitungClick 5ServiceanleitungLenovo 4Lenovo 21KS000NGE od PLN 10548 58 2024 Porównanie cen Cenowarka Polskav1v1gzhls at blob ldb a e 2 db1c70404231c9597f3cdba841fd7588dd2acontent 1081069982gzhls

db1c70404231c9597f3cdba841fd7588dd2a 5ServiceanleitungAdditional 3Lenovo PolskaLenovo 21G20027US 14 3K 21G20027USv1v11081069953gzhls 1081069953 ||| ||| ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 Hardware Maintenance Manual First Edition May 2024 Copyright Lenovo 2024. LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration GSA c ||| ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 Hardware Maintenance Manual First Edition May 2024 Copyright Lenovo 2024. LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration GSA c

ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 Hardware Maintenance Manual First Edition May 2024 Copyright Lenovo 2024. LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration GSA contract, use, reproduction, or disclosure is subject ...

lang:en score:36 filesize: 45.77 M page_count: 114 document date: 2024-05-28



[\[pdf\]](#) Specifications

OVERVIEW ThinkPad P16s Gen 3 Intel Spec v 9b8e0b4c 32d2 48db 8c29 efd258f8e487 psref gtm lenovo syspool Sys |||

ThinkPad P16s Gen 3 Intel OVERVIEW PSREF Product Specifications Reference 1. Smart card reader * 2. Nano-SIM card slot * 3. USB-A USB 5Gbps 4. Ethernet GbE RJ-45 5. Kensington Nano Security Slot 6. HDMI 7. 2x Thunderbolt 4 8. USB-A USB 5Gbps , Always On 9. 3.5mm headphone jack Notes: lte...

lang:en score:36 filesize: 1.24 M page_count: 9 document date: 2024-05-28



ThinkPad P16 Gen 3 and ThinkPad T16g Gen 3

[pdf] Quick Start Guide Documentation Guide Warranty

Linux User Guide Lenovo TS P16s G3 U7 265H 64 1T W11P1 Intel Core Ultra 7 265HX Mobile workstation 40 6 cm 16 WUXGA GB DDR5 SDRAM 1 TB SSD NVIDIA RTX PRO 2000 Blackwell Wi Fi 802 11be Windows 11 Pro Nordic Black for 21 MLenovo 21RQ000BMXmmo 134686994 1762357111 3413 103objects icecat biz objects mmo 103 ThinkPad P16 Gen 3 255HX 3000 Norwegian 21RQ000BMXLenovo 21RRS10W00mmo 103mmo 137619741 1762859796 4834 3430398objects 3430398 ||| ||| Linux User Guide ThinkPad P16 Gen 3 and ThinkPad T16g Gen 3 Read this first Before using this documentation and the product it supports, ensure that you read and understand the following: Safety and Warranty Guide Setup Guide Generic Safety Linux User Guide ThinkPad P16 Gen 3 and ThinkPad T16g Gen 3 Read this first Before using this documentation and the product it supports, ensure that you read and understand the following: Safety and Warranty Guide Setup Guide Generic Safety and Compliance Notices First Edition Septemb...

lang:en score:36 filesize: 21.17 M page_count: 59 document date: 2025-08-27



ThinkPad P14s Gen 5 / ThinkPad P16s Gen 3

Lenovo ThinkPad P14s Gen 5 / P16s Gen 3 Setup Guide

This setup guide provides essential information for setting up and using the Lenovo ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 laptops, including hardware overviews, connectivity options, and safety information.


lang:it score:35 filesize: 3.73 M page_count: 14 document date: 2025-05-06



[pdf] Dimension Guide Borchure

Lenovo ThinkPad P16s Gen 3 21KS001HUS Tech America 1081069945 content etilize Manufacturer Brochure ||| ThinkPad P16s Gen 3 Intel 21KS001HUS PERFORMANCE Processor 1 Intel CoreTM Ultra 7 155H, 16C 6P 8E 2LPE / 22T, Max Turbo up to 4.8GHz, 24MB NPU Intel AI Boost integrated in Intel CoreTM Ultra processor Graphics Integrated Intel Graphics Chipset Intel SoC Platform Memory 1x 16GB SO-DIMM DDR5...

lang:en score:35 filesize: 541.63 K page_count: 2 document date: 2024-07-04




[pdf] Specifications

Pełna specyfikacja Lenovo ThinkPad P16s Gen 3 Laptop INTEL G3 Sklep Laphard pl Certyfikowany Partner Intel Spec laphard userdata public assets QuickSpec |||

ThinkPad P16s Gen 3 Intel OVERVIEW PSREF Product Specifications Reference 1. Smart card reader * 2. Nano-SIM card slot * 3. USB-A USB 5Gbps 4. Ethernet GbE RJ-45 5. Kensington Nano Security Slot 6. HDMI 7. 2x Thunderbolt 4 8. USB-A USB 5Gbps , Always On 9. 3.5mm headphone jack Notes: Ite...

lang:en score:35 filesize: 1.24 M page_count: 9 document date: 2024-07-05




[\[pdf\]](#) Dimension Guide Borchure

Lenovo ThinkPad P16s Gen 3 21KS001NUS Tech America 1081069989 content etilize Manufacturer Brochure

|||

ThinkPad P16s Gen 3 Intel 21KS001NUS PERFORMANCE Processor Intel Core™ Ultra 7 155H, 16C 6P 8E 2LPE / 22T, Max Turbo up to 4.8GHz, 24MB AI PC Category AI-Ready Workstations NPU Intel AI Boost, up to 11 TOPS Graphics NVIDIA RTX 500 Ada Generation 4GB GDDR6 Chipset Intel SoC Platform Memory ...

lang:en score:35 filesize: 561.69 K page_count: 2 document date: 2024-09-23



[\[pdf\]](#) Dimension Guide Borchure

Lenovo ThinkPad P16s Gen 3 21KS001FUS Tech America 1081069944 content etilize Manufacturer Brochure

|||

ThinkPad P16s Gen 3 Intel 21KS001FUS PERFORMANCE Processor 1 Intel Core™ Ultra 7 165H, 16C 6P 8E 2LPE / 22T, Max Turbo up to 5.0GHz, 24MB AI PC Category AI-Ready Workstations NPU Intel AI Boost, up to 11 TOPS Graphics NVIDIA RTX 500 Ada Generation 4GB GDDR6 Chipset Intel SoC Platform Memo...

lang:en score:35 filesize: 562.6 K page_count: 2 document date: 2024-09-16



[\[pdf\]](#) Dimension Guide

Datenblatt Lenovo ThinkPad P16s Gen 3 Intel 21KS0001GE lap4worx de media 34 ee 74 |||

ThinkPad P16s Gen 3 Intel 21KS0001GE PERFORMANCE Processor 1 Intel Core™ Ultra 7 155H, 16C 6P 8E 2LPE / 22T, Max Turbo up to 4.8GHz, 24MB Graphics 2 Integrated Intel Arc™ Graphics Chipset Intel SoC Platform Memory 2x 16GB SO-DIMM DDR5-5600 Non-ECC Memory Slots Two DDR5 SO-DIMM slots, du...

lang:en score:35 filesize: 526.02 K page_count: 2 document date: 2024-06-10



[\[pdf\]](#) Dimension Guide

Datenblatt Lenovo ThinkPad P16s Gen 3 Intel 21KS000AGE lap4worx de media 9b 6f 28 |||

ThinkPad P16s Gen 3 Intel 21KS000AGE PERFORMANCE Processor 1 Intel Core™ Ultra 7 155H, 16C 6P 8E 2LPE / 22T, Max Turbo up to 4.8GHz, 24MB Graphics NVIDIA RTX 500 Ada Generation 4GB GDDR6 Chipset Intel SoC Platform Memory 2x 16GB SO-DIMM DDR5-5600 Non-ECC Memory Slots Two DDR5 SO-DIMM slot...

lang:en score:35 filesize: 526.12 K page_count: 2 document date: 2024-06-10



[\[pdf\]](#) Dimension Guide

Datenblatt Lenovo ThinkPad P16s Gen 3 Intel 21KS000NGE lap4worx de media 04 57 2f |||

ThinkPad P16s Gen 3 Intel 21KS000NGE PERFORMANCE Processor 1 Intel Core™ Ultra 9 185H, 16C 6P 8E 2LPE / 22T, Max Turbo up to 5.1GHz, 24MB Graphics 2 Integrated Intel Arc™ Graphics Chipset Intel SoC Platform Memory 2x 32GB SO-DIMM DDR5-5600 Non-ECC Memory Slots Two DDR5 SO-DIMM slots, du...

lang:en score:35 filesize: 526.1 K page_count: 2 document date: 2024-06-10



[\[pdf\]](#) Dimension Guide

Datenblatt Lenovo ThinkPad P16s Gen 3 Intel 21KS002GGE lap4worx de media cb 1d 45 |||

ThinkPad P16s Gen 3 Intel 21KS002GGE PERFORMANCE Processor 1 Intel Core™ Ultra 7 165H, 16C 6P 8E 2LPE / 22T, Max Turbo up to 5.0GHz, 24MB Graphics NVIDIA RTX 500 Ada Generation 4GB GDDR6 Chipset Intel SoC Platform Memory 2x 32GB SO-DIMM DDR5-5600 Non-ECC Memory Slots Two DDR5 SO-DIMM slot...

lang:en score:35 filesize: 526.13 K page_count: 2 document date: 2024-06-10

USB-C to Ethernet Adapter * For selected models - 1 - Overview ThinkPad P14s Gen 5
Press to log in to the computer Navigate as a tradit...

lang:en score:35 filesize: 1.11 M page_count: 11 document date: 2024-03-29
[\[pdf\]](#)




ThinkPad P16s Gen 3 Lenovo faa17df3 40b5 414e b4bd 750d491b39c3zoro static cms enhanced
750d491b39c3 |||

Professional machines for advanced users Designed for business users who tackle
computeintensive wor ... mobile workstations and ensures best-in-class reliability even
when you re away from the office. ThinkPad P16s Gen 3 Powered by the advanced Intel H
Series Core Ultra 9 Processor with up to 16...

lang:en score:35 filesize: 4.33 M page_count: 3 document date: 2025-01-31

[\[pdf\]](#) User Manual Guide

Hardware Maintenance Manual Lenovo ThinkPad P16 Gen 3 Intel Core Ultra 7 265HX Mobile workstation 40 6
cm 16 WUXGA 32 GB DDR5 SDRAM 1 TB SSD NVIDIA RTX PRO 2000 Blackwell Wi Fi 802 11be Windows 11
Pro UK English Black 21RQ000AUK user manual 46 MBmmo 132935538 1760704631 0464 1065800objects
icecat biz objects mmo 1065800 MBLenovo 9 275HX 64 4000 Italian 21RQ002VUS 1065800mmo 137281585
1761224338 5952 609595objects 609595 21RQ0012US 609595mmo 133686241 1761224310 079 81objects
81 21RQ001TUS 133686265 1761224319 6826 121mmo 121objects 21RQ002XUS 81mmo 137281587
1761224349 3252 77objects 77 21RQ001XUS 133686273 1761224329 0562 28mmo 28objects 255HX 1000
US 21RQ001HUS 133686242 1761313285 8893 2381626mmo 2381626objects 21RQ001DUS 133686247
1761313257 5622 2504182mmo 2504182objects 21RQ001BUS 133686249 1761313234 0808 1507089mmo
1507089objects 21RQ001JUS 1336862695 1761313297 1861 1100118mmo 1100118objects WQUXGA 2
21RQ001MUS 1336862749 1761313311 3791 2816998mmo 2816998objects 21RQ001FUS 133686272
1761313272 0008 1595887mmo 1595887objects 771087276943objects 77assets grandandtoy assets
Additional 10 87 1087276943 Swiss 21RQ000QGE 77mmo 134780117 1761646776 7485 121assets
21RQ000MGE 134780667 1761646732 9509 53mmo 53objects 21RQ000LGE 134779229 1761646719 1264
21RQ000PGE 134780118 1761646757 9722 115objects 115assets TS P16s G3 U7 265H 1T W11P1 Nordic
21RQ000BMX 134686994 1762357061 0549 73mmo 73objects 512 Danish 21RRS1M104 137577121
1762437831 0188 93mmo 93objects 21RQ000PMH 115mmo 134662685 1761646657 9481 58objects 58assets
3000 Norwegian 21RRS10W00 137619741 1762859635 6851 1552034mmo 1552034objects German
21RQ000KGE 134780704 1761657032 2295 1020562mmo 1020562objects 96 21RQ000GGE 134779225
1761657033 3764 111mmo 111objects 21RQ0006GE 134779242 4803 131mmo 131objects 21RRS10X00
137619742 1762859632 1667 391282mmo 391282objects ||| ||| Hardware Maintenance Manual ThinkPad P16
Gen 3 and ThinkPad T16g Gen 3 First Edition September 2025 Copyright Lenovo 2025. LIMITED AND
RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration
||| Hardware Maintenance Manual ThinkPad P16 Gen 3 and ThinkPad T16g Gen 3 First Edition September 2025
Copyright Lenovo 2025. LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered
pursuant to a General Services Administration ||| Hardware Maintenance Manual ThinkPad P16 Gen 3 and
ThinkPad T16g Gen 3 First Edition September 2025 Copyright Lenovo 2025. LIMITED AND RESTRICTED
RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration ||| Hardware
Maintenance Manual ThinkPad P16 Gen 3 and ThinkPad T16g Gen 3 First Edition September 2025 Copyright
Lenovo 2025. LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a
General Services Administration ||| Hardware Maintenance Manual ThinkPad P16 Gen 3 and ThinkPad T16g
Gen 3 First Edition September 2025 Copyright Lenovo 2025. LIMITED AND RESTRICTED RIGHTS NOTICE: If
data or software is delivered pursuant to a General Services Administration ||| Hardware Maintenance Manual
ThinkPad P16 Gen 3 and ThinkPad T16g Gen 3 First Edition September 2025 Copyright Lenovo 2025. LIMITED
AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services
Administration ||| Hardware Maintenance Manual ThinkPad P16 Gen 3 and ThinkPad T16g Gen 3 First Edition
September 2025 Copyright Lenovo 2025. LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is
delivered pursuant to a General Services Administration ||| Hardware Maintenance Manual ThinkPad P16 Gen 3
and ThinkPad T16g Gen 3 First Edition September 2025 Copyright Lenovo 2025. LIMITED AND RESTRICTED
RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration ||| Hardware
Maintenance Manual ThinkPad P16 Gen 3 and ThinkPad T16g Gen 3 First Edition September 2025 Copyright




[\[pdf\]](#) Dimension Guide

DatenblattLenovo ThinkPad P16s Gen 3 Intel 21KS0001GE lap4worx deLenovo Datenblatt v2lap4worx de media 17 58 c6 Lenovo v2 |||

ThinkPad P16s Gen 3 Intel 21KS0001GE PERFORMANCE Processor Intel Core™ Ultra 7 155H, 16C 6P 8E 2LPE / 22T, Max Turbo up to 4.8GHz, 24MB AI PC Category AI-Ready Workstations NPU Intel AI Boost, up to 11 TOPS Graphics 1 Integrated Intel Arc™ Graphics Chipset Intel SoC Platform Memory 2x 16...

lang:en score:34 filesize: 561.42 K page_count: 2 document date: 2024-10-07



[\[pdf\]](#) Quick Start Guide Specifications Documentation Guide Warranty

ThinkPad P14s Gen 5 and P16s 3 User Guide Bedienungsanleitung Lenovo G5 Intel Core Ultra 7 155H 32GB RAM 1TB SSD RTX 500 Ada Generation UK Preisvergleich Geizhals Deutschland

138b69d99466a029bd343ee8365cc0a7e6ed gzhls at blob ldb 2 9 |||

ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 User Guide Read this first Before using this documentation and the product it supports, ensure that you read and understand the following: Safety and Warranty Guide Setup Guide Generic Safety and Compliance Notices First Edition May 2024 Copyright ...

lang:en score:34 filesize: 23.6 M page_count: 86 document date: 2024-05-28



[Lenovo ThinkPad P14s Gen 5 & P16s Gen 3 Setup Guide](#)

A comprehensive setup guide for the Lenovo ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 laptops, covering initial setup, overview of features, and technical specifications.

lang:en score:33 filesize: 1 M page_count: 11 document date: 2025-07-28



[\[pdf\]](#) Catalog

ThinkPad P16s Gen 3 Lenovo v1gfx3 senetic akeneo catalog 2 8 a

282a81aae9e0be1cabde914acd492b20c8c6568 1760979 21KS003QGE icecat multimedia leaflet 1 en GB |||

Professional machines for advanced users Designed for business users who tackle computeintensive wor ... mobile workstations and ensures best-in-class reliability even when you re away from the office. ThinkPad P16s Gen 3 Powered by the advanced Intel H Series Core Ultra 9 Processor with up to 16...

lang:en score:33 filesize: 4.33 M page_count: 3 document date: 2025-02-12



[\[pdf\]](#) User Manual Guide

ThinkPad P14s Gen 5 and P16s 3 Hardware Maintenance Manual p14s gen5 p16s gen3 hmm en lenovo pccbbs mobiles |||

ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 Hardware Maintenance Manual First Edition May 2024 Copyright Lenovo 2024. LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration GSA contract, use, reproduction, or disclosure is subject ...

lang:en score:33 filesize: 45.74 M page_count: 114 document date: 2024-04-28



[\[pdf\]](#) Datasheet Borchure

ThinkPad P16s Gen 3 Lenovo 21KS000QML laptop Black Product Brochure Datasheet 4 MB mmo 125297633 1744075287 5904 4018239 objects icecat biz |||

Elevate Professional Endeavors with Powerhouse Workstations Designed for business users who tackle c ... r mobile workstations and ensures best-in-class reliability even when you re away from the office. ThinkPad P16s Gen 3 Powered by the advanced Intel H Series CoreTM Ultra 9 Processor with up to 16 co...

lang:en score:33 filesize: 4.36 M page_count: 3 document date: 0000-00-00




[\[pdf\]](#) User Manual Guide

ThinkPad P14s Gen 5 and P16s 3 Hardware Maintenance Manual Download Lenovo Wartungshandbuch Intel 21G2000DGE lap4worx de media b8 79 1a |||

ThinkPad P14s Gen 5 and ThinkPad P16s Gen 3 Hardware Maintenance Manual First Edition May 2024 Copyright Lenovo 2024. LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration GSA contract, use, reproduction, or disclosure is subject ...

lang:en score:32 filesize: 45.77 M page_count: 114 document date: 2024-05-28




[pdf]

PCF Template csaunder's original compliance lenovo content dam site design esg document library global pcf sheets notebooks ultrabooks thinkpad p16s gen 3 intel jcr renditions |||

Product Carbon Footprint ThinkPad P16s Gen 3 Intel 0DFKLQH7 SHV 21KS , 21KT
 Device Type: Notebook 5HSRUW DWH 05/06/2024 Lenovo values our commitment to the environment. As part of that commitment, -FOPWP performT a streamlined product lifecycle analysis in accordance with the IEC TR 62921 standar...

lang:en score:32 filesize: 362.98 K page_count: 1 document date: 2024-05-07




[pdf] Dimension Guide Borchure

ThinkPad P16s Gen 3 Intel 21KS0027USv1 assets grandandtoy assets Manufacturer Brochure 10 81 1081069982 |||

ThinkPad P16s Gen 3 Intel 21KS0027US PERFORMANCE Processor 1 Intel Core Ultra 7 155H, 16C 6P 8E 2LPE / 22T, Max Turbo up to 4.8GHz, 24MB NPU Intel AI Boost integrated in Intel Core Ultra processor Graphics NVIDIA RTX 500 Ada Generation 4GB GDDR6 Chipset Intel SoC Platform M...

lang:en score:32 filesize: 576.88 K page_count: 3 document date: 2024-07-05



[pdf]

ThinkPad P16 Gen 3 21RQ000GGE PSREFThinkPad PSREFv1gzhls at blob ldb 6 f a 4 4a971eb8d5629b6f0198a809bed1e7b3840c |||

ThinkPad P16 Gen 3 21RQ000GGE PERFORMANCE Processor Intel Core Ultra 9 275HX, 24C 8P 16E / 24T, Max Turbo up to 5.4GHz, 36MB AI PC Category AI-Ready Workstations NPU Integrated Intel AI Boost, up to 13 TOPS Graphics NVIDIA RTX PRO 2000 Blackwell Generation 8GB GDDR7 Laptop GPU Chipset ...

lang:en score:32 filesize: 219.4 K page_count: 2 document date: 2025-10-29




[pdf] Dimension Guide

ThinkPad P16s Gen 3 Intel 21KS0001GE PSREF f8cffe520c4b46cfd04962ce5d7724e0cef7 gzhls at blob ldb 1 f c |||

ThinkPad P16s Gen 3 Intel 21KS0001GE PERFORMANCE Processor 1 Intel CoreTM Ultra 7 155H, 16C 6P 8E 2LPE / 22T, Max Turbo up to 4.8GHz, 24MB NPU Intel AI Boost integrated in Intel CoreTM Ultra processor Graphics 2 Integrated Intel ArcTM Graphics Chipset Intel SoC Platform Memory 2x 16GB SO-...

lang:en score:32 filesize: 541.42 K page_count: 2 document date: 2024-06-17



[Lenovo ThinkPad P16s Gen 3 \(Intel\) 21KS001FUS Technical Specifications](#)

Detailed specifications for the Lenovo ThinkPad P16s Gen 3 (Intel) 21KS001FUS, including processor, memory, storage, display, graphics, connectivity, security features, and certifications.

lang:en score:32 filesize: 95.42 K page_count: 2 document date: 2025-07-28




[\[pdf\] Borchure](#)

Manufacturer BrochureLenovo ThinkPad P16s Gen 3 21KS001FCA 16 Notebook WQUXGA 21KS001FCA1081069990content etilize Brochure 1081069990 |||

ThinkPad P16s Gen 3 Intel 21KS001FCA PERFORMANCE Processor Intel Core Ultra 7 165H, 16C 6P 8E 2LPE / 22T, Max Turbo up to 5.0GHz, 24MB AI PC Category AI-Ready Workstations NPU Integrated Intel AI Boost, up to 11 TOPS Graphics NVIDIA RTX 500 Ada Generation 4GB GDDR6 Chipset Intel ...

lang:en score:32 filesize: 562.08 K page_count: 2 document date: 2025-01-08




[\[pdf\] Borchure](#)

Manufacturer BrochureLenovo ThinkPad P16s Gen 3 21KS0020US 16 Notebook WQUXGA 21KS0020US1081069950content etilize Brochure 1081069950 |||

ThinkPad P16s Gen 3 Intel 21KS0020US PERFORMANCE Processor Intel Core Ultra 7 165H, 16C 6P 8E 2LPE / 22T, Max Turbo up to 5.0GHz, 24MB AI PC Category AI-Ready Workstations NPU Integrated Intel AI Boost, up to 11 TOPS Graphics NVIDIA RTX 500 Ada Generation 4GB GDDR6 Chipset Intel ...

lang:en score:32 filesize: 562.55 K page_count: 2 document date: 2025-01-08



[\[pdf\] Dimension Guide Borchure](#)

Manufacturer s Product Brochure Lenovo ThinkPad P16s Gen 3 21KS0043US 16 Mobile Workstation WUXGA Intel Core Ultra 7 165H vPro Technology GB 512 SSD English Keyboard Black Camcor 226982594 LENOVO camcor brochures |||

ThinkPad P16s Gen 3 Intel 21KS0043US PERFORMANCE Processor Intel Core™ Ultra 7 165H, 16C 6P 8E 2LPE / 22T, Max Turbo up to 5.0GHz, 24MB AI PC Category AI-Ready Workstations NPU Integrated Intel AI Boost, up to 11 TOPS Graphics Integrated Intel Graphics Chipset Intel SoC Platform Memory 1x ...

lang:en score:32 filesize: 561.83 K page_count: 2 document date: 2024-11-08