

[Manuals.plus](#) /

› [CLP](#) /

› CLP Elmira Dining Chair Instruction Manual

CLP Elmira

CLP Elmira Dining Chair Instruction Manual

Model: Elmira

INTRODUCTION

Thank you for choosing the CLP Elmira Dining Chair. This manual provides essential information for the safe assembly, use, and maintenance of your new chair. Please read these instructions carefully before assembly and retain them for future reference.





Image: The CLP Elmira Dining Chair, featuring green velvet upholstery and gold metal legs, positioned next to a wooden dining table in a modern kitchen.

SAFETY INFORMATION

- Ensure all components are present and undamaged before assembly.
- Assemble the chair on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly to avoid damaging components.
- Regularly check all fasteners to ensure they remain tight.
- Do not stand on the chair.
- The maximum weight capacity for this chair is 120 kg (264 lbs).
- Keep children away from small parts during assembly.

PACKAGE CONTENTS

Please verify that all the following parts are included in your package:


- 1 x Seat with backrest (upholstered)
- 1 x Set of four metal legs
- 1 x Hardware pack (screws, washers, Allen key)

Note: No additional components are included beyond the chair parts.

SETUP AND ASSEMBLY

Follow these steps to assemble your CLP Elmira Dining Chair:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, flat surface to prevent damage.
2. **Attach Legs:** Identify the four metal legs. Align each leg with the corresponding mounting points on the underside of the seat frame.
3. **Secure Legs:** Insert the provided screws and washers through the leg brackets and into the seat frame. Hand-tighten all screws initially.
4. **Final Tightening:** Once all legs are in place, gradually tighten all screws using the included Allen key. Ensure they are secure but do not overtighten.
5. **Check Stability:** Place the assembled chair on a flat surface and gently test its stability. If the chair wobbles, check that all screws are evenly tightened.



Images: Left, a close-up of the chair's four metal legs. Right, an illustration highlighting the floor protectors on the chair legs, designed to prevent damage to delicate floors.

OPERATING INSTRUCTIONS (USAGE)

The CLP Elmira Dining Chair is designed for comfortable seating in dining rooms or kitchens. Its ergonomic design and padded seat and backrest provide comfort for extended periods.

- Use the chair on a flat, stable surface.
- Avoid sudden movements or leaning excessively to one side to prevent tipping.
- The chair is intended for indoor use only.



Image: A detailed view of the chair's comfortable padding on both the seat and backrest, indicating its ergonomic design.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your Elmira Dining Chair, follow these care instructions:

- **Cleaning:** For light dirt, wipe the velvet upholstery with a damp cotton cloth. Avoid abrasive cleaners or harsh chemicals.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub, as this can spread the stain.
- **Dusting:** Regularly dust the chair with a soft brush or vacuum cleaner with an upholstery attachment to prevent dust buildup.
- **Frame Care:** Wipe the metal frame with a soft, dry cloth.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading of the upholstery.




Image: An illustration depicting a cleaning cloth and an instruction manual, symbolizing proper care and maintenance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair wobbles	Screws are loose or unevenly tightened.	Check and tighten all assembly screws evenly. Ensure the chair is on a flat surface.
Scratches on floor	Floor protectors are missing or damaged.	Ensure all floor protectors are securely attached to the chair legs. Replace if damaged.
Upholstery appears dirty	Dust or light stains.	Wipe with a damp cotton cloth. For persistent stains, consult a professional upholstery cleaner.

SPECIFICATIONS

Model Name	Elmira
Brand	CLP
Overall Dimensions (D x W x H)	53 cm x 50 cm x 84 cm (20.9 in x 19.7 in x 33.1 in)
Seat Height	47 cm (18.5 in)
Seat Dimensions (W x D)	35 cm x 42 cm (13.8 in x 16.5 in)
Backrest Height	39 cm (15.4 in)
Weight	5 kg (11 lbs)
Maximum Load Capacity	120 kg (264 lbs)
Frame Material	Metal (Gold finish)
Upholstery Material	Velvet (100% Polyester)
Filling Material	Polyester
Color (Current Variant)	Green
Assembly Required	Yes



Image: A technical diagram illustrating the precise dimensions of the Elmira dining chair, including overall height, width, depth, seat height, and backrest height.



Image: An icon visually representing the maximum load capacity of 120 kg for the chair.

WARRANTY INFORMATION

CLP products are manufactured with high-quality materials and craftsmanship. For specific warranty details, please refer to the warranty card included with your purchase or contact CLP customer support directly. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact CLP customer support. Refer to the contact information provided with your product packaging or visit the official CLP website.

For more information, you may visit the [CLP Brand Store on Amazon](#).

© 2024 CLP. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question