Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VECELO KHD-SS07-WHT-C

VECELO Entryway Shoe Bench with Storage (Model KHD-SS07-WHT-C) Instruction Manual

Model: KHD-SS07-WHT-C | Brand: VECELO

Introduction

Thank you for choosing the VECELO Entryway Shoe Bench with Storage. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new shoe bench. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The VECELO Entryway Shoe Bench with Storage, featuring a white finish, flip drawers, and a comfortable seat cushion.

Setup and Assembly

This shoe bench requires assembly. Please ensure all parts are present before starting. A detailed instruction guide and hardware kits are included with your purchase.

Before You Begin:

- Unpack all components and verify against the parts list provided in the packaging.
- Gather necessary tools (typically a screwdriver, not always included).
- Assemble on a soft, clean surface to prevent scratches.

Assembly Tips:

- Pay close attention to the orientation of parts, especially during the final steps.
- When attaching the top and bottom sections, note that the lock nuts (often labeled 'A' in hardware kits) have a screw

side and a Phillips head side. Screw the threaded side into the top board first. The Phillips head side will then click into the corresponding locking nuts on the other component.

- Do not overtighten screws to avoid damaging the material.



Image: Diagram illustrating the overall dimensions of the shoe bench (47.2" W x 13.8" D x 27" H) and internal compartment measurements.

Operation

Using the Flip Drawers:

The shoe bench features two flip-down drawers designed for shoe storage. To open, gently pull the metal handle located on the front of each drawer. The drawer will pivot downwards, revealing two tiers for shoes.



Image: Detail of the gold-colored metal handle and the mechanism of the flip-down shoe drawers.

Adjustable Dividers:

Each flip drawer contains internal dividers that are adjustable and removable. This allows you to customize the storage space to accommodate various shoe sizes and types, from flats to boots. To adjust, carefully slide the divider out of its current slot and reposition it into another slot. To remove, simply pull the divider completely out.




Image: Illustration demonstrating the three adjustable height positions for the internal shelves within the shoe storage compartments, allowing for different shoe heights.

Using the Seat Cushion:

The bench is equipped with a thick, soft PU leather cushion for comfortable seating. This cushion is removable for cleaning or if you prefer to use the bench without it. The cushion is designed to provide a comfortable surface for sitting while putting on or taking off shoes.



Image: Exploded view showing the layers of the seat cushion, including smooth PU leather, thick foam, sturdy plywood, and non-woven fabric, highlighting its comfortable and durable construction.

Side Storage Cabinet:

The integrated side cabinet provides additional enclosed storage. This space is suitable for items such as umbrellas, bags, or other entryway essentials. The internal shelf within this cabinet is also adjustable, offering flexibility for various item sizes.



Image: The interior of the side storage cabinet, showing an adjustable shelf and space for storing items like a basket or umbrellas.

Maintenance and Care

Cleaning the Seat Cushion:

The PU leather cushion is waterproof and easy to clean. For general cleaning, wipe with a damp cloth and mild soap. For deeper cleaning, the cushion can be hand washed. Allow to air dry completely before reattaching to the bench.

Cleaning the Bench Frame:

Wipe the wooden and metal surfaces with a soft, dry or slightly damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish. Ensure all surfaces are dry after cleaning.

General Care:

- Periodically check and tighten all screws and fasteners to ensure stability.
- Avoid placing hot items directly on the surface.
- Do not expose the bench to excessive moisture or direct sunlight for prolonged periods.

Troubleshooting

Stability Issues:

- If the bench feels wobbly, re-check all assembly connections. Ensure all screws are securely tightened.
- Verify that the bench is placed on a flat, even surface.

Flip Drawers Not Operating Smoothly:

- Ensure no objects are obstructing the drawer mechanism.
- Check that the drawer slides and hinges are properly aligned and free of debris.

Shoe Fit Limitations:

- The internal depth of the flip drawers may not accommodate all shoe sizes, particularly larger women's shoes (e.g., size 7 and above) or men's shoes. Utilize the adjustable and removable dividers to maximize space for different shoe types.

Specifications

Model Number	KHD-SS07-WHT-C

Brand	VECELO
Color	White
Product Dimensions (D x W x H)	13.8" x 47.2" x 27"
Material	Faux Leather (cushion), Metal (frame), Wood (furniture finish)
Item Weight	57.2 pounds
Maximum Weight Recommendation	400 Pounds
UPC	840408985499



Image: Detail of the sturdy gold-colored steel frame legs, indicating the robust construction of the bench.

Warranty Information

VECELO provides a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. Please retain your proof of purchase for warranty claims.

For detailed warranty terms and conditions, please refer to the documentation included with your product or contact customer support.

Customer Support

Should you encounter any difficulties during installation, operation, or if you have any other questions regarding your VECELO Entryway Shoe Bench, please do not hesitate to contact our customer support team.

We are committed to providing prompt assistance, and your inquiries will typically receive a response within 24 hours.

Please refer to your product packaging or the VECELO official website for the most current contact information.

© 2025 VECELO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9JFNKBP

More documents and user manuals: **https://manuals.plus/**