Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEDIARY c3abe59e-146d-4cd7-848b-74602086ba91

LEDIARY 20-inch Caged Ceiling Fan with Light and Remote - Instruction Manual

Model: c3abe59e-146d-4cd7-848b-74602086ba91

Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your LEDIARY 20-inch Caged Ceiling Fan with Light and Remote. Please read this manual thoroughly before installation and retain it for future reference.

Safety Information

- Ensure power is disconnected at the circuit breaker before installation or maintenance.
- All wiring must be in accordance with national and local electrical codes.
- Consult a qualified electrician if you are unsure about the installation process.
- Do not bend fan blades during installation or cleaning.
- Ensure the mounting structure can support the weight of the fan.
- Keep children away from the fan during operation.

Package Contents

The LEDIARY 20-inch Caged Ceiling Fan package includes all necessary accessories for installation. Please verify all components are present before beginning installation.

- Caged Ceiling Fan Unit (with integrated fan blades and lamp holders)
- Remote Control (2 AAA batteries included)
- Mounting Hardware
- Instruction Manual



Image: Overview of the LEDIARY Caged Ceiling Fan, showing its main components including the caged exterior, internal fan, and light sockets.

Setup and Installation

The LEDIARY Caged Ceiling Fan is designed for easy installation. A detailed instruction manual is included in the

package to guide you through each step. Ensure all electrical connections are secure and follow local electrical codes.

Light Bulb Installation

This fan requires 4 E26 base bulbs (not included). Compatible bulb types include ST21, A19, ST19, T45 incandescent bulbs (up to 60W), and LED bulbs (up to 10W).



Image: Illustration showing the E26*4 bulb base and compatible bulb types (Incandescent Max 60W, LED Max 10W).



Image: Close-up view of the fan's internal structure, showing the mounting bracket and wiring connections for installation.

Operating Instructions

Remote Control Functions

The fan is controlled via the included remote. The remote offers comprehensive control over fan speed, direction, light, and timer settings.

- **Light ON/OFF:** Press the light button to toggle the light.
- **Fan Speed:** Select from 6 fan speeds (1-6) to adjust airflow.
- **Forward/Reverse Mode:** Use the 'F' (Forward) and 'R' (Reverse) buttons to change fan direction for seasonal use. Forward mode (downward airflow) is ideal for cooling in summer, while Reverse mode (upward airflow) helps circulate warm air in winter.
- **Timer:** Set the fan to turn off automatically after 1, 2, 4, or 8 hours.
- **Mute Option:** The remote control features a mute option to silence button beeps.
- **All Off:** Press the 'ALL OFF' button to turn off both the fan and light simultaneously.




Image: Diagram illustrating the remote control layout and its various functions, including light control, fan speed, forward/reverse, and timer settings.

Wall Switch Control

The fan can also be controlled by a single-pole wall switch (not included) for basic light ON/OFF functionality.




Image: Visual representation of controlling the fan and light using both the remote control and a wall switch.

Seasonal Operation



Image: Diagram illustrating the fan's clockwise rotation for summer mode (downward draft for cooling) and reversal for winter mode (upward draft for air circulation and temperature equilibrium).

Your browser does not support the video tag.

Video: Official LEDIARY overview of the Caged Ceiling Fan with Light, demonstrating its features and functionality.

Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan. Always disconnect power before cleaning or performing any maintenance.

- **Cleaning:** Use a soft, damp cloth to clean the fan's exterior. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Replace bulbs with compatible types as specified in the "Setup and Installation" section.
- **Tighten Screws:** Periodically check and tighten all screws on the fan housing and mounting bracket.

Troubleshooting

Problem	Possible Cause	Solution
Fan does not operate.	No power supply; loose wiring; remote control battery low.	Check circuit breaker; ensure all connections are secure; replace remote control batteries.
Light does not turn on.	Bulb faulty or loose; incorrect bulb type; loose wiring.	Replace bulb; ensure correct bulb type and wattage; check wiring connections.
Fan makes excessive noise.	Loose screws; unbalanced blades.	Tighten all screws; ensure blades are properly installed and balanced.
Remote control not responding.	Batteries low or incorrectly inserted; remote not paired.	Replace batteries; refer to the full instruction manual for remote pairing instructions.

If issues persist after attempting these solutions, please contact LEDIARY customer service for assistance.

Specifications

- **Brand:** LEDIARY
- **Model Name:** c3abe59e-146d-4cd7-848b-74602086ba91

- **Product Dimensions:** 20"D x 20"W x 8.5"H
- **Color:** White and Gold
- **Electric Fan Design:** Ceiling Fan
- **Power Source:** AC/DC
- **Style:** Farmhouse
- **Special Features:** Bladeless, Remote Controlled, Timer
- **Recommended Uses:** Cooling (Indoor, Outdoor)
- **Noise Level:** 35 Decibels
- **Wattage:** 60 watts
- **Finish Type:** Brushed
- **Speed:** 1080 RPM (6 speeds)
- **Control Method:** Remote
- **Installation Type:** Flush Mount
- **Item Weight:** 9.28 pounds
- **Batteries:** 2 AAA batteries required (included for remote)

Warranty and Support

All components of the LEDIARY Caged Ceiling Fan (except the motor) are covered by a 2-year after-sales service. Our customer service team is available to respond to and resolve any issues within 24 hours.

For technical support or warranty claims, please contact LEDIARY customer service through the retailer where the product was purchased or visit the official LEDIARY store online.



Image: Graphic detailing LEDIARY's friendly customer service, functional upgrades, and multi-style design.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9JG12KN

More documents and user manuals: **https://manuals.plus/**