Catitru BX17

Catitru BX17 Wireless Earbuds User Manual

Model: BX17 | Brand: Catitru

Introduction

Thank you for choosing the Catitru BX17 Wireless Earbuds. These earbuds are designed to provide a superior audio experience with features tailored for active lifestyles. Enjoy extended playback time, clear calls, and a secure, comfortable fit for sports and daily use.

Key Features:

- **Extended Playtime:** Up to 80 hours of total listening time with the charging case.
- **Secure & Comfortable Fit:** Designed with elastic and soft ear hooks, perfect for sports and workouts.
- **IPX7 Waterproof:** Resistant to water splashes and sweat, ideal for various activities.
- **Fast & Stable Connection:** Bluetooth 5.3 for quick pairing and reliable connectivity.
- **Clear Calls:** Equipped with ENC Noise Canceling Mic for enhanced voice clarity.
- **Intuitive Controls:** Easy-to-use physical buttons for music, calls, and volume.
- **LED Power Display:** Digital display on the charging case to monitor battery levels.

What's in the Box

Please check the contents of your package to ensure all items are present:

- Wireless Earbuds (Left and Right)
- Charging Case
- Type-C Charging Cable
- User Manual
- Eartips (3 sizes: S, M, L)



Image: Contents of the Catitru BX17 package, showing the wireless earbuds, charging case, Type-C cable, user manual, and three pairs of eartips.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The case provides multiple charges for the earbuds.

1. Connect the Type-C charging cable to the charging port on the case and a USB power source.
2. The LED power display on the case will show the charging status and battery percentage.
3. Place the earbuds into the charging case. They will automatically begin charging.



Image: The Catitru BX17 earbuds in their charging case, highlighting the 80-hour battery life and the Type-C charging capability.



Image: A close-up of the charging case's LED digital display, indicating the remaining power for both the charging case and the individual earbuds.

2. Bluetooth Pairing

The earbuds feature a built-in hall switch for fast and convenient pairing.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "BX17" in the list of available Bluetooth devices and select it to connect.
4. Once connected, the earbuds will automatically reconnect to your last paired device when the case is opened.



Image: An illustration demonstrating the Bluetooth 5.3 technology and one-step pairing process, with a smartphone displaying the 'BX17' connection.

3. Wearing the Earbuds

For optimal sound quality and comfort, choose the correct ear tip size and ensure a secure fit.

1. Select the ear tips (S, M, L) that best fit your ear canal.
2. Place the earbud into your ear canal and rotate it slightly to ensure a snug fit.
3. Adjust the flexible ear hook over your ear until it feels comfortable and secure.



Image: A visual representation of the Catitru BX17 earbuds' ergonomic design, flexible earhooks, IPX7 waterproof feature, and the three available ear tip sizes (L, M, S).



Image: A step-by-step guide illustrating how to properly wear the earbuds for a secure and comfortable fit, emphasizing the ergonomic design.

Operating Instructions

Touch Controls

The Catitru BX17 earbuds feature intuitive touch controls for easy management of music playback, calls, and voice assistant.

Action	Left Earbud (L)	Right Earbud (R)
Play/Pause	One Tap	One Tap
Answer/End Call	One Tap	One Tap
Reject Call	Long Press	Long Press
Next Track	Long Press	Long Press
Previous Track	Long Press	Long Press
Volume Up		One Tap
Volume Down	One Tap	
Voice Assistant	Long Press	Long Press



Image: A visual guide to the physical button controls on the Catitru BX17 earbuds, detailing actions for music playback, call handling, and voice assistant activation.

Maintenance

Cleaning

Regular cleaning helps maintain sound quality and hygiene.

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Do not use abrasive cleaners or immerse the earbuds or case in water.

Water Resistance (IPX7)

The earbuds are IPX7 waterproof, meaning they can withstand splashes, sweat, and rain. They are not designed for swimming or prolonged submersion.

- Ensure the charging port cover (if applicable) is securely closed before exposure to water.
- After exposure to water, dry the earbuds completely before placing them back in the charging case to prevent damage.



Image: The Catitru BX17 earbuds shown with water splashing, demonstrating their IPX7 waterproof and sweat-resistant design, making them suitable for sports.

Storage

Store the earbuds in their charging case when not in use to protect them and keep them charged.

Troubleshooting

If you encounter any issues with your Catitru BX17 earbuds, please refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing	◦ Ensure earbuds are charged. ◦ Turn off Bluetooth on your device and turn it back on. ◦ Forget "BX17" in your device's Bluetooth settings and try pairing again. ◦ Place earbuds back in the case, close, then open to reset.
No sound from one earbud	◦ Ensure both earbuds are charged. ◦ Try placing both earbuds back in the case and taking them out again. ◦ Reset the earbuds by forgetting the device and re-pairing.
Charging case not charging	◦ Check the Type-C cable and power adapter. Try a different cable or adapter. ◦ Ensure the charging port is clean and free of debris.

Problem	Possible Solution
Poor sound quality	◦ Ensure earbuds are properly seated in your ears and you are using the correct ear tip size. ◦ Clean the ear tips and speaker mesh. ◦ Move closer to your paired device to avoid interference.

Specifications

Feature	Detail
Model Name	BX17
Brand	Catitru
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Ear Placement	In Ear (Over Ear Hook)
Water Resistance Level	IPX7 Waterproof
Control Type	Touch / Physical Buttons
Total Playtime	Up to 80 hours (with charging case)
Single Charge Playtime	15 hours
Charging Port	Type-C
Microphone	Yes (with ENC Noise Canceling)
Product Dimensions	1.54 x 2.76 x 1.1 inches
Item Weight	5 ounces
Material	Plastic

Warranty and Support

For warranty information or technical support, please contact the manufacturer or your point of purchase. Keep your proof of purchase for any warranty claims.

© 2025 Catitru. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question