

MAHANCRIS BRHB40E01

MAHANCRIS Bakers Rack with Power Outlet

Model: BRHB40E01

INTRODUCTION

Thank you for choosing the MAHANCRIS Bakers Rack with Power Outlet. This multifunctional storage rack is designed to optimize space in your kitchen, dining room, or office, providing convenient storage and power access for various appliances. Please read this manual thoroughly before assembly and use to ensure safe and proper operation.

SAFETY INFORMATION

- Children should not climb on or play with the product.
- Always secure the product with the supplied anti-tip device for stability.
- Ensure all screws are tightened securely before use.
- Do not overload shelves beyond their specified weight capacity.
- Keep electrical components away from water or excessive moisture.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Metal Frame Components (various lengths and shapes)
- Mesh Shelves
- Wooden Top Board
- Power Outlet Strip with Switch and Power Cord

- Adjustable Feet
- S-shaped Hooks (4x)
- L-shaped Hooks (2x)
- Screws (M6x12mm, M6x25mm, M6x23mm)
- Allen Wrench
- Anti-tip Device

ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. An Allen wrench is provided for tightening screws. Do not fully tighten screws until all components are in place to allow for adjustments.

1. Step 1: Assemble the Side Frames

Connect the metal frame pieces to form the two side frames of the rack. Use the M6x12mm screws (D) to secure these connections. Ensure the pieces are aligned correctly before tightening.

2. Step 2: Attach Crossbars to Side Frames

Connect the horizontal crossbars between the two assembled side frames. Use the M6x25mm screws (B) for these connections. This will start to form the basic structure of the rack.

3. Step 3: Install Mesh Shelves

Place the mesh shelves onto the designated slots within the frame. Secure them using the M6x12mm screws (D). Ensure the mesh is facing upwards.

4. Step 4: Attach Wooden Top Board

Position the wooden top board onto the uppermost frame. Secure it using the M6x23mm screws (C).

5. Step 5: Install Power Outlet

Mount the power outlet strip to the side of the rack using the provided screws. Ensure it is securely fastened.

6. Step 6: Attach Hooks and Adjustable Feet

Attach the S-shaped and L-shaped hooks to the side bars as desired for hanging utensils or other items. Screw the adjustable feet into the bottom of the rack legs. Adjust them to level the rack on uneven surfaces.

7. Step 7: Secure Anti-Tip Device

For enhanced safety, especially in households with children or pets, attach the anti-tip device to the top of the rack and secure it to a wall stud according to the instructions provided with the device.

For a visual guide, please refer to the assembly video:

Your browser does not support the video tag.

Video: Detailed assembly instructions for the MAHANCRIS Bakers Rack with Power Outlet.

OPERATING INSTRUCTIONS

Power Outlet Usage

The bakers rack is equipped with a 2-outlet power strip (120V/12A) and a convenient on/off switch. Plug your kitchen appliances (e.g., microwave, toaster, coffee machine) into the outlets. Use the red switch to

easily control power to the connected devices, eliminating the need for frequent plugging and unplugging.

Charging Function

2 standard outlets for timely charging of kitchen appliances with a switch for easy on/off.



[120V/12A]
2 AC Outlets



[On/Off]
Switch



[4.9-Foot]
Power Cord

Image: Integrated power outlet with switch for convenient appliance use.

Using the Hooks

The rack includes both S-shaped and L-shaped hooks. These can be attached to the side bars to hang various cooking tools, mugs, or other kitchen accessories, keeping them within easy reach and helping to maintain an organized space.

Multifunctional Hooks

To hang different cooking tools conveniently.

 x2



 x4



Image: Multifunctional hooks for hanging kitchen tools.

Adjustable Feet

The four adjustable feet at the base of the rack allow you to stabilize the unit on uneven flooring. Rotate each foot clockwise or counter-clockwise to raise or lower the corresponding corner until the rack is level and stable.



◀ Multifunctional Hooks

Protective Fences ▶



◀ Adjustable Feet

Image: Adjustable feet for stability on uneven surfaces.

MAINTENANCE

To maintain the appearance and longevity of your baker's rack, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Dusting:** Regularly dust the metal and wooden surfaces to prevent buildup.
- **Tightening:** Periodically check and tighten all screws to ensure the rack remains stable.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wooden top.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Rack is wobbly or unstable.	Uneven floor; loose screws; not secured to wall.	Adjust the leveling feet. Tighten all assembly screws. Install the anti-tip device and secure it to a wall stud.
Power outlets not working.	Power switch is off; power cord not plugged in; circuit breaker tripped.	Ensure the red power switch is in the 'ON' position. Check if the power cord is fully plugged into a working wall outlet. Check your household circuit breaker.
Shelves appear to bow under weight.	Overloaded shelf.	Reduce the weight on the shelf. Ensure weight does not exceed 22 lbs per metal shelf or 44 lbs for the top wooden shelf.

SPECIFICATIONS

Feature	Detail
Model Number	BRHB40E01
Dimensions (D x W x H)	14.2" x 22.4" x 47.2"
Material	Engineered Wood, Metal
Number of Shelves	4
Top Shelf Weight Capacity	44 lbs
Metal Shelf Weight Capacity	22 lbs (each)
Power Outlet	2 AC Outlets (120V/12A) with On/Off Switch
Power Cord Length	4.9 feet
Included Components	Rod, 6 Hooks, Anti-tip device
Assembly Required	Yes

WARRANTY AND SUPPORT

MAHANCRIS products are designed for quality and durability. For any questions, missing parts, or assistance with assembly and operation, please contact MAHANCRIS customer support. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims. You can also visit the official MAHANCRIS store on Amazon for more information and support: [MAHANCRIS Store](#)