Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Orbegozo MHH 1200

Orbegozo MHH 1200 Ice Maker User Manual

Model: MHH 1200 (S9912673)

1. Introduction

Thank you for choosing the Orbegozo MHH 1200 Ice Maker. This appliance is designed to produce ice cubes efficiently for your home use. Please read this manual thoroughly before operating the ice maker to ensure safe and optimal performance. Keep this manual for future reference.

2. Important Safety Instructions

- Read all instructions before using the appliance.
- Do not immerse the power cord, plug, or any part of the appliance in water or other liquids.
- Supervise children when the appliance is in use.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only potable water for ice production.
- Ensure proper ventilation around the appliance. Maintain at least 10 cm of space on all sides.
- Do not place the appliance near heat sources or in direct sunlight.
- This appliance is for household use only.

3. Product Components



Figure 1: Orbegozo MHH 1200 Ice Maker Overview

This image displays the Orbegozo MHH 1200 Ice Maker in black, featuring a clear lid that allows visibility of the ice basket filled with ice cubes. The front panel includes indicator lights for "REFILL", "ICE FULL", "SMALL", and "LARGE" ice sizes, along with a power button. A sturdy handle is integrated into the top for portability. Ventilation grilles are visible on the side.

The Orbegozo MHH 1200 Ice Maker consists of the following main parts:

- **Control Panel:** Located on the front, with indicator lights and operation buttons.

- **Ice Basket:** Removable basket for collecting produced ice.
- **Water Reservoir:** Internal tank for water supply.
- **Ice Scoop:** (Typically included, though not visible in image) For serving ice.
- **Transparent Lid:** Allows monitoring of ice production.
- **Handle:** For easy transport.
- **Air Vents:** Located on the sides for proper heat dissipation.

4. Setup

1. **Unpacking:** Carefully remove the ice maker from its packaging. Remove all packing materials, including any tape or protective film.
2. **Initial Cleaning:** Before first use, clean the interior of the ice maker, including the water reservoir and ice basket, with a soft cloth and mild detergent. Rinse thoroughly with clean water and dry.
3. **Placement:** Place the ice maker on a stable, level surface, away from direct sunlight and heat sources. Ensure there is at least 10 cm of clear space around the appliance for proper ventilation.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

5. Operating Instructions

1. **Fill Water Reservoir:** Open the lid and fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
2. **Power On:** Press the **POWER** button on the control panel to turn on the ice maker.
3. **Select Ice Size:** The control panel features indicators for "SMALL" and "LARGE" ice cubes. Press the corresponding button to select your desired ice size. The default setting is usually "LARGE".
4. **Ice Production:** The ice maker will begin the ice production cycle. The first batch of ice may take slightly longer to produce.
5. **Indicator Lights:**
   - **REFILL:** This light illuminates when the water reservoir is low and needs refilling.
   - **ICE FULL:** This light indicates that the ice basket is full, and ice production will pause until some ice is removed.
6. **Collecting Ice:** Once ice is produced, use the provided ice scoop to remove ice from the basket.
7. **Power Off:** To stop ice production, press the **POWER** button again. Unplug the appliance if not in use for an extended period.

6. Maintenance and Cleaning

- **Daily Cleaning:** After each use, drain any remaining water from the reservoir. Clean the ice basket and the interior with a soft cloth.
- **Regular Cleaning:** Periodically clean the entire unit, including the water reservoir, ice tray, and ice shovel. Use a solution of water and mild detergent. For stubborn mineral deposits, a solution of water and vinegar (1:1 ratio) can be used. Rinse thoroughly.
- **Exterior Cleaning:** Wipe the exterior of the ice maker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the ice maker for an extended period, ensure it is completely dry. Store it in a cool, dry place.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Ice maker not working.	No power; appliance not plugged in.	Check power cord connection and wall outlet.
"REFILL" light is on.	Water reservoir is empty or low.	Add potable water to the reservoir up to the MAX line.
"ICE FULL" light is on.	Ice basket is full.	Remove ice from the basket.
Ice cubes are small or clumpy.	Water temperature too high; air temperature too high.	Use colder water. Ensure proper ventilation and a cooler room temperature.
Unusual noise during operation.	Normal operation sounds (compressor, water pump); loose part.	Some noise is normal. If excessive, ensure the unit is on a stable surface. If noise persists or is unusual, contact customer support.

8. Specifications

Brand: Orbegozo
Model: MHH 1200
Model Number: S9912673
Power: 120 W
Voltage: 240 Volts
Capacity: 1 Liter (Water Reservoir)
Dimensions (L x W x H): 33 x 24.5 x 30.5 cm
Weight: 7.1 kg
Color: Multicolor (as per product description, though appears black in image)

9. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Orbegozo website. Keep your proof of purchase for any warranty claims.
Visit the Orbegozo Store on Amazon

© 2024 Orbegozo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9K8Y8WB

More documents and user manuals: **https://manuals.plus/**