

[Manuals.plus](#) /

> [Seang](#) /

> Seang 48x24 Inch Electric Standing Desk User Manual

Seang JZQC

Seang 48x24 Inch Electric Standing Desk User Manual

Model: JZQC (SA-SD-JZQC)

INTRODUCTION

Thank you for choosing the Seang Electric Standing Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new adjustable height desk. Please read these instructions thoroughly before assembly and use to ensure proper function and longevity of the product.



Image: The Seang Electric Standing Desk in a modern home office environment, showcasing its design and functionality with a

SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- **Weight Limit:** Do not exceed the maximum weight recommendation of 154 pounds (70 kg). Exceeding this limit may cause instability and potential damage to the desk or personal injury.
- **Assembly:** Follow all assembly instructions carefully. Incorrect assembly can lead to instability and operational issues.
- **Clearance:** Ensure there are no obstructions above or below the desk during height adjustment to prevent collisions.
- **Children and Pets:** Keep children and pets away from the desk during operation to prevent accidents.
- **Power:** Ensure the power cord is properly connected and not damaged. Do not operate the desk with a damaged cord or plug.
- **Liquid Spills:** Avoid spilling liquids on the control panel or motor components.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. Refer to the detailed installation manual included in the package for a complete list of parts.

- Desktop (48x24 inch, Nature Top)
- Electric Lift System (Legs and Motor)
- Control Panel
- Power Adapter and Cable
- Headphone Hook (Included Component)
- Assembly Hardware (Screws, L-shaped mounting tools)
- Installation Manual

SETUP AND ASSEMBLY

The Seang Electric Standing Desk requires assembly. A detailed installation manual with precise pre-drilled holes and L-shaped mounting tools are included to facilitate a quick and easy assembly process. It is recommended that **1 person** perform the assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Legs to Desktop:** Follow the instructions in the provided manual to securely attach the electric lift legs to the underside of the desktop using the provided hardware. The pre-drilled holes will guide placement.
3. **Install Control Panel:** Mount the control panel to the designated area on the underside of the desktop.
4. **Connect Cables:** Connect the motor cables and control panel cable to the control box, then connect the power adapter. Ensure all connections are secure.
5. **Attach Accessories:** Install the headphone hook and any other included accessories as per the manual.
6. **Final Check:** Before plugging in, double-check all connections and ensure all screws are tightened.



Easy Installation

Clear installation instructions and video installation guide.

Image: A close-up of a person assembling the desk, showing the use of a screwdriver and the detailed instruction manual.

OPERATING INSTRUCTIONS

Your Seang Electric Standing Desk features an advanced electric lift system for smooth height adjustments and a multi-function intelligent keypad.

Height Adjustment

- The height adjustment range is from **28.3 inches to 46.5 inches**.
- Use the **Up (▲)** and **Down (▼)** buttons on the control panel to manually adjust the desk to your desired height.
- The powerful motor ensures a smooth and low-noise lifting process.

Adjustable Heights for Every Need

Height Adjustment Range



Image: Visual representation of the desk's adjustable height range, showing the desk at its minimum (28.3") and maximum (46.5") heights.

Memory Presets

The control panel allows you to save preferred heights for quick adjustments.

- **Set a Preset:** Adjust the desk to your desired height using the Up/Down buttons. Press and hold one of the memory buttons (1 or 2) until the LED display flashes or beeps, indicating the height is saved.
- **Recall a Preset:** Press the corresponding memory button (1 or 2) to automatically move the desk to the saved height.

Multi-Function Intelligent Keypad

Control whatever you want



LED Display



Up/Down Move



2 Memory Buttons

Image: Detailed view of the control panel, highlighting the LED display, up/down movement buttons, and two memory preset buttons.

Quiet Operation

The desk is designed for quiet operation, with a noise level of approximately 45dB during adjustment.

Ultra Quiet Design

Enjoy this moment of peace



10dB
Falling Leaves

45dB
Our Product

60dB
Normal Voice

Image: A hand interacting with the control panel, emphasizing the desk's quiet operation feature with a visual comparison of sound levels.

MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your standing desk.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cable Management:** Periodically check that all cables are securely connected and not pinched or tangled. Use the provided cord holes to maintain a tidy workspace.
- **Fastener Check:** Occasionally check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Motor Care:** The electric motor is designed for maintenance-free operation. Do not attempt to open or service the motor housing.

TROUBLESHOOTING

If you encounter issues with your Seang Electric Standing Desk, refer to the following common troubleshooting steps:

- **Desk Not Moving:**
 - Ensure the power cable is securely plugged into both the desk and a working power outlet.
 - Check all motor and control panel connections to the control box.
 - If the desk has an anti-collision feature, ensure no objects are obstructing its path.
- **Uneven Movement or Wobble:**
 - Verify that the desk is assembled correctly and all fasteners are tightened.
 - Ensure the desk is placed on a level surface.
 - Do not exceed the maximum weight capacity of 154 lbs.
- **Control Panel Not Responding:**
 - Unplug the desk from the power outlet for 10-15 seconds, then plug it back in to reset the system.
 - Check the connection of the control panel cable to the control box.

If these steps do not resolve the issue, please contact Seang customer support for further assistance.

SPECIFICATIONS

Key specifications for the Seang Electric Standing Desk (Model JZQC):

Brand	Seang
Model Name	JZQC
Model Number	SA-SD-JZQC

Desk Design	Standing Desk
Desktop Dimensions	48 x 24 inches
Height Adjustment Range	28.3 inches to 46.5 inches
Maximum Weight Capacity	154 lbs (70 kg)
Lifting Mechanism	Electric
Top Material Type	Wood (Nature Top)
Base Material	Metal (Alloy Steel Frame)
Included Components	Headphone Hook, Assembly Tools
Recommended Assembly Persons	1



Image: A visual diagram detailing the desk's dimensions and maximum load capacity.

154LBS Load Capacity

Supports and smoothly lifts more



Image: A person sitting on the desk, illustrating its 154 lbs load capacity.

WARRANTY INFORMATION

The Seang Electric Standing Desk comes with a **Limited Warranty**. Please refer to the warranty card included in your package or contact customer support for specific details regarding coverage and terms.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Seang Electric Standing Desk, please do not hesitate to contact our customer support team. We offer 24/7 support to provide quick solutions to any issues you may encounter.

Contact Information: Please refer to the contact details provided in your product packaging or visit the official Seang website for the most up-to-date support information.