

[manuals.plus](#) /

› [Glitzhome](#) /

› [Glitzhome 4FT Lighted Pop-Up Christmas Snowman Instruction Manual](#)

**Glitzhome lighted outdoor decor**

# Glitzhome 4FT Lighted Pop-Up Christmas Snowman Instruction Manual

Brand: Glitzhome | Model: lighted outdoor decor

## 1. PRODUCT OVERVIEW

The Glitzhome 4FT Lighted Pop-Up Christmas Snowman is a festive outdoor decoration designed to enhance your holiday display. Crafted from high-quality materials, this snowman features a sturdy metal frame, a foldable design for easy storage, and 160 warm white LEDs that are weather-resistant.



Image: The Glitzhome 4FT Lighted Pop-Up Christmas Snowman, fully assembled and illuminated.

Its generous dimensions of 33.50 inches (L) x 19 inches (W) x 47.25 inches (H) ensure it stands out in any setting, whether indoors or outdoors.

## 2. PACKAGE CONTENTS

Please ensure all components are present before beginning assembly:

- Foldable Snowman Body (with integrated LED lights)
- Metal Frame Components (base, vertical poles)
- Ground Stakes
- Zip Ties
- Hat
- Scarf

- Decorative Light String (if separate)

### 3. ASSEMBLY INSTRUCTIONS

---

Follow these steps to assemble your Glitzhome 4FT Lighted Pop-Up Christmas Snowman:

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Assemble Base Frame:** Connect the metal frame components to form the circular base.
3. **Insert Vertical Poles:** Insert the vertical support poles into the designated slots on the base.
4. **Expand Snowman Body:** Gently expand the foldable snowman body and carefully place it over the assembled metal frame. Ensure the internal structure aligns with the frame.
5. **Secure Body to Frame:** Use the provided zip ties to secure the snowman's fabric body to the metal frame at various points to ensure stability.
6. **Connect Internal Wiring:** Locate and connect any internal wiring for the LED lights within the snowman's structure.
7. **Attach Accessories:** Place the hat on the snowman's head and drape the scarf around its neck. Arrange the decorative light string (if separate) as desired.
8. **Ground Stakes (Outdoor Use):** For outdoor placement, use the ground stakes to firmly anchor the snowman's base to the ground, preventing movement in windy conditions.

# BRILLIANT LED LIGHTS



Colorful Bulbs and 160  
warm white LED Lights



Long lasting LEDs  
work well in rainy or frosty.



Zip Ties



Image: Visual guide illustrating the easy assembly process of the snowman, showing components and step-by-step setup.

Your browser does not support the video tag.

Video: An official Glitzhome video demonstrating the assembly of the 3D Lighted Christmas Snowman.

## 4. OPERATING INSTRUCTIONS

To operate your lighted snowman, simply plug the power cord into a standard electrical outlet. The 160 warm white LEDs will illuminate, creating a festive glow. The lights are designed to be long-lasting and the unit is weather-resistant, suitable for both indoor and outdoor use.



Image: The snowman illuminated in a snowy outdoor environment, showcasing its festive appearance.



Image: The snowman illuminated in an indoor setting, demonstrating its versatility.

## 5. CARE AND MAINTENANCE

- **Cleaning:** To clean the snowman, gently wipe the surface with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Thanks to its foldable design, the snowman can be easily disassembled and stored compactly. Ensure the unit is completely dry before storing. Store in a cool, dry place away from direct sunlight and extreme temperatures to prolong its lifespan.
- **Inspection:** Periodically inspect the power cord, lights, and frame for any signs of damage. Discontinue use if any damage is found.

## 6. TROUBLESHOOTING

If you encounter any issues with your snowman, please refer to the following common troubleshooting tips:

- **Lights Not Illuminating:**
  - Check if the power cord is securely plugged into a working electrical outlet.

- Inspect the power cord for any cuts or damage.
- Ensure all internal light connections are secure.

- **Instability:**

- Verify that the metal frame is correctly assembled and all connections are tight.
- For outdoor use, ensure ground stakes are fully inserted into the soil.
- Check that the snowman body is securely attached to the frame with zip ties.

If these steps do not resolve the issue, please contact Glitzhome customer support.

## 7. SPECIFICATIONS

Feature	Detail
Frame Material	Metal
Light Color	Warm White
Number of Light Sources	160
Recommended Uses	Decoration
Number of Items	1
Product Dimensions (L x W x H)	33.5 x 19 x 47.25 inches
Item Weight	5.99 pounds (2.72 Kilograms)
Material	Glass Fiber Cloth, Plastic, Metal



Image: Detailed dimensions of the 4FT Lighted Pop-Up Christmas Snowman.


## 8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Glitzhome customer service directly. Keep your purchase receipt for any warranty claims.

You can visit the official Glitzhome store for more information:[Glitzhome Store](#)

© 2025 Glitzhome. All rights reserved.

**Related Documents - lighted outdoor decor**

	<p><a href="#"><b>Glitzhome 6ft Pre-Lit Snow Flocked Fir Christmas Tree Assembly Instructions</b></a></p> <p>Assembly instructions for the Glitzhome 6ft Pre-Lit Snow Flocked Fir Christmas Tree with 300 Warm White Lights. Includes disassembly, storage, and step-by-step assembly guidance.</p>
	<p><a href="#"><b>Glitzhome 9ft Pre-Lit Flocked Spruce Artificial Christmas Tree Assembly Instructions</b></a></p> <p>Assembly and disassembly guide for the Glitzhome 9ft Pre-Lit Flocked Layered Spruce Artificial Christmas Tree with 500 Warm White Lights (Model 2014600099). Includes product specifications, parts list, step-by-step assembly, and safety precautions.</p>
	<p><a href="#"><b>9ft Deluxe Pre-Lit Flocked Pine Artificial Christmas Tree Assembly Instructions</b></a></p> <p>Assembly and disassembly instructions for the Glitzhome 9ft Deluxe Pre-Lit Flocked Pine Artificial Christmas Tree with 650 Warm White Lights, including parts list, safety precautions, and storage tips.</p>
	<p><a href="#"><b>Glitzhome 9ft Pre-Lit Pencil Green Pine Artificial Christmas Tree with 480 Warm White Lights - Assembly Instructions</b></a></p> <p>Assembly and setup guide for the Glitzhome 9ft Pre-Lit Pencil Green Pine Artificial Christmas Tree (Model 2014600092). Features 480 warm white lights and easy setup.</p>
	<p><a href="#"><b>Glitzhome 41.75" H Lighted Wooden "Santa Stop Here" Yard Stake Assembly Instructions</b></a></p> <p>Step-by-step assembly instructions for the Glitzhome 41.75 inch lighted wooden 'Santa Stop Here' yard stake. Includes hardware list and assembly guide.</p>
	<p><a href="#"><b>Glitzhome 7.5ft Pre-Lit Flocked Pencil Spruce Artificial Christmas Tree Assembly Instructions (Model 2014600093)</b></a></p> <p>Step-by-step assembly instructions for the Glitzhome 7.5ft Pre-Lit Flocked Pencil Spruce Artificial Christmas Tree with 350 Warm White Lights, model 2014600093. Includes disassembly, storage, and caution information.</p>