TomTom 1YF6.002.00

TomTom Navigator GO Classic 2nd Edition User Manual

Model: 1YF6.002.00

1. Introduction

The TomTom Navigator GO Classic 2nd Edition is a reliable navigation device designed to provide accurate routing and real-time traffic information. This manual provides essential information for setting up, operating, and maintaining your device.

Key features include high-quality TomTom maps, real-time TomTom Traffic updates, monthly map updates for Europe, multiple route options, and a responsive 6-inch capacitive touch screen.

2. Product Components

Before you begin, ensure all components are present in the box:

- TomTom Navigator GO Classic 2nd Edition Device
- Integrated Reversible Mount
- Car Charger
- USB-C Cable
- Installation Poster



Figure 2.1: Device Overview. This image displays the TomTom Navigator GO Classic 2nd Edition from a side angle, highlighting key components such as the power button, USB-C port, integrated reversible mount, and speaker. The screen size is either 5 or 6 inches.



Figure 2.2: Screen Size Comparison. This image illustrates the difference between the 5-inch and 6-inch screen options for the TomTom Navigator GO Classic, emphasizing the clear and bright capacitive touch screen display.

3. Setup

3.1 Charging the Device

Connect the supplied USB-C cable to the device's USB-C port and the other end to the car charger. Plug the car charger into your vehicle's 12V power outlet. The device will begin charging automatically.

3.2 Mounting the Device

The TomTom Navigator GO Classic features an integrated reversible mount. Attach the mount securely to your vehicle's windshield or dashboard using the suction cup. Ensure the device is positioned where it does not obstruct your view of the road.

3.3 Initial Setup and Wi-Fi Connection

Upon first power-on, the device will guide you through the initial setup process. This includes selecting your language,

time zone, and connecting to a Wi-Fi network. A Wi-Fi connection is essential for receiving map and software updates.

1. Power on the device by pressing the power button.
2. Follow the on-screen prompts to select your preferred language and region.
3. When prompted, select your Wi-Fi network and enter the password.
4. Allow the device to check for and install any available software updates.

4. Operating Instructions

4.1 Planning a Route

To plan a route, tap the screen and select "Search" or "Drive to". You can enter an address, point of interest, or coordinates. The device will calculate the fastest route based on current traffic conditions.



Figure 4.1: Active Navigation Screen. This image shows the TomTom Navigator GO Classic displaying an active navigation route, including distance to next turn, road names, speed limit, current speed, and estimated arrival time with traffic information.

4.2 TomTom Traffic

The device provides real-time traffic updates to help you avoid congestion and arrive on time. If a faster route becomes available due to traffic, the device will offer an alternative.



Figure 4.2: TomTom Traffic Alternative Route. This image demonstrates how the TomTom device suggests an alternative route to save time by avoiding traffic congestion, displaying the time saved.



Figure 4.3: TomTom Traffic Main Route. This image shows the TomTom device actively navigating a route with real-time traffic information integrated into the map display, indicating potential delays.

4.3 Speed Camera Alerts

The device provides real-time notifications for speed cameras to help you adhere to speed limits. This feature is available for a trial period and can be continued with a subscription.

4.4 Lane Guidance

The advanced lane guidance feature clearly indicates the correct lane to take for upcoming turns and exits, ensuring you are in the right position well in advance.

5. Maintenance

5.1 Map and Software Updates via Wi-Fi

Your TomTom Navigator GO Classic receives monthly map updates for Europe and software updates directly via Wi-Fi. No computer connection is required.

1. Ensure your device is connected to a stable Wi-Fi network.
2. Navigate to the "Settings" menu on your device.
3. Select "Updates & New Items" or a similar option.
4. The device will check for available updates. Follow the on-screen instructions to download and install them. Keep the device connected to power during updates.



Figure 5.1: Map Update Screen. This image shows the TomTom device's screen displaying available map updates for various European regions, indicating the size of each update and options to add or delete maps.

5.2 General Care

- Clean the screen with a soft, lint-free cloth. Avoid abrasive cleaners.
- Do not expose the device to extreme temperatures or direct sunlight for prolonged periods.
- Protect the device from drops and impacts.

6. Troubleshooting

6.1 Device Not Powering On

- Ensure the device is fully charged. Connect it to the car charger or a USB power source for at least 30 minutes.
- Perform a soft reset by pressing and holding the power button for 15-20 seconds until the device restarts.

6.2 GPS Signal Loss

- Ensure the device has a clear view of the sky. Obstructions like tall buildings or tunnels can interfere with GPS signals.
- Move the device to a different location in your vehicle, away from other electronic devices that might cause interference.
- Check for any available software updates, as these can sometimes improve GPS performance.

6.3 Map Updates Failing

- Verify your Wi-Fi connection is stable and strong.
- Ensure there is sufficient free space on the device (32 GB internal memory). You may need to delete older maps if necessary.
- Restart the device and attempt the update again.

7. Specifications

Model Number	1YF6.002.00
Screen Size	6 Inches
Display Type	Capacitive Touchscreen
Internal Memory	32 GB
Map Type	Europe (monthly updates)
Connectivity	Wi-Fi, USB-C
Battery Type	1 Lithium Polymer (included)
Item Weight	15.9 ounces (450 Grams)
Included Components	Device, Mount, Car Charger, USB-C Cable, Installation Poster

8. Warranty and Support

For warranty information and technical support, please refer to the documentation included with your product or visit the official TomTom support website. Keep your proof of purchase for warranty claims.

For further assistance, you may visit the TomTom Store on Amazon.

© 2024 TomTom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question