



Manuals.plus /

› Vonia /

› Vonia Spot Cleaner for Carpets and Upholstery - 450W Instruction Manual

Vonia V177TG

Vonia Spot Cleaner Instruction Manual

Model: V177TG

Brand: Vonia

1. INTRODUCTION

Thank you for choosing the Vonia Spot Cleaner. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and retain them for future reference.

2. SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance.

- Read all instructions before using the appliance.
- Do not immerse the appliance in water or other liquids.
- Do not use with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer or a qualified service agent.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Unplug from outlet when not in use and before cleaning or servicing.
- Exercise extreme care when cleaning on stairs.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PACKAGE CONTENTS

Verify that all items are present and in good condition upon unpacking.

- Vonia Spot Cleaner Main Unit
- Cleaning Nozzle (Small)
- Cleaning Nozzle (Large)
- Instruction Manual



Image: The Vonia Spot Cleaner packaging box, illustrating the main unit and included accessories.

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your Vonia Spot Cleaner.

- **Clean Water Tank:** Holds fresh water and cleaning solution. Capacity: 1080 ml.
- **Dirty Water Tank:** Collects extracted dirty water. Capacity: 850 ml.
- **Hose:** Flexible hose for directing cleaning nozzles. Length: 1.2 meters.
- **Cleaning Nozzles:** Two attachments for different cleaning tasks.
- **Power Cord:** For electrical connection. Length: 5 meters.
- **Power Button:** Activates the cleaner.



Image: The Vonia Spot Cleaner main unit, showcasing its design and the two included cleaning attachments.



Image: A visual representation of the Vonja Spot Cleaner's key features, including its suction power, tank capacities, and cord length.

5. SETUP

Follow these steps to prepare your Vonja Spot Cleaner for use.

1. **Unpack:** Carefully remove all components from the packaging.
2. **Attach Nozzle:** Select the appropriate cleaning nozzle for your task and securely attach it to the end of the hose.
3. **Fill Clean Water Tank:** Remove the clean water tank. Fill it with warm water (max 40°C) and a suitable carpet/upholstery cleaning solution according to the solution's instructions. Do not overfill. Securely reattach the tank.
4. **Position:** Place the spot cleaner on a stable, flat surface near the area to be cleaned.
5. **Plug In:** Insert the power cord into a grounded electrical outlet.

6. OPERATING INSTRUCTIONS

The Vonio Spot Cleaner is designed for effective cleaning of carpets, rugs, upholstery, and car interiors.



Image: Examples of surfaces suitable for cleaning with the Vonio Spot Cleaner, including car upholstery, carpeted stairs, rugs, and couches.

1. **Pre-treat (Optional):** For stubborn stains, pre-treat the area with a suitable stain remover before using the spot cleaner. Allow it to sit for a few minutes as per the pre-treatment product's instructions.
2. **Power On:** Press the power button to turn on the appliance.
3. **Spray and Scrub:** Hold the cleaning nozzle over the stained area. Press the trigger on the nozzle to spray the cleaning solution onto the fabric. Gently scrub the stain with the brush on the nozzle.
4. **Extract:** Release the spray trigger and slowly pull the nozzle over the wet area, applying downward pressure. This will suction up the dirty water. Repeat this step until the water being extracted appears clean.
5. **Dry:** Continue to suction the area without spraying to remove as much moisture as possible. This helps to speed up drying time.
6. **Repeat:** For heavily soiled areas, you may need to repeat the spray, scrub, and extract process.
7. **Power Off:** Once cleaning is complete, turn off the appliance and unplug it from the power outlet.



INCLUDING 2 HANDY ATTACHMENTS



Image: The cleaning nozzle in action, demonstrating its ability to spray solution and extract stains from carpet.




Image: The spot cleaner's effectiveness against different types of stains and unpleasant odors.




Image: A visual comparison demonstrating the cleaning results achieved with the Vonio Spot Cleaner.

7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your spot cleaner.

1. **Empty and Rinse Dirty Water Tank:** After each use, remove the dirty water tank, empty its contents, and rinse it thoroughly with clean water. Allow it to air dry before reattaching.
2. **Rinse Clean Water Tank:** If any cleaning solution remains, empty and rinse the clean water tank.
3. **Clean Nozzles and Hose:** Detach the cleaning nozzle and rinse it under running water to remove any debris. Flush the hose with clean water by running the cleaner with only clean water in the tank for a few seconds.
4. **Wipe Down:** Wipe the exterior of the appliance with a soft, damp cloth.
5. **Storage:** Store the spot cleaner in a dry, cool place, away from direct sunlight and out of reach of children. Ensure all tanks are empty and dry before storage.

8. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

| Problem | Possible Cause | Solution |
|---------------------------|--|---|
| No suction | Dirty water tank full; hose or nozzle clogged; tank not properly seated. | Empty dirty water tank; clear any clogs; ensure tanks are securely in place. |
| No spray | Clean water tank empty; spray nozzle clogged; tank not properly seated. | Refill clean water tank; clean spray nozzle; ensure tanks are securely in place. |
| Poor cleaning performance | Incorrect cleaning solution; heavily soiled area; slow extraction speed. | Use recommended cleaning solution; pre-treat stubborn stains; move nozzle slower for better extraction. |
| Water leaking | Tanks not properly sealed; damaged tank or seal. | Ensure tanks are correctly installed and sealed; inspect tanks and seals for damage. |

9. SPECIFICATIONS

| Feature | Specification |
|--------------------------------|----------------------|
| Brand | Vonia |
| Model Number | V177TG |
| Power | 450W |
| Suction Power | 11 KPa (110000 Pa) |
| Clean Water Tank Capacity | 1080 ml |
| Dirty Water Tank Capacity | 850 ml |
| Power Cord Length | 5 meters |
| Hose Length | 1.2 meters |
| Product Dimensions (L x W x H) | 30 x 16 x 26 cm |
| Item Weight | 2 Kilograms |
| Country of Origin | China |



450W VERMOGEN



LIGHTWEIGHT AND COMPACT



1,2M HOSE



SAVES SPACE



Image: Key features of the Vonja Spot Cleaner, including its power, compact size, and hose length.

10. WARRANTY AND SUPPORT

The Vonja Spot Cleaner is designed for durability and performance. Spare parts availability is supported for 1 year from the date of purchase. For any questions, technical assistance, or warranty claims, please refer to your purchase documentation or contact the retailer where the product was purchased.