Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

etoe D1221

ETOE Starfish Mini Projector User Manual

Model: D1221

1. Introduction

Thank you for choosing the ETOE Starfish Mini Projector. This device integrates a high-definition projector with Google TV, offering a comprehensive entertainment experience. It features a unique starry night mode, a touch-sensitive night light, and smart functionalities like autofocus and voice control. This manual provides essential information for setting up, operating, and maintaining your projector to ensure optimal performance and longevity.

2. What's in the Box

- ETOE Starfish Mini Projector
- Remote Control
- Power Adapter
- User Manual (this document)


Easy To Enjoy

Image: The ETOE Starfish Mini Projector, remote control, and power adapter laid out.

3. Product Overview

The ETOE Starfish projector is designed for versatility and ease of use. Key features include:

- **Integrated Google TV:** Access Netflix, Prime Video, YouTube, and thousands of other apps directly.
- **Starry Night Mode:** Create ambient lighting with multiple modes.
- **Touch Night Light:** A built-in, multi-color night light with adjustable brightness.
- **High-Definition Projection:** Native 1080P resolution with 4K decoding support.
- **Smart Adjustments:** Automatic focus and keystone correction for a clear, aligned image.
- **Flexible Placement:** 140° rotation allows projection on walls or ceilings.
- **Voice Control:** Google Assistant integration for hands-free operation.
- **Sealed Optical Engine:** 99.99% dustproof design for long-lasting image quality.
- **Connectivity:** Wi-Fi 5G, Bluetooth 5.0, HDMI, USB, AirPlay, Chromecast.



Image: A detailed side view of the ETOE Starfish Mini Projector, highlighting its compact design.

4. Setup

4.1 Power Connection

1. Connect the power adapter to the projector's power input port.
2. Plug the power adapter into a wall outlet.
3. The projector will typically power on automatically or enter standby mode.

4.2 Initial Boot-Up and Google TV Setup

1. Upon first power-on, the projector will guide you through the Google TV setup process.
2. Follow the on-screen instructions to select your language, connect to a Wi-Fi network, and log in with your Google

account.

3. This process will activate pre-installed apps like Netflix, Prime Video, and YouTube.

4.3 Image Adjustment (Autofocus & Keystone)

The projector features automatic focus and keystone correction for a clear and rectangular image.

- **Autofocus:** The projector will automatically adjust focus when powered on or moved.
- **Auto Keystone:** The image will automatically correct its shape to be rectangular, even if the projector is at an angle.
- **Manual Adjustment:** If needed, you can fine-tune focus and keystone settings in the projector's menu.



Image: A projector screen showing automatic focus and keystone correction in action, ensuring a perfectly aligned image.

4.4 Placement and Rotation

The projector's design allows for flexible placement and projection angles.

- Place the projector on a stable surface.
- The projector head can rotate up to 140°, allowing you to project onto walls, ceilings, or any desired surface.
- Adjust the projector's position and angle to achieve the desired screen size and location.

5. Operating Instructions

5.1 Basic Projection

- **Power On/Off:** Use the power button on the remote control or the projector itself.
- **Navigation:** Use the directional pad and OK button on the remote to navigate the Google TV interface.
- **Volume Control:** Use the volume buttons on the remote.

5.2 Google TV and Streaming

Your projector comes with official Google TV, providing access to a vast library of content.

- **Pre-installed Apps:** Netflix, Prime Video, and YouTube are ready to use after initial setup.
- **App Store:** Access the Google Play Store to download additional apps and games.
- **Personalized Profiles:** Create individual profiles for each family member for personalized recommendations.
- **Kids Mode:** Utilize parental controls and curated content for children.



Image: The Google TV home screen displaying various streaming service logos like Netflix, Prime Video, and YouTube.

5.3 Voice Control with Google Assistant

Use your voice to control the projector and search for content.

- Press the Google Assistant button on your remote control.
- Speak your command into the remote's microphone (e.g.,

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9M5P1VZ

More documents and user manuals: **https://manuals.plus/**