

[Manuals.plus](#) /

› [SHLUCE](#) /

› User Manual for Farmhouse Flush Mount Caged Ceiling Fan

SHLUCE FLA003A

Farmhouse Flush Mount Caged Ceiling Fan User Manual

Model: FLA003A | Brand: SHLUCE

1. SETUP

1.1 Unboxing and Components

Your SHLUCE Farmhouse Flush Mount Caged Ceiling Fan comes with all necessary components for installation and operation. Carefully unpack all items and ensure nothing is missing. The package includes the main fan unit, a remote control, and all required mounting hardware.



Image: The complete ceiling fan unit with the remote control, showcasing its rustic design.

1.2 Product Specifications

Specification	Detail
Dimensions	19"L x 19"W x 7.1"H
Voltage	110 Volts
Wattage	40 watts
Bulb Base	4 x E26 (bulbs not included)
Material	Metal
Control Method	Remote Control
Indoor/Outdoor Usage	Indoor

Item Weight	11.43 pounds
-------------	--------------

Product Specifications

6 Speed + Natural Wind

4xE26 Base(More Brighter)

Reversible Motor

Timing 2/4H

Easy to Install(Already Assembled)

Mute: No beeping

Image: Detailed product dimensions for installation planning.

1.3 Installation

The fan is designed for easy installation, with most functional components pre-assembled. All necessary mounting hardware is included. For safety, it is recommended to consult a qualified electrician for installation if you are not familiar with electrical wiring. Always turn off power at the circuit breaker before beginning installation.

Reversible Motor

Image: View of the internal wiring connections, designed for straightforward setup.

2. OPERATING

2.1 Remote Control Functions

The fan is operated via a convenient remote control. It features 6 speed settings, a silent mode (no beeping), and 2/4-hour timing options. The lighting and fan functions can be controlled independently. The fan also has a reversible motor for year-round use.



Image: The remote control displaying buttons for fan speed, light control, and timer settings.

2.2 Fan Speed and Airflow

Choose from 6 fan speeds to customize your comfort. Lower speeds provide a gentle breeze, while higher speeds offer powerful airflow. The upgraded DC motor ensures strong wind with low noise levels, typically below 30 decibels.



Image: Visual representation of the fan's 6 speed settings, from gentle to strong wind.

2.3 Reversible Motor Function

The fan features a reversible motor, allowing it to circulate air effectively in both summer and winter. In summer, the downdraft mode creates a cooling effect. In winter, the updraft mode helps circulate warm air throughout the room.



Image: Illustration of the fan's reversible motor, showing downdraft for summer cooling and updraft for winter heat circulation.

3. MAINTENANCE

3.1 Cleaning

To maintain the appearance and performance of your ceiling fan, regularly dust the metal cage and fan blades with a soft, dry cloth. For more thorough cleaning, wipe surfaces with a damp cloth and mild detergent, then dry immediately. Avoid using abrasive cleaners or solvents.

3.2 Bulb Replacement

The fan uses 4 E26 base bulbs (not included). To replace bulbs, ensure the power to the fan is turned off at the circuit breaker. Allow bulbs to cool before handling. Carefully unscrew old bulbs and screw in new ones. Do not overtighten.

3.3 Safety Precautions

Always disconnect power to the fan before performing any maintenance or cleaning. Do not attempt to repair or modify the fan yourself. Refer to qualified personnel for any repairs beyond basic cleaning and bulb replacement.

4. TROUBLESHOOTING

4.1 Fan Not Operating / Lights Not Turning On

- Check the circuit breaker to ensure power is supplied to the fan.
- Verify that the remote control batteries are not depleted and are inserted correctly.
- Ensure all wiring connections are secure and properly installed.
- For lights, check if the bulbs are securely screwed in and not burnt out.

4.2 Fan Wobbling

- Ensure the mounting bracket is securely fastened to the ceiling joist.
- Check that all screws on the fan assembly are tightened.
- Verify that the fan blades are properly balanced.

4.3 Remote Control Not Responding

- Replace the remote control batteries.
- Ensure there are no obstructions between the remote and the fan's receiver.
- If issues persist, refer to the detailed instruction manual for remote pairing or contact customer support.

5. SPECIFICATIONS

Attribute	Value
Brand	SHLUCE
Model Number	FLA003A
Color	Black Gold
Material	Metal
Style	Ceiling Mount, Farmhouse
Room Type	Kitchen, Living Room, Bedroom, Home Office, Dining Room
Product Dimensions	19"L x 19"W x 7.1"H
Indoor/Outdoor Usage	Indoor
Power Source	DC
Installation Type	Flush Mount
Control Method	Remote
Light Source Type	LED (Bulbs not included)
Number of Light Sources	4
Voltage	110 Volts
Wattage	40 watts
Bulb Base	E26
Item Weight	11.43 pounds

6. WARRANTY AND SUPPORT

SHLUCE offers a **2-year warranty** and a **30-day refund policy** for this product. We also provide free spares support. If you experience any issues such as lost, defective, or missing parts (e.g., remote control), please contact us through your Amazon orders for assistance.

For further support or inquiries, please refer to the contact information provided in your original purchase documentation or visit the official SHLUCE store on Amazon.

© 2025 SHLUCE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question