HOGOKIDS HG1017

HOGOKIDS City Camper Van Building Set with LED Light - Instruction Manual

Model: HG1017

Introduction

This manual provides detailed instructions for the assembly, operation, and care of your HOGOKIDS City Camper Van Building Set. This 3-in-1 building toy allows for the construction of a travel trailer, a motorhome, or a van conversion, complete with an integrated LED lighting system.
Please read these instructions carefully before beginning assembly to ensure a smooth and enjoyable building experience.

Package Contents

Before starting, verify that all components are present. The HOGOKIDS City Camper Van Building Set (Model HG1017) includes:

- 879 building pieces
- Instruction manual
- Sticker sheet
- LED light module (batteries not included)



Image: Overview of the HOGOKIDS City Camper Van Building Set packaging, dimensions, and included components: the building set box, a sticker sheet, the instruction manual, and the LED light module.

Safety Information

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

- Keep small parts away from young children.
- Ensure all pieces are securely connected during assembly and play.
- Do not expose the LED light module to water or extreme temperatures.
- Adult supervision is recommended during assembly and play.

Setup and Assembly

The HOGOKIDS City Camper Van Building Set offers three distinct configurations. Choose your desired model before starting assembly. Follow the step-by-step instructions provided in the included printed manual for detailed guidance.

General Assembly Tips:

1. **Organize Pieces:** Sort the building blocks by color and type to facilitate easier assembly.
2. **Follow Instructions:** Refer to the numbered steps in the physical instruction booklet. Each step illustrates the pieces required and their placement.
3. **Secure Connections:** Ensure each block is firmly pressed into place to create a stable structure.
4. **LED Light Installation:** The LED light module is typically integrated during specific steps of the main vehicle assembly. Insert batteries (not included) into the LED module as indicated in the manual before final placement.



Image: The complete HOGOKIDS City Camper Van Building Set, showcasing the primary camper van, a separate pickup truck, and various camping accessories like a tent, BBQ grill, and outdoor seating. This image highlights the multiple configurations possible with the set.



Image: A visual representation of the three distinct building options for the HOGOKIDS City Camper Van: a camper van with a detachable trailer, a compact motorhome, and a streamlined van conversion. Each model is shown with its accompanying accessories and LED light feature.

Operating Instructions

Once assembled, your HOGOKIDS City Camper Van offers interactive features for imaginative play.

Key Features:

- **LED Light:** Activate the LED light module by pressing the designated button (location specified in the printed manual) to illuminate the interior of the camper van.
- **Movable Parts:** The camper van features an openable door, opening windows, and a removable roof for access to the detailed interior.
- **Retractable Awning:** Rotate the mechanism to extend or retract the awning, providing shade for outdoor scenes.
- **3-in-1 Design:** Easily disassemble and reassemble the main vehicle to switch between the travel trailer,

motorhome, or van conversion configurations.

- **Accessories:** Utilize the included accessories such as the dining table, BBQ grill, bicycle, and drone to enhance play scenarios.



Image: A comparison showing the HOGOKIDS City Camper Van in daylight with the LED light off, and at night with the LED light on, demonstrating the illuminated interior and cozy atmosphere created by the lighting feature. Various camping accessories are also visible.




Image: Detailed views of the HOGOKIDS City Camper Van's interactive elements, including a door that swings open, windows that can be opened, and a section of the roof that can be removed to access the interior. These images illustrate the functional design of the building set.



Image: This image highlights the modularity and interactive features of the HOGOKIDS City Camper Van, showing an awning that can be opened, a section of the camper that can be quickly disassembled for reconfiguration, and the option to connect the camper to a pickup truck.

Maintenance

Proper care will ensure the longevity of your HOGOKIDS building set.

- **Cleaning:** Wipe pieces with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly. Do not immerse the LED light module in water.
- **Storage:** Store the building set in a cool, dry place away from direct sunlight to prevent discoloration or warping of plastic pieces.
- **Battery Replacement:** When the LED light dims, replace the batteries in the LED module. Refer to the printed manual for battery type and replacement instructions.

Troubleshooting

Common Issues and Solutions:

- **Missing Pieces:** Carefully check the packaging and surrounding area. If pieces are genuinely missing, contact HOGOKIDS customer support.
- **Pieces Not Fitting:** Ensure you are using the correct pieces for the step. Apply firm, even pressure. If a piece still doesn't fit, check for any manufacturing defects.
- **LED Light Not Working:**
    a. Check if batteries are correctly installed and not depleted.
    b. Ensure the LED module is properly connected within the model.
    c. Verify the power switch is in the "on" position.
- **Model Instability:** Re-examine previous steps to ensure all connections are secure. Loose connections can lead to structural weakness.

Specifications

Feature	Detail
Brand	HOGOKIDS
Model Number	HG1017
Number of Pieces	879
Product Dimensions	0.39 x 0.39 x 0.39 inches (packaging dimensions; assembled model dimensions may vary by configuration)
Item Weight	0.035 ounces (packaging weight)
Recommended Age	6 years and up
Special Features	3-in-1 build options, LED light, movable parts (door, windows, awning, removable roof)

Warranty and Support

HOGOKIDS strives to provide high-quality products. For specific warranty information, please refer to the packaging or contact HOGOKIDS directly. As a general guideline, retain your proof of purchase.
For any questions, missing parts, or support needs, please contact HOGOKIDS customer service through their official website or the retailer where the product was purchased. You can often find contact information on the product packaging or by visiting the HOGOKIDS Store on Amazon.

© 2025 HOGOKIDS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question