Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GNMN V7

GNMN Bluetooth Headphones Wireless Earbuds User Manual

Model: V7 | Brand: GNMN

Product Overview

The GNMN V7 Wireless Earbuds are designed for an immersive audio experience with comfort and durability in mind. Featuring a balanced sound profile with rich bass and clear treble, these earbuds are suitable for various activities, including sports and workouts. They offer extended playback time and are equipped with IPX7 waterproofing for protection against sweat and rain. The intuitive one-step pairing ensures quick connection to your devices.

- **Comfortable and Stable Fit:** Designed with flexible and soft ear hooks, ensuring a secure fit during strenuous activities. Includes multiple size eartips for a customizable fit.
- **All-day Battery Life:** Up to 8 hours of playback on a single charge, extendable to 80 hours with the charging case. Features a smart LED power display on the case.
- **Fast Auto Pairing:** Automatically connects to the last paired device upon removal from the charging case, offering low latency and stable signal.
- **HD Stereo Music & Clear Call:** Equipped with 11mm speaker driver units for hi-fi sound with strong bass and clear treble. Features a large chamber acoustic design for clear calls.
- **Touch Control & Wide Compatibility:** Sensitive touch controls for managing music and calls. Compatible with most Bluetooth-enabled devices including smartphones, TVs, computers, and smartwatches.

Package Contents

Please verify that all items are present in the package:

- GNMN V7 Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Multiple Sizes of Eartips (S, M, L)
- User Manual




Image: The GNMN V7 wireless earbuds shown inside their charging case, displaying the LED battery indicator.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, wall adapter).
3. The LED display on the charging case will show the battery percentage of the case and individual earbud charging status.
4. Once fully charged, the display will indicate 100% for the case and the earbud indicators will turn off or show full.




Image: The charging case connected via a USB-C cable, illustrating the charging process and battery life.



Image: Close-up of the charging case's dual digital display, showing separate battery levels for the case and each earbud.

2. Pairing with a Bluetooth Device

The earbuds support one-step automatic pairing.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, computer), enable Bluetooth.
3. Search for "V7" in the list of available Bluetooth devices.
4. Select "V7" to connect. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
5. For subsequent uses, the earbuds will automatically connect to the last paired device when taken out of the case, provided Bluetooth is enabled on the device.



Image: An illustration showing the earbuds connecting to a smartphone via Bluetooth, with "V7" visible in the device list.

Operating Instructions

Touch Controls

The GNMN V7 earbuds feature sensitive touch controls on each earbud. The following actions can be performed:

Action	Left Earbud	Right Earbud
Play/Pause Music	Single Tap	Single Tap
Next Track	Triple Tap	
Previous Track		Triple Tap
Volume Up	Double Tap	
Volume Down		Double Tap
Answer/End Call	Single Tap	Single Tap
Reject Call	Press and Hold (2s)	Press and Hold (2s)
Activate Voice Assistant	Press and Hold (2s)	Press and Hold (2s)

Wearing the Earbuds

For optimal sound quality and comfort, ensure the earbuds are properly seated in your ears. Choose the eartip size that provides the best seal and comfort.




Image: A person wearing the earbuds, demonstrating the secure and comfortable fit provided by the ear hooks and multiple eartip options.

Maintenance

Cleaning

- Regularly clean the earbuds, especially the eartips and charging contacts, with a soft, dry, lint-free cloth.

- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Remove eartips and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.

Storage

- When not in use, always store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place, away from extreme temperatures and direct sunlight.

Water Resistance (IPX7)

The earbuds are IPX7 waterproof, meaning they can withstand submersion in up to 1 meter of water for 30 minutes. This protects them from sweat and rain. **Note: The charging case is NOT waterproof.**



Image: The earbuds shown with water droplets, illustrating their IPX7 waterproof rating, suitable for sports and wet conditions.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Earbuds not pairing/connecting	Bluetooth off on device, earbuds not in pairing mode, interference.	Ensure Bluetooth is on. Place earbuds back in case, then take them out to re-enter pairing mode. Turn off/on device's Bluetooth. Clear previous "V7" connections.
Only one earbud working	Earbuds not properly synced, low battery on one earbud.	Place both earbuds back in the charging case, close the lid, wait a few seconds, then take them out again. Ensure both earbuds are charged.
Low volume or poor sound quality	Improper fit, dirty eartips/speakers, low battery.	Adjust earbuds for a secure fit. Try different eartip sizes. Clean eartips and speaker mesh. Charge earbuds fully.
Charging case not charging	Faulty cable/adapter, dirty charging port.	Try a different USB-C cable and power adapter. Ensure the charging port is clean and free of debris.

Specifications

Model Name: V7

Connectivity Technology: Wireless (Bluetooth)

Bluetooth Version: 5.0

Ear Placement: Over Ear

Water Resistance Level: IPX7 (Earbuds only)

Battery Life (Earbuds): Up to 8 Hours (single charge)

Total Playback Time (with Charging Case): Up to 80 Hours

Charging Time: Not specified for full charge, but 8 hours playback on single charge.

Control Type: Touch Control (Media Control)

Audio Driver Type: 11mm Dynamic Driver

Compatible Devices: Smartphones, Computers, Laptops, Smart TVs, Smart Watches

Material: Silicone

Color: Pink (Rose Gold+Pink style)



Image: An exploded view diagram of the earbud's internal components, highlighting the 11mm dynamic drivers and biological fiber composite diaphragm responsible for Hi-Fi stereo sound.

Warranty and Support

GNMN products are manufactured to the highest quality standards. For any questions, technical support, or warranty claims, please contact GNMN customer service through the retailer where the product was purchased or visit the official GNMN website for contact information.
Please retain your proof of purchase for warranty purposes.

© 2024 GNMN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9NWK8T2

More documents and user manuals: **https://manuals.plus/**