

[Manuals.plus](#) /

› [Sharper Image](#) /

› Sharper Image® Pulse Cupping Therapy Massager Set Instruction Manual

Sharper Image 1018359

Sharper Image® Pulse Cupping Therapy Massager Set

Model: 1018359

Brand: Sharper Image

INTRODUCTION

This manual provides essential information for the safe and effective use of your Sharper Image® Pulse Cupping Therapy Massager Set. Designed for full body pain relief and recovery, this wireless cupping kit combines heat, vibration, and suction to address muscle soreness, inflammation, and improve flexibility. Please read this manual thoroughly before operation and retain it for future reference.

SAFETY INFORMATION

Adherence to the following safety guidelines is crucial for preventing injury and ensuring proper device function:

- Use only specified batteries.
- Avoid use near water or in wet environments.
- Do not use on sensitive areas of the body or for extended periods beyond recommended session times.
- Do not use on broken skin, open wounds, or inflamed areas.
- This device is not intended to diagnose, treat, cure, or prevent any disease or health condition. Consult a healthcare professional for medical advice.


PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Pulse Cupping Therapy Massager Unit
- 1 x Small Interchangeable Cupping Cup (for targeted massage)
- 1 x Large Interchangeable Cupping Cup (for broad muscle groups)
- 1 x USB-C Charging Cable

- 1 x User Manual (this document)

SHARPER IMAGE®



MULTIPLE SUCTION LEVELS



OPTIONAL VIBRATION



OPTIONAL HEAT



2 INCLUDED CUPS

Use the smaller cup for more precision
and the larger cup for a wider coverage

Figure 1: Pulse Cupping Massager with both small and large cups.

PRODUCT OVERVIEW AND FEATURES

The Sharper Image® Pulse Cupping Therapy Massager is designed to provide a customizable and effective massage experience. Key features include:

- **Customizable Massage Experience:** Features 4 suction modes, 9 levels of suction intensity, 3 heat settings, and multiple vibration modes for a fully tailored massage.
- **Precise & Wide Coverage:** Comes with 2 interchangeable cups—a smaller cup for targeted massage and a larger one for broad muscle groups—enhancing precision and coverage.
- **Enhanced Recovery & Mobility:** Utilizes powerful suction and heat to boost blood circulation, accelerate recovery, and improve overall mobility with targeted relief.

- **Portable Design:** The compact, cordless design, complemented by USB-C charging, offers the convenience of therapeutic relief on the go.



Figure 2: The Pulse Cupping Massager and its packaging, highlighting key features.

SETUP

1. **Charge the Device:** Before first use, fully charge the massager using the provided USB-C cable. Connect the cable to the device and a compatible USB power source (e.g., wall adapter, computer USB port). The indicator light will show charging status.
2. **Attach the Desired Cup:** Select either the small or large cupping cup based on the area you intend to treat. Align the cup with the base of the massager and twist gently until it securely locks into place.



Figure 3: The massager unit, USB-C charging cable, and both cup sizes, illustrating the compact and rechargeable design.

OPERATING INSTRUCTIONS

Follow these steps for optimal use of your Pulse Cupping Therapy Massager:

- 1. Prepare the Skin:** For best results and to ensure proper suction, apply a light coat of massage oil or lotion to the skin area where you plan to use the massager.
- 2. Power On:** Press and hold the power button (usually indicated by a power symbol) to turn on the device.
- 3. Select Suction Mode and Intensity:** Use the dedicated buttons to cycle through the 4 suction modes and adjust the suction intensity across 9 levels. Start with a lower intensity and gradually increase as comfortable.
- 4. Activate Heat and Vibration (Optional):** Press the heat button to select one of the 3 heat settings. Press the vibration button to activate and cycle through the multiple vibration modes. These features can be used independently or in combination with suction.
- 5. Apply to Skin:** Place the cupping massager firmly onto the prepared skin area. The device will create a vacuum, drawing the skin and underlying tissue into the cup.
- 6. Massage Technique:** You can either leave the cup stationary for a few minutes (typically 5-10 minutes per area, especially when starting) or gently glide it across the skin for a dynamic massage. Do not exceed 10 minutes per

area, especially during initial uses, to gauge your body's reaction.

7. **Power Off:** After your session, press and hold the power button to turn off the device. Gently break the suction by tilting the cup or pressing the release button if available.

SHARPER IMAGE®

PULSE CUPPING

MULTIFUNCTION MASSAGER

+ CUSTOM MESSAGE
Adjust suction,
heat and vibration

#1 MESSAGE BRAND*

Figure 4: Demonstrating the application of the massager to the thigh, highlighting the adjustable settings for a custom message.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the features and use of the Sharper Image Pulse Cupping Massager, including its various modes and application on different body parts.

MAINTENANCE

To ensure the longevity and hygiene of your massager:

- **Cleaning:** After each use, detach the cupping cup and wipe both the cup and the main unit with a soft, damp cloth. For thorough cleaning, the cups can be washed with mild soap and water. Ensure all parts are completely dry before

reassembling or storing.

- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures. Keep it out of reach of children.
- **Battery Care:** If the device will not be used for an extended period, charge it periodically to maintain battery health.

TROUBLESHOOTING

If you encounter issues with your Pulse Cupping Therapy Massager, refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or no charge.	Charge the device fully using the provided USB-C cable.
No or weak suction.	Improper cup attachment, dry skin, or low battery.	Ensure the cup is securely attached. Apply massage oil or lotion to the skin. Recharge the device.
Heat or vibration not working.	Feature not activated or low battery.	Press the respective heat/vibration buttons to activate. Ensure the device is sufficiently charged.
Device stops unexpectedly.	Automatic shut-off (session limit) or low battery.	The device may have a built-in session timer (e.g., 10 minutes). Recharge if battery is low.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

- **Product Dimensions:** 3.31 x 3.31 x 3.86 inches
- **Item Weight:** 6.88 ounces
- **Model Number:** 1018359
- **Power Source:** Battery Powered (1 Lithium Ion battery included)
- **Material:** Plastic
- **Manufacturer:** Merchsource

WARRANTY AND SUPPORT

This Sharper Image® Pulse Cupping Therapy Massager Set is backed by a **1-year manufacturer warranty**. For any questions, issues, or to claim warranty support, please contact us through Amazon's messaging system. Our customer support team is ready to provide quick resolution and reliable product support.

For additional information or to explore other Sharper Image products, visit the official Sharper Image Store on Amazon: [Sharper Image Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question