



Manuals.plus /

› Euphro /

› Euphro 10.1" Digital Picture Frame User Manual

Euphro WF133-CA

Euphro 10.1" Digital Picture Frame User Manual

Model: WF133-CA

INTRODUCTION

Thank you for choosing the Euphro 10.1" Digital Picture Frame. This device allows you to easily share and display your cherished photos and videos with family and friends through a seamless Wi-Fi connection and the intuitive Uhale app. With its vibrant IPS touch screen and ample storage, your memories will be brought to life in stunning detail. This manual provides detailed instructions for setting up, operating, and maintaining your digital picture frame.

PRODUCT OVERVIEW

Key Features

- **10.1-inch IPS Touch Screen:** Features a 1280x800 resolution for vivid and clear display of photos and videos. The touch screen allows for easy navigation and interaction.
- **32GB Built-in Storage:** Provides ample space to store approximately 60,000 photos (at 300KB/pc). Storage is expandable via Micro SD card.
- **Wi-Fi Connectivity:** Enables instant sharing of photos and videos from anywhere using the free Uhale app (available on Android and iOS).
- **Multi-User Sharing:** Supports multiple users to connect and share content to the frame, making it ideal for families.
- **Automatic Rotation:** The frame automatically adjusts photo orientation whether placed horizontally or vertically.
- **Customization Options:** Adjust display order, image scaling, hide images, and change transition effects to personalize your viewing experience.
- **Privacy Protection:** The Uhale app is designed with multiple layers of privacy protection, ensuring photos are encrypted and transmitted end-to-end.

Components

The Euphro Digital Picture Frame package includes the following components:

- Euphro 10.1" Digital Picture Frame
- Power Adapter
- User Manual (this document)




Figure 1: Euphro Digital Picture Frame with the Uhale app interface on a smartphone, showing a dog swimming underwater.

This image illustrates the digital picture frame displaying a vibrant image of a dog swimming, alongside a smartphone showing the Uhale app's gallery view. This highlights the frame's display quality and the app's photo management capabilities.



Figure 2: Wireless Instant Sharing via Uhale App.

This image demonstrates the ease of sharing photos wirelessly from a smartphone to the digital picture frame using the Uhale app. It shows the app's icon and prompts to download from the App Store and Google Play.

32GB Built-in Memory

Supports micro SD card, Unlimited User Connections



Figure 3: 32GB Built-in Memory and Micro SD Card Support.

This image showcases the frame's internal storage capacity, indicating 32GB built-in memory and support for Micro SD card expansion. It displays a grid of various photos, emphasizing the large number of memories that can be stored.

Incredible Color Display

10.1 inch IPS touchscreen, 1280x800 resolution



Figure 4: Incredible Color Display with 10.1 inch IPS Touchscreen.

This image highlights the frame's 10.1-inch IPS touchscreen with 1280x800 resolution, demonstrating its ability to display images with incredible color and clarity, featuring a hot air balloon against a blue sky.

Auto-Rotate&Photo Adjust

Find the desired fit and decorate your space the way you like




Figure 5: Auto-Rotate and Photo Adjust Features.

This image illustrates the frame's auto-rotate function, showing it displaying a vertical photo of two people. It also indicates support for pictures/videos, weather forecasts, and unlimited user connections.

SETUP GUIDE

1. **Power On:** Connect the provided power adapter to the frame's power port and plug it into a wall outlet. The frame will automatically power on.
2. **Initial Setup:** Follow the on-screen prompts to select your language, time zone, and connect to a Wi-Fi network. Ensure you have your Wi-Fi password ready. The frame supports 2.4GHz Wi-Fi networks.
3. **Download the Uhale App:** On your smartphone (iOS or Android), search for and download the "Uhale" app from your respective app store.
4. **Pair the Frame with the App:**
 - Open the Uhale app and create an account or log in.
 - On the frame, navigate to the "Settings" or "Add Device" section to find the unique device code.
 - In the Uhale app, enter this device code to pair your smartphone with the digital picture frame.
 - Once paired, you can start sending photos and videos to your frame.

OPERATING INSTRUCTIONS

Sending Photos and Videos

- **Via Uhale App:**

Open the Uhale app on your smartphone. Select the photos or videos you wish to send from your gallery. Choose your connected Euphro frame and tap "Send" or "Share". The content will be uploaded to your frame via Wi-Fi.



Figure 6: Instant Sharing of photos and videos from a smartphone to the frame via the Uhale app.

This image visually explains how to instantly share content. A smartphone user is shown selecting photos, which are then wirelessly transmitted to the digital picture frame, illustrating the ease of use.

- **Via Micro SD Card/USB Drive:**

Insert a Micro SD card or USB drive containing your photos and videos into the designated slot on the frame. Navigate to the "Gallery" or "Storage" section on the frame's interface to access and import content. The frame supports various picture and video formats.

Customizing Settings

The frame offers various customization options accessible through the touch screen interface:

- **Display Order:** Adjust the sequence in which photos and videos are displayed (e.g., chronological, random).
- **Image Scaling:** Choose how images fit the screen (e.g., fit to screen, fill screen).
- **Image Transitions:** Select from various transition effects between photos (e.g., fade, slide).
- **Hide/Delete Images:** Manage your content directly on the frame by hiding or deleting unwanted photos/videos.
- **Sleep Mode:** Configure the frame to enter sleep mode during specific hours to save energy.
- **Weather Forecast:** Enable or disable the display of local weather information.

Meet the 10.1" Euphro Canvas

Euphro 10.1" Canvas frame digital helps you keep every smile in stunning detail and bring all your favorite memories to life with 10.1" 1280x800 resolution.



10.1" HD 1280x800

Delivers vibrant colors and vivid details in 10.1" screen

32GB Storage

Built-in 32GB memory can store up to 60,000 photos

WiFi Connection

Share your moments via 2.4G hz WiFi connection

IPS Touchscreen

See all the stunning colors across 178° viewing angle

Figure 7: Overview of Euphro 10.1" Canvas features including HD display, 32GB storage, WiFi, and IPS Touchscreen.

This image provides a summary of the key features of the Euphro 10.1" Canvas model, emphasizing its HD display, 32GB storage capacity, WiFi connectivity for sharing, and responsive IPS touchscreen with wide viewing angles.

MAINTENANCE

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the screen. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution designed for electronics. Avoid harsh chemicals or abrasive materials.
- **Cleaning the Frame:** Wipe the frame's body with a dry, soft cloth.
- **Storage:** When not in use for extended periods, store the frame in a cool, dry place away from direct sunlight and extreme temperatures.
- **Software Updates:** Periodically check for software updates through the frame's settings menu to ensure optimal performance and access to new features.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Frame does not power on.	Power adapter not connected or faulty outlet.	Ensure the power adapter is securely connected to the frame and a working power outlet. Try a different outlet.
Cannot connect to Wi-Fi.	Incorrect password, weak signal, or unsupported network frequency.	Double-check the Wi-Fi password. Move the frame closer to the router. Ensure your router is broadcasting a 2.4GHz network. Restart the frame and router.
Photos/Videos not appearing on frame.	App not paired, incorrect frame selected, or network issue.	Verify the frame is correctly paired with the Uhale app. Ensure you are sending to the correct frame ID. Check your internet connection.
Screen is unresponsive.	Temporary software glitch.	Restart the frame by unplugging and re-plugging the power adapter.
Images appear distorted or low quality.	Low resolution source image or incorrect display settings.	Ensure the original images are of high resolution. Adjust image scaling settings on the frame (e.g., "Fit to Screen" vs. "Fill Screen").

SPECIFICATIONS

Model Number: WF133-CA

Screen Size: 10.1 Inches

Resolution: 1280x800 IPS Touch Screen

Internal Storage: 32GB

Expandable Storage: Supports Micro SD Card

Connectivity: Wi-Fi (2.4GHz)

Product Dimensions: 18 x 26 x 2.51 cm

Weight: 870 g

Compatible Devices: Smartphone (via Uhale App)

Manufacturer: Euphro

Country of Origin: China

WARRANTY AND SUPPORT

Euphro is committed to providing high-quality products and excellent customer service.

- **Warranty:** Your Euphro Digital Picture Frame comes with a One-Year Warranty, providing worry-free and lifetime technical support.
- **After-Sales Service:** All queries will be handled within 24 hours.
- **Contact Information:**
 - **Email:** help@euphroframes.com
 - **Website:** www.euphroframes.com

EUPHRÓ

Unite Loved Ones Near and Far

The Brand That **Brings Joy**



24-Hour After-Sales Service

All queries will be handled within 24 hours



One-Year Warranty

Worry-Free and life-time tech support



Gift Packing Design

Make life simple with gift-ready packaging



Environmentally Friendly

Proud to support environment preservation

Figure 8: Euphro Brand Commitments.

This image highlights Euphro's commitment to customer satisfaction, including 24-hour after-sales service, a one-year warranty, gift-ready packaging, and environmentally friendly practices.