

[Manuals.plus](#) /

> [Vicco](#) /

> Vicco Omira Desk User Manual

## Vicco 22819

# Vicco Omira Desk User Manual

Model: 22819

## PRODUCT OVERVIEW

The Vicco Omira Desk is designed for home office or workplace use, offering a functional and elegant solution. It features four pull-out drawers for ample storage and an excellent solution for those who need to work on a computer or have a functional work table. The robust construction ensures solidity and stability, while the compact design makes it suitable for various situations. Versatile and combinable with other models, Omira is the ideal choice for those looking for a functional and high-level desk.



Image: Front view of the Vicco Omira Desk in black, showcasing its sleek design and integrated drawers.

## SAFETY INFORMATION

**Important! Keep for future reference. Read carefully!**

### TIP-OVER HAZARD!

Unanchored furniture can tip over, causing serious or fatal crushing injuries. To prevent this furniture from tipping over, it must be securely anchored to the wall. Use fastening accessories suitable for your home's wall materials. If you have any questions regarding proper installation, contact your local specialist dealer. Always follow each step of the assembly and installation instructions carefully.

## SETUP AND ASSEMBLY

The Vicco Omira Desk requires assembly. All necessary mounting materials and detailed assembly instructions are included in the package. Please ensure you have sufficient space and the appropriate tools before beginning assembly.

1. **Unpack all components:** Carefully remove all parts from the packaging and verify against the parts list provided in the assembly instructions.
2. **Identify components:** Familiarize yourself with each part and its corresponding label as shown in the manual.
3. **Follow step-by-step instructions:** Adhere strictly to the sequence of steps outlined in the assembly manual. Do not skip steps.
4. **Secure wall anchoring:** As a critical safety measure, ensure the desk is anchored to a wall using the provided hardware or suitable alternatives for your wall type. This prevents tip-over hazards.
5. **Tighten all fasteners:** Once assembled, ensure all screws and fasteners are securely tightened, but do not overtighten.




Image: Technical diagram showing the dimensions of the Vicco Omira Desk, including overall width, height, depth, and drawer measurements.

## OPERATING INSTRUCTIONS

The Vicco Omira Desk is designed for general office and study use. Its primary function is to provide a stable work surface and integrated storage.

- **Work Surface:** Use the main desk surface for placing computers, monitors, writing materials, and other office essentials. Ensure weight is distributed evenly.
- **Drawers:** The desk features four pull-out drawers. Use them to organize documents, stationery, and other items. Avoid overloading drawers to ensure smooth operation and prevent damage.
- **Placement:** Position the desk on a flat, stable surface. Avoid placing it in direct sunlight or near heat sources to prevent material degradation.



Image: The Vicco Omira Desk integrated into a modern home office environment, demonstrating its aesthetic appeal and functional use.

## MAINTENANCE AND CARE

To ensure the longevity and appearance of your Vicco Omira Desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the surface with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive materials that could damage the melamine resin coating.
- **Spills:** Immediately wipe up any spills to prevent liquid absorption and staining.
- **Fasteners:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary, but do not overtighten.
- **Avoid excessive weight:** Do not place excessively heavy items on the desk surface or in the drawers beyond their intended capacity.
- **Environmental conditions:** Maintain a stable room temperature and humidity. Extreme fluctuations can affect wood-based materials.



Image: A close-up view of the Vicco Omira Desk's drawers, demonstrating their smooth operation and internal storage capacity.

## TROUBLESHOOTING

This section addresses common issues you might encounter with your Vicco Omira Desk.

| Problem                        | Possible Cause                                             | Solution                                                                                                                               |
|--------------------------------|------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| Desk feels wobbly or unstable. | Loose fasteners; uneven floor; desk not anchored to wall.  | Check and tighten all assembly fasteners. Ensure the desk is on a level surface. Verify wall anchoring is secure.                      |
| Drawers do not slide smoothly. | Overloaded drawers; debris in runners; misaligned runners. | Reduce weight in drawers. Clean drawer runners. Check assembly instructions for proper runner alignment.                               |
| Surface scratches or marks.    | Sharp objects; abrasive cleaning.                          | Use coasters or desk mats. Clean with soft cloth and mild cleaner only. Minor scratches may be camouflaged with furniture repair kits. |

## SPECIFICATIONS

- **Model:** 22819
- **Brand:** Vicco
- **Color:** Black
- **Dimensions (Width x Height x Depth):** 120 cm x 76 cm x 55 cm (47.2 x 29.9 x 21.7 inches)
- **Material:** Particle board, 16 mm
- **Surface:** Melamine resin coating
- **Net Weight:** 36.3 kg (79.9 lbs)
- **Special Features:** Compact design, 4 pull-out drawers




Image: An illustrative diagram highlighting the modern and elegant design, ample storage space, and sturdy material of the Vicco Omira Desk.

## WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or technical support, please refer to the documentation included with your purchase or contact the retailer or manufacturer directly. Keep your proof of purchase for any warranty claims.

**Manufacturer:** Vicco

**Model:** 22819

**ASIN:** B0D9R4CPNG

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0D9R4CPNG>

More documents and user manuals: <https://manuals.plus/>