

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [KICKDOT](#) /

› [KICKDOT Phone Controller User Manual](#)

## KICKDOT KD-PC01

# KICKDOT Phone Controller User Manual

Model: KD-PC01

## 1. INTRODUCTION

---

Thank you for choosing the KICKDOT Phone Controller. This device is designed to enhance your mobile gaming experience by providing precise control and ergonomic comfort. It is compatible with a wide range of smartphones and supports various gaming platforms. Please read this manual thoroughly before using the controller to ensure proper operation and to maximize its features.

## 2. PACKAGE CONTENTS

---

- KICKDOT Phone Controller
- USB Charging Cable
- User Manual

## 3. PRODUCT OVERVIEW

---



Figure 3.1: KICKDOT Phone Controller with an inserted smartphone, showing compatibility with Xbox Game Pass, PS Remote Play, Steam Link, and various mobile games.

The KICKDOT Phone Controller features a telescopic design to securely hold various smartphone sizes. It includes standard gaming controls such as dual analog joysticks, a D-pad, action buttons (A, B, X, Y), and shoulder buttons. Additional buttons include SELECT, START, TURBO, and HOME. Indicator lights (1, 2, 3, 4) are present to show connection status or player number. The controller supports both Apple iOS and Android devices, connects wirelessly via Bluetooth, and is powered by a rechargeable battery.

### 3.1. Controller Components

- **Left Side:** Left Analog Joystick, D-Pad, SELECT button, TURBO button, Player Indicator Lights (1-4).
- **Right Side:** Right Analog Joystick, Action Buttons (A, B, X, Y), START button, HOME button.
- **Top/Bottom:** Shoulder/Trigger buttons, USB-C Charging Port.
- **Center:** Extendable phone clamp.

## 4. SETUP

## 4.1. Charging the Controller

Before first use, fully charge the controller. Connect the provided USB charging cable to the controller's charging port and the other end to a USB power source (e.g., computer USB port, wall adapter). The indicator lights will show charging status and turn off or change color when fully charged.

## 4.2. Installing Your Smartphone

1. Gently pull the left and right sides of the controller outwards to extend the phone clamp.
2. Carefully place your smartphone into the center slot, ensuring it is securely seated and centered.
3. Release the sides of the controller to allow the clamp to hold the phone firmly.

## 4.3. Bluetooth Pairing

1. Ensure the controller is sufficiently charged.
2. Turn on the controller by pressing and holding the **HOME** button for a few seconds. The indicator lights will begin to flash, indicating it is in pairing mode.
3. On your smartphone, navigate to **Settings > Bluetooth**.
4. Turn on Bluetooth and search for available devices.
5. Select "**KICKDOT Controller**" (or similar name) from the list of found devices.
6. Once paired, one or more indicator lights on the controller will become solid, indicating a successful connection.

*Note:* If pairing fails, turn off the controller and your phone's Bluetooth, then repeat the steps. Some games or applications may require specific controller modes; refer to the game's settings for optimal configuration.

# 5. OPERATING INSTRUCTIONS

---

## 5.1. Basic Controls

- **Analog Joysticks:** Used for precise movement and camera control in games.
- **D-Pad:** Used for directional input, often for menu navigation or specific actions.
- **Action Buttons (A, B, X, Y):** Perform in-game actions such as jumping, attacking, interacting, etc.
- **SELECT/START Buttons:** Typically used for pausing games, opening menus, or confirming selections.
- **HOME Button:** Powers the controller on/off, or returns to the device's home screen in some configurations.
- **TURBO Button:** Activates rapid-fire functionality for selected action buttons. To use, hold the TURBO button and press the desired action button (e.g., A). Press again to deactivate.

## 5.2. Touchpad Functionality

The KICKDOT Phone Controller includes a touchpad feature, allowing for mouse-like input in compatible applications or games. This can be particularly useful for navigating menus or interacting with elements that typically require touch input on a smartphone screen. Refer to your game or application settings for specific touchpad configuration and usage.

## 5.3. Gaming Platform Compatibility

The controller is designed to work seamlessly with popular gaming platforms and services, including:

- [Xbox Game Pass](#)
- [PS Remote Play](#)
- [Steam Link](#)

For optimal performance, ensure your gaming applications are updated to their latest versions and check their in-app controller settings.

## 6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the controller. Do not use abrasive cleaners or solvents.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the controller frequently. Charge it regularly, even if not in use for extended periods.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Controller does not turn on.	Low battery.	Charge the controller fully.
Cannot pair with smartphone.	Bluetooth not enabled; controller not in pairing mode; interference.	Ensure Bluetooth is on. Press and hold HOME button to enter pairing mode. Move closer to the phone. Restart both devices.
Buttons/joysticks unresponsive in game.	Incorrect game settings; controller not recognized by game; low battery.	Check in-game controller settings. Restart the game. Repair the controller. Charge the controller.
Phone does not fit securely.	Phone case too bulky; phone size exceeds limits.	Remove phone case. Verify phone dimensions against controller specifications.

## 8. SPECIFICATIONS

**Model:** KD-PC01

**Connectivity:** Bluetooth Wireless

**Compatibility:** iOS, Android Smartphones

**Power:** Rechargeable Lithium-ion Battery

**ASIN:** B0D9SCFHFL

**Features:** Touchpad, Extendable Phone Clamp, Ergonomic Design

## 9. WARRANTY AND SUPPORT

KICKDOT products are manufactured to the highest quality standards. For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official KICKDOT website. If you encounter any issues not covered in this manual, please contact our customer support team for assistance.