

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [King Lucky](#) /

› [King Lucky i121 Open Ear Clip-on Earbuds User Manual](#)

King Lucky i121

King Lucky i121 Open Ear Clip-on Earbuds User Manual

Model: i121 | Brand: King Lucky

1. INTRODUCTION

Welcome to the user manual for your King Lucky i121 Open Ear Clip-on Earbuds. These earbuds are designed to provide a comfortable audio experience while keeping you aware of your surroundings. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new device.

Global sales **No.1**

Open Ear buds



1,000,000+ units

Global Sales

In Frost&Sullivan (2023) global survey, this product ranked No.1 in sales among same-priced open-ear earbuds, proving its high quality and reputation.

TOP 1

Image: King Lucky i121 Open Ear Clip-on Earbuds and their charging case.

2. PRODUCT OVERVIEW

Key Features

- **Open Ear Design:** Enjoy audio while maintaining awareness of your surroundings.
- **Comfortable Fit:** Upgraded C-shaped bridge design and lightweight (5.3g per earbud) for extended wear without discomfort.
- **Clear Calls:** Equipped with ENC (Environmental Noise Cancellation) technology for crystal-clear voice calls, even in noisy environments.
- **Extended Playtime:** Up to 6 hours of listening on a single charge, with a total of up to 50 hours using the portable charging case.
- **Advanced Connectivity:** Features Bluetooth 5.4 for stable, low-latency connections and efficient energy consumption.

- **Durable Design:** IPX5 waterproof rating with a nano hydrophobic coating protects against rain and sweat.
- **Sound Leakage Prevention:** Utilizes directional acoustic technology to minimize sound leakage.

What's in the Box




Image: The retail package contents, including the earbuds, charging case, user manual, and Type-C charging cable.

- King Lucky i121 Open Ear Earbuds x 2
- Charging Case x 1
- User Manual x 1
- Type-C Charging Cable x 1

3. SETUP

Wearing the Earbuds

For optimal sound and comfort, ensure the earbuds are worn correctly.



Image: Step-by-step guide on how to wear the earbuds: 1. Align the speaker with your ear canal. 2. Position the earbud. 3. Adjust for a secure and comfortable fit.

1. **Align:** Position the earbud so the speaker aligns with your ear canal.
2. **Clip:** Gently clip the earbud onto your ear, ensuring the C-shaped bridge sits comfortably around your earlobe.

3. **Adjust:** Make minor adjustments to ensure a secure and comfortable fit. The lightweight design should feel barely noticeable.

Initial Charging

Before first use, fully charge both the earbuds and the charging case.

- Place the earbuds into the charging case.
- Connect the Type-C charging cable to the charging port on the case and a power source.
- The indicator light on the case will show charging status. A full charge typically takes about 2 hours for the case.

Bluetooth Pairing

Follow these steps to pair your earbuds with your device:

1. Ensure the earbuds are charged and placed inside the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing light (refer to specific light patterns in the full manual if available).
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices and select "King Lucky i121" (or similar name) from the list.
5. Once connected, the earbuds will indicate successful pairing (e.g., a voice prompt or solid light).
6. The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

4. OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Open the charging case, and the earbuds will power on automatically.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off automatically and begin charging.

Touch Controls

The King Lucky i121 earbuds feature intuitive touch controls on each earbud. Refer to the diagram below for specific functions:




Image: Touch control guide for music playback and call management.

Earbud Touch Control Functions

Action	Function
Single Tap (L/R)	Volume Up/Down
Double Tap (L/R)	Play/Pause Music
Double Tap (L/R)	Answer/End Call
Press and Hold 2s (L/R)	Reject Call

Charging the Earbuds and Case



Image: The charging case displaying battery life and charging times.

- **Earbuds Charging:** Place the earbuds into the charging case. They will automatically charge from the case's internal

battery.

- **Case Charging:** Connect the provided Type-C cable to the charging case and a USB power adapter (not included). The indicator light will show charging progress.
- **Battery Life:** Earbuds provide approximately 6 hours of playtime on a single charge. The charging case extends total playtime to up to 50 hours.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your King Lucky i121 earbuds.

Cleaning



What's in the box ?

- Open Ear Earbuds x2
- Charging Case x1
- User Manual x1
- Type-c Charging Cabl x1

Image: The earbuds are shown in water, highlighting their IPX5 waterproof feature.

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Avoid using abrasive materials, solvents, or aerosol sprays.
- The earbuds are IPX5 waterproof, meaning they are resistant to splashes and sweat. Do not submerge them in water or expose them to strong jets of water.

Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Keep the device in a cool, dry place, away from extreme temperatures and direct sunlight.

6. TROUBLESHOOTING

If you encounter issues with your earbuds, refer to the following common solutions:

Common Troubleshooting Steps

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on your device's Bluetooth. Forget the device in Bluetooth settings and re-pair.
No sound from one earbud	Place both earbuds back in the case, close the lid, then open again. Check device's audio balance settings.

Problem	Solution
Earbuds not charging	Ensure the charging cable is securely connected. Check if the charging case has power. Clean charging contacts on earbuds and case.
Poor sound quality	Ensure earbuds are clean and properly seated in your ears. Move closer to your paired device to avoid interference.
Touch controls unresponsive	Ensure your fingers are clean and dry. Try restarting the earbuds by placing them in the case and taking them out.

Factory Reset

If issues persist, a factory reset may resolve them. Consult the full product manual or King Lucky support for specific reset procedures for the i121 model.

7. SPECIFICATIONS

Detailed technical specifications for the King Lucky i121 Open Ear Clip-on Earbuds.




Image: An exploded view illustrating the 12mm audio driver for immersive sound.

King Lucky i121 Earbuds Specifications

Feature	Detail
Model Name	i121
Bluetooth Version	5.4
Ear Placement	Open Ear
Form Factor	In Ear (Clip-on)
Water Resistance Level	IPX5
Battery Life (Earbuds)	6 Hours
Battery Life (with Case)	Up to 50 Hours
Charging Time	2 Hours (Case)

Feature	Detail
Control Type	Touch Control
Audio Driver Type	Dynamic Driver (12mm)
Noise Control	ENC (Environmental Noise Cancellation for calls)
Item Weight	3.2 ounces (total package)
Material	Leather (as per spec, likely referring to ear-contact material)

Additional Features Demonstrated

Your browser does not support the video tag.

Video: A demonstration of the King Lucky i121 earbuds, showcasing their design, lightweight nature, IPX5 waterproofing, and long battery life. This video highlights key features and user experience.




Image: Explanation of dual sound wave directional transmission technology for minimizing sound leakage.




Image: Demonstrates ENC Noise Cancellation for clear calls in various environments.

8. WARRANTY AND SUPPORT

Warranty Information

King Lucky offers a 100-day return guarantee for this product. Please retain your proof of purchase for warranty claims.

Customer Support

For further assistance, technical support, or warranty inquiries, please contact King Lucky customer service through the retailer where you purchased the product or visit the official King Lucky website for contact information.