AUKTWE SQ-1

AUKTWE Electric Water Gun Instruction Manual

Model: SQ-1

1. Product Overview

The AUKTWE Electric Water Gun is designed for exciting water battles, offering both manual and automatic firing modes. It features a light-up muzzle, a powerful shooting range of 28-32 feet, and a high-capacity water tank for extended play. Constructed from durable ABS plastic, this water gun ensures safe and enjoyable outdoor fun for both adults and children.

Figure 1: AUKTWE Electric Water Gun in action.

2. What's in the Box

Please check the package contents to ensure all items are present:

- Water Gun x 1
- Light Up Muzzle x 1
- Battery Pack x 1
- USB Charger x 1
- Type-C Charger x 1
- Instruction Manual x 1

Figure 2: Package Contents.

3. Safety Information

WARNING: CHOKING HAZARD -- Small parts. Not for children under 3 years.
This product may be mistaken for a firearm by law enforcement officers or others. Altering the coloration or markings required by state or federal law or regulations so as to make the product look more like a firearm is dangerous and may be a crime. Brandishing or displaying this product in public may cause confusion

and may be a crime.

Always use the water gun responsibly and in appropriate environments. Do not aim at eyes or face. Use clean tap water only. Keep away from electrical outlets and devices when wet.

4. Setup

4.1 Charging the Battery

Before first use, ensure all components are fully charged. The water gun's scope contains a battery, and the silencer (muzzle flash) also requires charging. An unused charger (not included in the packaging) is required for charging.

1. Open the cover of the scope to access the charging port.
2. Connect the scope charging cable to an unused charger and plug it in. The light on the charging cable will change color once fully charged.
3. Connect the silencer charging cable to an unused charger and plug it in. The silencer is fully charged in approximately half an hour.

Figure 3: Charging the scope and silencer.

4.2 Assembly

Follow these steps to assemble your electric water gun:

1. **Fill the Water Tank:** Open the lid of the water tank and fill it with clean water. Remember to securely close the lid after filling.
2. **Install Water Tank:** Insert the filled water tank into the water gun's handle. Push it firmly until it clicks into place.
3. **Install the Scope:** When holding the water gun facing forward, ensure the logo on the scope faces the left side. Slide the scope onto the top rail of the water gun until it is secure.
4. **Install the Silencer:** Attach the silencer to the muzzle of the water gun. Ensure the light switch on the silencer is turned on. You can insert a toothpick into the muzzle to check if it lights up; it's a sensor-activated light.

Figure 4: Assembly Steps.

4.3 Assembly and Charging Demonstration

Your browser does not support the video tag.

Video 1: This video demonstrates the unboxing, charging of components (scope and silencer), and the assembly process of the AUKTWE Electric Water Gun. It highlights how to properly install the water tank, scope, and silencer, and how to activate the light-up feature.

5. Operating Instructions

Once assembled and charged, your AUKTWE Electric Water Gun is ready for use:

1. **First Use Priming:** When using the water gun for the first time, hold down the trigger for approximately 1 minute to allow the water to start flowing and prime the system.
2. **Firing:** Press the trigger to activate the automatic firing mechanism. The water gun features a one-touch burst fire with powerful recoil simulation.

3. **Shooting Range:** The water gun can achieve a shooting range of 28-32 feet, making it effective for various water games.
4. **Muzzle Flash:** The integrated light-up muzzle activates during firing, adding an exciting visual effect.
5. **Water Capacity:** The high-capacity water tank allows for over 500 water blasts per fill.

Figure 5: Shooting Range and Light-Up Feature.

Figure 6: Enjoying the water gun.

5.1 Operational Features Demonstration

Your browser does not support the video tag.

Video 2: This video showcases the full automatic firing, muzzle flash, and shooting range capabilities of the AUKTWE Electric Water Gun. It also demonstrates the water-resistant modular battery and convenient charging.

6. Maintenance

To ensure the longevity and optimal performance of your AUKTWE Electric Water Gun, follow these maintenance guidelines:

- **Cleaning:** After each use, empty any remaining water from the tank. Wipe down the exterior of the water gun with a clean, damp cloth. Do not submerge the entire gun in water.
- **Drying:** Allow all components to air dry completely before storing to prevent mold or mildew.
- **Storage:** Store the water gun in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Recharge the battery pack periodically, even if not in use, to maintain battery health. The modular battery is water-resistant, but avoid prolonged submersion.

7. Troubleshooting

If you encounter any issues with your AUKTWE Electric Water Gun, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Water gun does not shoot water.	Insufficient priming; water tank not properly installed; internal suction issue.	Hold trigger for 1 minute to prime. Ensure water tank is fully inserted and sealed. Check for blockages in the water intake.
Light-up muzzle not working.	Silencer battery low; light switch off; silencer not properly installed.	Charge the silencer battery. Ensure the light switch on the silencer is turned on. Reinstall the silencer securely.
Gun not firing automatically.	Main battery low or not connected.	Ensure the main battery (in the scope) is fully charged and properly connected.

For further assistance, please refer to the troubleshooting video or contact customer support.

8. Specifications

Feature	Detail
Product Dimensions	10.6 x 5 x 10.8 inches
Item Weight	1.76 pounds
Item Model Number	SQ-1
Manufacturer Recommended Age	8 years and up
Batteries	1 Lithium Ion battery required (included)
Country of Origin	China
Manufacturer	AUKTWE

9. Warranty and Support

AUKTWE is committed to providing high-quality products and excellent customer service. Your Electric Water Gun comes with the following:

- **30-Day Return Policy:** Enjoy a 30-day no-reason return policy.
- **24-Hour Response:** Quick response via phone or email for any inquiries.
- **Lifetime Support:** Dedicated lifetime support and satisfactory solutions.
- **1-Year Free Replacement:** A 1-year free replacement warranty for manufacturing defects.

If you have any questions or require support, please feel free to contact us via Amazon messaging or visit the official AUKTWE Store: AUKTWE Store.

Figure 7: AUKTWE Support Commitments.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question