

ESR 2K644

ESR MagSafe Wallet with Find My Functionality

Model: 2K644

Brand: ESR

1. INTRODUCTION

The ESR MagSafe Wallet with Find My Functionality is designed to securely hold your essential cards while providing advanced tracking capabilities through Apple's Find My network. This wallet features strong magnetic attachment, RFID blocking for data security, and a rechargeable battery for extended use. It is crafted from durable vegan leather and offers convenient access to your cards.



Image 1.1: ESR MagSafe Wallet attached to an iPhone, showcasing its design and the Find My app interface.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- ESR Geo Wallet Boost (HaloLock)
- 1.7-ft (50 cm) PIN to USB-C charging cable

What We've Done

2024 • Won IF design award and 2 French design awards

2023 • Revolutionized MagSafe wallets with Find My

- Launched Apple-certified MagSafe + CryoBoost
- Won 2 Red Dot design awards and an IF design award

2022 • Sped up charging with CryoBoost

- Won IF design award

2021 • Brought MagSafe charging to the car

- Developed 110-lb impact-resistant Armorite

2020 • Won first Red Dot design award

2017 • Pioneered the kickstand phone case

2009 • ESR was found

Image 2.1: Contents of the ESR MagSafe Wallet package.

3. SETUP

3.1 Charging the Wallet

Before initial use, fully charge your ESR MagSafe Wallet. A full charge takes approximately 1.5 hours and provides up to 6 months of battery life.

1. Connect the provided USB-C charging cable to the charging port on the wallet.
2. Connect the other end of the cable to a USB power adapter (not included).
3. The indicator light on the wallet will show charging status. Charge until the green light is solid.



Image 3.1: The ESR MagSafe Wallet connected to its USB-C charging cable.

3.2 Pairing with Apple Find My

The wallet integrates with Apple's Find My network for location tracking. Follow these steps to pair your wallet:

1. **Charge your Geo Wallet** until the green light is on.
2. On your iPhone, go to **Settings > Bluetooth** and ensure Bluetooth is enabled. Also, navigate to **Settings > Privacy & Security > Location Services** and ensure Location Services is enabled.
3. **Press the power button** on your Geo Wallet until you hear a beep.
4. Open the **Find My app** on your iPhone. Go to **Items > Add New Item > Other Supported Item > Connect**. Follow the on-screen prompts to complete the pairing process.

Pairing in 4 Easy Steps




Image 3.2: Step-by-step guide for pairing the wallet with Apple Find My.

4. OPERATING INSTRUCTIONS

4.1 Attaching to Your iPhone

Align the ESR MagSafe Wallet with the MagSafe area on the back of your compatible iPhone or MagSafe-compatible case. The strong N52 magnets will securely attach the wallet.

Stronger Magnetic Lock



Magnetic strength

ESR with ESR magnetic case



3,200 g

Others



800 g

4x
stronger

*Data based on ESR lab testing with iPhone 15 Pro Max

Image 4.1: Illustration of the strong magnetic hold of the wallet.

4.2 Storing and Accessing Cards

The wallet features two slots designed to hold up to 5 cards or 4 cards with 3 banknotes. A 20mm bottom cutout facilitates easy and instant card access.

- To insert cards: Gently slide your cards into the designated slots.
- To retrieve cards: Use the bottom cutout to push the cards upwards, then pull them out.

Smart Card Storage

Holds 4 cards and 3 banknotes securely



+



or



4 cards and 3 banknotes

5 cards

Image 4.2: Demonstrating smart card storage in the wallet.

Easy Card Access



Image 4.3: Easy card access using the bottom cutout.

4.3 Using Find My Functionality

Once paired, you can utilize the Find My app to locate your wallet:

- **Track Location:** View the real-time location of your wallet on a map within the Find My app.
- **Play Sound:** If your wallet is nearby but out of sight, use the 'Play Sound' feature in the Find My app to emit an audible alert from the wallet.
- **Left Behind Notifications:** Receive alerts on your iPhone if you accidentally leave your wallet behind.

Full Find My Functionality



Image 4.4: Using the Find My app to locate the wallet and play a sound.

5. MAINTENANCE

5.1 Cleaning

To clean your ESR MagSafe Wallet, gently wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these may damage the vegan leather finish.

5.2 Protecting Magnetic Cards

The wallet features a special anti-degaussing lining to protect your cards' magnetic strips from demagnetization. Ensure cards are fully inserted into the slots for optimal protection.



Image 5.1: The anti-degaussing lining for card protection.

6. TROUBLESHOOTING

- **Wallet not attaching securely:** Ensure your iPhone or case is MagSafe-compatible. Non-magnetic cases will prevent a secure attachment. Clean both the wallet and phone/case surfaces to remove any debris.
- **Difficulty inserting/removing cards:** While the wallet can hold up to 5 cards, optimal access is achieved with 4 cards or 4 cards and 3 banknotes. Overfilling may make card retrieval difficult.
- **Find My functionality not working:**
 - Ensure the wallet is charged.
 - Verify Bluetooth and Location Services are enabled on your iPhone.
 - Confirm the wallet is properly paired with the Find My app (refer to Section 3.2).
 - Note that Find My does not offer 'Precision Finding' like an AirTag. Location is approximate, and the sound feature is used for close-range retrieval.
 - 'Left Behind' notifications may have a slight delay (up to 10 minutes) depending on network conditions.
- **Battery draining quickly:** Ensure the wallet is fully charged as per Section 3.1. If issues persist, contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	2K644
Dimensions	3.78 x 2.6 x 0.45 inches
Weight	5.6 ounces
Material	Vegan Leather
Color	Brown

Card Capacity	Up to 5 cards or 4 cards + 3 banknotes
Magnetic Strength	3,200 g (with ESR magnetic case)
Charging Time	1.5 hours
Battery Life	Up to 6 months
Special Features	Find My Functionality, RFID Blocking, Strong Magnetic Hold

8. COMPATIBILITY

8.1 Compatible Devices/Accessories

- iPhones with MagSafe (iPhone 12 series or later, including 17/16/15/14/13/12 Pro Max, Pro, Plus, Air, and standard models)
- Official MagSafe cases
- ESR magnetic cases
- ESR Universal Rings

8.2 Not Compatible With

- iPhone 13/12 Mini
- Non-magnetic cases

Compatibility

✓ iPhones with MagSafe (12 series or later)

✓ Official MagSafe cases

✓ ESR magnetic cases

✓ ESR Universal Rings

✗ iPhone 13/12 mini

✗ Non-magnetic cases



Image 8.1: Visual guide to device compatibility.

9. SAFETY INFORMATION

- Keep the wallet away from strong magnetic fields that are not part of its intended use, as this may affect its functionality or demagnetize cards.
- Do not expose the wallet to extreme temperatures, direct sunlight, or liquids.
- Avoid dropping or subjecting the wallet to severe impacts.
- Do not attempt to disassemble or modify the wallet.

10. WARRANTY AND SUPPORT

For warranty information, product support, or any inquiries, please visit our official website or contact our customer support team:

- Website: esrgear.com
- Email: esr.support@esrgear.com

