

Ejoyous Ejoyousg46xofc9zq

Ejoyous Portable Coffee Maker Instruction Manual

Model: Ejoyousg46xofc9zq

1. SAFETY INFORMATION

Please read all instructions carefully before using the Ejoyous Portable Coffee Maker. Keep this manual for future reference.

- This appliance is designed for household use only. Do not use it for commercial purposes.
- Do not immerse the main unit in water or any other liquid. Clean only with a damp cloth.
- The coffee maker does **not** have a water boiling function. Always use hot water (up to 92 degrees Celsius) for brewing.
- Keep out of reach of children.
- Ensure the Type-C charging cable is used with a compatible power source.
- Do not operate the appliance if it is damaged or malfunctioning. Contact customer support for assistance.

2. PRODUCT OVERVIEW

The Ejoyous Portable Coffee Maker is a versatile 2-in-1 device designed for convenience on the go. It supports both coffee capsules and ground coffee, offering flexibility for your brewing preferences. Its compact and cordless design, powered by a built-in rechargeable battery, makes it ideal for travel, camping, and other outdoor activities.

Cordless and portable
Take the familiar taste with you
Lightweight and portable

50 cups on a
single charge

Built in
lithium battery




Image: The Ejoyous Portable Coffee Maker highlighting its cordless and portable nature, capable of brewing up to 50 cups on a single charge.

Key Features:

- **Versatile 2-in-1 Design:** Compatible with both coffee capsules (5-6g) and ground coffee (up to 10g).
- **Portable and Rechargeable:** Built-in 1200mAh lithium battery with Type-C charging, weighing only 495g.
- **One-Button Operation:** Simple and intuitive brewing process.
- **Segmental Compression Principle:** Ensures stable pressure for rich coffee extraction.

3. COMPONENTS

The Ejoyous Portable Coffee Maker consists of several detachable parts for easy use and cleaning.





Coffee grounds compartment



Brewing assembly



Coffee cup

Image: Detailed view of the coffee maker's internal components, including the coffee grounds compartment, brewing assembly, and coffee cup.

Included in the Box:

- Ejoyous Portable Coffee Maker (Main Unit)
- Coffee Grounds Compartment / Filter
- Brewing Assembly
- Coffee Cup (integrated base)
- Type-C Charging Cable
- Storage Pouch
- Coffee Scoop

4. GETTING STARTED (SETUP)

Before first use, ensure the device is fully charged. The indicator light will show charging status.

Initial Setup and Charging:

1. Unpack all components from the box.
2. Connect the provided Type-C charging cable to the charging port on the coffee maker and a suitable power adapter.
3. Allow the device to charge until the indicator light signals a full charge.
4. Familiarize yourself with the detachable parts as shown in the Components section.

Your browser does not support the video tag.

Video: An official demonstration of the Ejoyous Portable Coffee Maker, showing its unboxing, assembly, and basic handling.

5. OPERATING INSTRUCTIONS

The Ejoyous Portable Coffee Maker is designed for simple, one-button operation to deliver a rich espresso experience.

mini portable coffee machine

Coffee grounds /
capsule dual use



Image: Visual guide illustrating the four easy steps for brewing coffee with the portable coffee maker.

Brewing Coffee (4 Easy Steps):

1. **Prepare Coffee:** Add either 5-6g of a coffee capsule or up to 10g of ground coffee into the appropriate capsule holder/filter.
2. **Assemble:** Install the filled capsule holder/filter into the brewing assembly, then screw the brewing assembly clockwise into the main unit.
3. **Add Hot Water:** Pour hot water (up to 92 degrees Celsius) into the water compartment, ensuring it is below the MAX line (maximum 160ml). *Note: This device does not heat water.*
4. **Extract Coffee:** Press the power button once to turn on the machine (indicator turns blue). Press the power button a second time to begin the coffee extraction process. The machine will automatically extract 50-70ml of coffee.

Dual compatible

Suitable for both capsules and coffee
grounds

You can use self ground coffee grounds to
enjoy your favorite coffee flavor



Image: The coffee maker demonstrating its dual compatibility with both coffee capsules and ground coffee.

Premium Pressure Extraction:

The Ejoyous Portable Coffee Maker utilizes a segmental compression principle to maintain stable pressure within the powder chamber. This ensures a rich and flavorful coffee extraction, producing dense oils, rich aroma, and a slightly sweet aftertaste, characteristic of a quality espresso.

Premium Pressure Extraction

Original espresso oil
One button coffee extraction
Dense oils | Rich aroma | Slightly bitter
Slightly sweet aftertaste



Image: A visual representation of the rich espresso produced by the machine's premium pressure extraction.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and longevity of your Ejoyous Portable Coffee Maker.

Fully detachable

More convenient to clean

The part is designed to detach, easy to clean.



Image: The coffee maker disassembled, showing its fully detachable parts for convenient cleaning.

Cleaning Steps:

1. After each use, disassemble the coffee maker by unscrewing the coffee cup and removing the brewing assembly and capsule holder/filter.

2. Discard used coffee grounds or capsules.
3. Rinse all detachable parts (coffee cup, brewing assembly, capsule holder/filter) under running water. Use a mild detergent if necessary.
4. Wipe the main unit with a damp cloth. **Do not immerse the main unit in water.**
5. Allow all parts to air dry completely before reassembling or storing.

7. TROUBLESHOOTING

If you encounter any issues with your Ejoyous Portable Coffee Maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Machine does not turn on.	Low battery or no charge.	Charge the device using the provided Type-C cable.
Coffee is not extracting.	Insufficient water, clogged filter, or improper assembly.	Ensure enough hot water is added. Check if the filter is clean. Reassemble all parts correctly.
Coffee tastes weak.	Too little coffee grounds/capsule, water too cold, or coarse grind.	Use recommended amount of coffee. Ensure water is hot (up to 92°C). Use a finer grind for ground coffee.
Leaking during operation.	Parts not properly sealed or damaged O-rings.	Ensure all parts are screwed on tightly and correctly. Check O-rings for damage and replace if necessary.

8. SPECIFICATIONS

Detailed technical specifications for the Ejoyous Portable Coffee Maker.





Image: Product dimensions for the Ejoyous Portable Coffee Maker.

- **Brand:** Ejoyous
- **Model Name:** Ejoyousg46xofc9zq
- **Product Dimensions:** 10.23"D x 3.54"W x 3.14"H (Approx. 26cm D x 9cm W x 8cm H)
- **Item Weight:** 1.09 pounds (Approx. 495g)
- **Coffee Input Type:** Capsule, Ground Coffee
- **Water Capacity:** Up to 160ml (Does not boil water)
- **Battery:** Built-in 1200mAh Lithium Battery
- **Charging Port:** Type-C
- **Operation Mode:** Semi-Automatic

- **Filter Type:** Microfilter

© 2024 Ejoyous. All rights reserved.

For customer support, please refer to your purchase documentation or contact the seller directly.