KiwiCo SCAL-F2470

KiwiCo Santa's Railroad Train Advent Calendar Instruction Manual

Model: SCAL-F2470

Introduction

The KiwiCo Santa's Railroad Train Advent Calendar provides a unique and engaging way to count down to Christmas. This kit includes 24 daily projects that culminate in a complete North Pole-themed train set. Each day, a new component is revealed, allowing for a gradual and exciting build-up to the holiday season. This manual provides instructions for assembly, usage, and care of your advent calendar.



Image: The complete Santa's Railroad Advent Calendar set, featuring a train, various buildings, and festive characters, with a child placing a piece.

Setup and Assembly

Follow these steps to set up your KiwiCo Santa's Railroad Train Advent Calendar. The kit is designed for ages 5 and up, promoting building and creativity.

Unboxing and Initial Preparation

1. Carefully open the main box. Inside, you will find 24 individually numbered envelopes, a supply kit, and a snowy setting background.
2. Locate the instruction sheet, which provides an overview of the daily activities and how to use the calendar.
3. Unfold the large snowy setting background. This will serve as the base for your North Pole scene.



Image: An overhead view of the fully assembled Santa's Railroad scene, including the snowy background with dimensions (36" x 12").

Daily Assembly Process

Each day from December 1st through Christmas Eve, you will open a new envelope and assemble a unique part of the train set or scene. Each envelope contains the necessary components and specific instructions for that day's build.

- **Step 1:** On the corresponding day, open the numbered envelope.
- **Step 2:** Inside each envelope, you will find the pieces for that day's project along with detailed, illustrated instructions.
- **Step 3:** Assemble the pieces according to the instructions. Some projects may require additional common household items like glue or scissors (not included).
- **Step 4:** Once assembled, add the new project to your snowy North Pole scene.



Image: A close-up of an instruction card for 'Santa's Workshop', detailing the assembly process with visual steps and required components.



Image: A partially assembled wooden Santa's workshop, showing the interior with miniature gift boxes.

Optional Display Methods

The 24 advent envelopes can be displayed in two ways:

- **Garland:** Use the provided string to create a festive garland by hooking the envelopes onto the string.
- **Stands:** If you prefer not to hang them, use the included stand pieces to display the envelopes upright.



Image: A child hanging numbered advent envelopes as a decorative garland above a fireplace, showcasing one display option.

Video Guide

Your browser does not support the video tag.

Video: An official overview of the KiwiCo Santa's Railroad Advent Calendar, demonstrating the daily build process and the final assembled scene.

Operating Instructions

The Santa's Railroad Train Advent Calendar is designed for daily engagement throughout December, leading up to Christmas. Each day's project adds to the overall scene, creating a dynamic and interactive display.

- **Daily Unveiling:** Begin on December 1st by opening the envelope labeled '1'. Continue opening one numbered

envelope each day until December 24th.

- **Creative Customization:** The kit includes art supplies. Feel free to customize your builds with colors and details as you wish.
- **Interactive Play:** Once assembled, the train set and characters can be used for imaginative play, creating stories and scenarios in your North Pole scene.



Image: A child engaging with the assembled train, tunnel, and other elements of the Santa's Railroad scene.

Maintenance and Care

To ensure the longevity of your KiwiCo Santa's Railroad Train Advent Calendar, follow these maintenance guidelines:

- **Cleaning:** Wipe components gently with a dry or slightly damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** After the holiday season, disassemble the larger structures if desired and store all components in their original packaging or a suitable container to prevent loss or damage. Keep in a dry place away from direct sunlight.
- **Handling:** Handle the wooden and paper components with care to avoid bending, tearing, or breaking.

Troubleshooting

If you encounter any issues during assembly or use, consider the following common solutions:

- **Missing Piece:** Double-check the envelope and surrounding area. If a piece is genuinely missing, contact KiwiCo customer support.
- **Difficulty Assembling:** Refer to the detailed illustrations on the instruction card for the specific day's project. Ensure all tabs and slots are aligned correctly. Some pieces may require gentle pressure to fit.
- **Loose Connections:** If pieces feel loose, a small amount of craft glue (not included) can be used to secure them, especially for permanent display.
- **Damaged Components:** If a component arrives damaged, contact KiwiCo customer support for assistance.

Specifications

Attribute	Detail
Brand	KiwiCo
Model Number	SCAL-F2470
Item Weight	3.74 pounds
Package Dimensions	12.56 x 12.32 x 4.88 inches
Batteries	3 LR44 batteries required (included)
Color	Red, Green, Blue, Yellow
Material Type	Wood
Age Range (Description)	Kid (Ages 5+)
Theme	Christmas

Warranty and Support

For information regarding product warranty, returns, or additional support, please visit the official KiwiCo website or contact their customer service directly. You can also find more products and information on the KiwiCo Amazon Store.

© 2025 KiwiCo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question