Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JoFomp 081239-LED

JoFomp 12-Inch Silent LED Night Light Wall Clock Instruction Manual

Model: 081239-LED

Introduction

Thank you for choosing the JoFomp 12-Inch Silent LED Night Light Wall Clock. This clock features a silent quartz movement, an integrated LED night light with automatic brightness adjustment, and multiple power options. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.




Figure 1: JoFomp 12-Inch Wall Clock (Unilluminated)

Package Contents

- 1 x JoFomp 12-Inch Silent LED Night Light Wall Clock
- 1 x USB Power Cable
- 1 x Instruction Manual (this document)

Note: AA batteries are not included and must be purchased separately.

Setup

1. Battery Installation

The clock requires two sets of batteries for independent functions:

- **For Clock Movement:** Insert 1 "AA" battery into the designated compartment for the timekeeping mechanism.

- **For LED Light Effect:** Insert 3 "AA" batteries into the compartment for the LED lighting. Alternatively, the LED light can be powered via the included USB cable.

Important: Avoid using high-energy alkaline batteries for the clock movement, as their high current may damage the quartz mechanism. Carbon dry batteries are recommended to extend the clock's lifespan.

2. USB Power Connection (for LED Light)

If you prefer not to use batteries for the LED light, connect the provided USB cable to the Type-C port on the back of the clock and plug the other end into a compatible USB power adapter (not included).




Figure 2: Type-C USB Port for LED Power

3. Mounting

The clock is designed for wall mounting. Use the integrated hook on the back of the clock to securely hang it on a wall nail or screw.



Figure 3: Clock Components and Rear View

Operating Instructions

1. Setting the Time

Turn the adjustment knob located on the back of the clock's movement mechanism to set the correct time. Ensure the minute and hour hands are aligned accurately.

2. LED Night Light Control

On the back of the clock, locate the slide switch for the LED light control. It has three modes:

- **OFF:** Turns off the LED light effect.
- **AUTO:** Activates the automatic light sensing feature. The LED light will turn on and adjust its brightness intelligently

based on ambient light levels.

- **ON:** Keeps the LED light on continuously, regardless of ambient light.



Figure 4: LED Light Mode Switch

3. Brightness Adjustment (in ON or AUTO mode)

When the LED light is in "ON" or "AUTO" mode, you can adjust its brightness using the "BRIGHTNESS" slider control on the back of the clock. Slide it towards "+" for increased brightness or towards "-" for decreased brightness.



Figure 5: Brightness Adjustment Slider




Figure 6: Visual Representation of Brightness Adjustment

Figure 7: Automatic Light Sensing Function

Maintenance

1. Battery Replacement

When the clock hands stop moving or the LED light dims significantly (and is not due to brightness settings or USB power), it is time to replace the batteries. Follow the battery installation steps in the Setup section.

2. Cleaning

To clean the clock, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these may damage the finish or the clock face.

Troubleshooting

- **Clock is not keeping accurate time:**
  - Ensure the "AA" battery for the clock movement is fresh and correctly installed.
  - Verify that a carbon dry battery is used for the clock movement, not an alkaline battery.
- **LED light is not turning on or is too dim:**
  - Check the 3 "AA" batteries for the LED light; ensure they are fresh and correctly installed.
  - If using USB power, ensure the USB cable is securely connected and the power adapter is functioning.
  - Verify the LED light control switch is set to "ON" or "AUTO".
  - Adjust the "BRIGHTNESS" slider to increase the light intensity.
  - If in "AUTO" mode, ensure the ambient light is low enough for the sensor to activate the LED.
- **Clock is making ticking sounds:**
  - The JoFomp wall clock features a silent quartz movement. If ticking is heard, ensure the clock is securely mounted and not vibrating against the wall. If the issue persists, contact customer support.

Specifications

Brand	JoFomp
Model Number	081239-LED
Color	Warm Light
Display Type	Analog
Special Feature	Silent Clock, LED Night Light, Auto-Dimming
Product Dimensions	12"W x 12"H
Power Source	1 x AA Battery (for clock movement), 3 x AA Batteries OR USB Cable (for LED light)
Frame Material	Plastic
Item Weight	1.94 pounds (0.88 Kilograms)



Figure 8: Quartz Movement Detail

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact JoFomp customer service directly. Contact details are typically available on the manufacturer's website or through your purchase platform.

© 2025 JoFomp. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9XSJ9GX

More documents and user manuals: **https://manuals.plus/**