

[Manuals.plus](#) /

› [Lehoo Castle](#) /

› Lehoo Castle Amphibious RC Car 1841-1 User Manual

Lehoo Castle 1841-1

Lehoo Castle Amphibious RC Car 1841-1 User Manual

Model: 1841-1

1. INTRODUCTION

The Lehoo Castle Amphibious RC Car is a versatile remote-controlled vehicle designed for operation on land and water. It features 4-wheel drive, a water gun function, and LED lights, offering multiple modes of play including RC car, RC boat, and battle mode. This manual provides essential information for safe and optimal use of your product.



Image: The Lehou Castle Amphibious RC Car demonstrating its three modes: racing as an RC car, battling as an RC tank with a water gun, and swimming as an RC boat.

2. WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- 1 x Amphibious RC Car
- 1 x Remote Control (RC)
- 2 x 1200mAh 3.7V Rechargeable Batteries
- 1 x USB Charging Cable
- 1 x Screwdriver
- 1 x Water Bottle (for filling water gun)
- 1 x Product Manual (this document)



Image: An accessory sheet displaying all included components: the amphibious stunt car, waterproof remote control, USB charging cable, screwdriver, water bottle, user manual, and two 1200mAh 3.7V rechargeable batteries.

3. SETUP

3.1. Battery Installation

Car Battery Installation:

1. Use the included screwdriver to open the battery compartment cover on the underside of the RC car.
2. Connect one of the 1200mAh 3.7V rechargeable batteries to the car's battery connector.
3. Carefully place the battery inside the compartment and close the cover, securing it with the screw.

Remote Control Battery Installation:

1. Open the battery compartment on the back of the remote control.
2. Insert 2 x 1.5V AAA batteries (not included) into the compartment, ensuring correct polarity.

3. Close the battery compartment cover.

3.2. Charging the Car Batteries

The car uses rechargeable batteries. Follow these steps to charge them:

1. Connect the 1200mAh 3.7V rechargeable battery to the USB charging cable.
2. Plug the USB charging cable into a suitable USB power source (e.g., computer, USB wall adapter).
3. The charging indicator light will show the charging status.
4. Charging typically takes approximately 3-4 hours for a full charge.
5. A low-battery indicator light on the car will flash quickly when power is low, signaling it's time to return the car for charging.



Image: A visual guide demonstrating the easy installation of the 1200mAh battery into the RC car and how to connect the battery to the USB charging cable for charging.

Video: A demonstration of the Lehou Castle Amphibious RC Car's functions, including battery installation and basic operation.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off

1. Turn on the power switch on the RC car.
2. Press the power button on the remote control to turn it on. The remote and car should automatically pair.
3. To turn off, press the power button on the remote and then turn off the switch on the car.

4.2. Remote Control Functions

GHZ 2.4 REMOTE CONTROL



Image: A detailed diagram of the 2.4GHz remote control, labeling buttons for forward/backward movement, speed adjustment (2 levels), light switch, water jet switch (single/continuous), left/right rotation, start switch, and automatic mode.

- **Forward/Backward:** Use the left joystick to move the car forward or backward.
- **Left/Right Rotation:** Use the right joystick to rotate the car left or right.
- **Speed Adjustment:** Press the speed adjustment button (2 levels) to change the driving speed.
- **Light Switch:** Toggle the light switch to turn the LED lights on or off.
- **Water Jet Switch:** Press this button to activate the water gun. It supports both single shot and continuous spray modes.
- **Start Switch:** Main power button for the remote.
- **Automatic Mode:** Activates a pre-programmed demonstration sequence.

4.3. Driving on Land and Water

The RC car is designed for all-terrain use. It can drive on various surfaces including land, grass, and even snow, and operates as a boat in water.

- **Land Mode:** Use the remote control to navigate the car on flat surfaces or rough terrain.

- **Water Mode:** The waterproof design allows the car to glide across water in pools, lakes, or beaches. Ensure all battery compartments are securely closed before entering water.



Image: A collage showcasing the Lehou Castle Amphibious RC Car's ability to operate as an all-terrain vehicle, driving on grass, pavement, and in water, highlighting its versatility.

4.4. Water Gun Operation

The RC car features a dual-mode water gun for interactive fun.

1. **Onboard Tank Mode (for land play):** Fill the included water bottle with water and install it into the designated water tank on the car. Use the water jet switch on the remote to spray water up to 15-30 ft.
2. **Self-Absorbing Mode (for water play):** When in water, the car can absorb water directly from its surroundings through a bottom pumping hole. Ensure the sealing cap on the bottom is open and the filter plug is on. This allows for continuous water spraying without refilling.



Image: The Lehou Castle Amphibious RC Car demonstrating its water blasting action, showing the range of the water gun on land.



Image: A visual guide explaining the two methods of water pumping: using the onboard water container for land play and the self-absorbing bottom hole for water play.

Video: A demonstration of the Lehou Castle Amphibious RC Car's water gun feature, showcasing its use for summer fun.

4.5. Stunts and LED Lights

- The car can perform 360° spins and other stunts with ease due to its design.
- Bright LED lights enhance visibility and add to the visual appeal, especially during night play.



Image: The Lehou Castle Amphibious RC Car showcasing its dazzling LED lights while operating in water, creating a thrilling visual effect.

5. MAINTENANCE

- After use, especially in water, wipe the car clean with a dry cloth to remove any residue.
- Ensure all battery compartments are dry before storing.
- Store the car and remote control in a cool, dry place away from direct sunlight.
- Remove batteries from the remote control if not in use for an extended period to prevent leakage.
- Regularly check for any loose parts or damage. Do not operate if damaged.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Car does not respond to remote.	Low battery in car or remote; not paired; interference.	Charge car battery; replace remote batteries; re-pair car and remote; move to an area with less interference.
Water gun not spraying.	No water in tank/filter blocked; low car battery.	Refill water tank or ensure car is in water for self-absorbing mode; check for blockages in the water intake/nozzle; charge car battery.
Short playtime.	Battery not fully charged; old battery.	Ensure batteries are fully charged (3-4 hours); consider replacing old batteries if performance degrades significantly.
Car moves slowly or erratically.	Low car battery; obstruction in wheels.	Charge car battery; check wheels for debris and clear them.

7. SPECIFICATIONS

- **Brand:** Lehou Castle
- **Model Name:** Amphibious RC Car
- **Model Number:** 1841-1
- **Material:** Plastic
- **Color:** Black
- **Power Source:** Battery Powered
- **Car Battery:** 2 x 1200mAh 3.7V Lithium-Ion (included)
- **Remote Control Battery:** 2 x 1.5V AAA (not included)
- **Charging Time:** Approximately 3-4 hours
- **Playtime:** Up to 120 minutes (with dual batteries)
- **Control Frequency:** 2.4 GHz
- **Control Range (Land):** Up to 131 ft (40 meters)
- **Control Range (Water):** Up to 98 ft (30 meters)
- **Water Gun Spray Range:** 15-30 ft (4.5-9 meters)
- **Features:** 3-in-1 (Land, Water, Battle), 4WD, Waterproof, 360° Stunts, LED Lights, Water Gun
- **Item Weight:** 0.76 Kilograms
- **Item Dimensions:** 6.2 x 5.5 x 7 inches
- **Recommended Age:** 6-12 years (Manufacturer Minimum Age: 72 months, Maximum Age: 144 months)
- **Indoor/Outdoor Usage:** Outdoor

8. SAFETY INFORMATION

No specific safety warnings are provided beyond general toy safety. Please observe the following general safety guidelines:

- Adult supervision is recommended, especially for younger children.
- Do not aim the water gun at eyes or face.
- Keep away from electrical hazards.
- Do not modify the product.

- Ensure all battery compartments are sealed before water play.
- Dispose of batteries responsibly according to local regulations.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or contact Lehou Castle customer service directly. Keep your purchase receipt for any warranty claims.

© 2026 Lehou Castle. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question