

- › [Best Choice Products](#) /
- › [Best Choice Products Kids' Outdoor Wooden Sandbox with Foldable Bench Seats - Instruction Manual for Model SKY7685](#)

Best Choice Products SKY7685

Best Choice Products Kids' Outdoor Wooden Sandbox with Foldable Bench Seats - Instruction Manual

Model: SKY7685

PRODUCT OVERVIEW

The Best Choice Products Kids' Outdoor Wooden Sandbox is designed for children aged 3 years and up, providing a dedicated space for sand play. This large sandbox features durable cedar wood construction, foldable bench seats that convert into a protective cover, and an included bottom liner for drainage and ventilation. Its design aims to offer a safe and engaging outdoor activity area while ensuring the sand remains clean and protected when not in use.



Image: The Best Choice Products Kids' Outdoor Wooden Sandbox, shown in Espresso, filled with sand and various colorful sand toys, highlighting its spacious design and integrated benches.

SAFETY INFORMATION

- Not for children under 3 years old.
- Adult supervision is recommended during play.
- Ensure the sandbox is placed on a level surface to prevent distortion and stress on joints.
- Regularly inspect the sandbox for loose screws, splinters, or damaged parts. Tighten screws as needed.
- Use play-grade sand only (sold separately).

WHAT'S IN THE BOX

- Sandbox wooden panels and components
- Hardware for assembly
- Bottom liner
- Assembly Guide

SETUP AND ASSEMBLY

Assembly is required for this product. Follow the included Assembly Guide carefully. It is recommended to have at least two adults for efficient assembly. Ensure all parts are present before beginning. Avoid over-tightening screws to prevent wood splitting.

1. **Prepare the Area:** Choose a level outdoor surface for placement. Clear any debris or uneven ground.
2. **Assemble the Base:** Follow the step-by-step instructions in the Assembly Guide to construct the main sandbox frame.
3. **Install the Bottom Liner:** Place the included liner inside the assembled frame. This liner facilitates drainage and ventilation, and helps contain the sand.
4. **Attach Bench Components:** Secure the foldable bench seats according to the instructions. These benches will also serve as the sandbox cover.
5. **Fill with Sand:** Once assembled, fill the sandbox with play-grade sand (sold separately). The sandbox can hold a significant amount of sand; adjust depth as desired.

COMFORTABLE SEATING

✓ Backrests included

✓ Seats Up to 220 lbs.
Per Bench

✓ Seats Up to 4



Image: A detailed view of the sandbox's built-in benches, showing their sturdy construction and reinforced backrests, designed for comfortable seating.

SEATS CONVERT TO COVER

Designed with 2 sturdy bench seats that fold down to serve as a split sandbox cover

PROTECTS AGAINST



Weather



Animals



Debris



Image: The sandbox with its two bench seats folded inward, demonstrating how they convert into a split cover to protect the sand from weather, animals, and debris.



Bottom Liner

OPEN BOTTOM WITH LINER

The bottomless construction facilitates drainage, ventilation, and adjustment of sand depth

Image: An interior view of the sandbox, showing the open bottom design and the included black liner, which aids in drainage and sand depth management.

OPERATING INSTRUCTIONS

- **Opening the Sandbox:** To open, gently lift each side of the cover (which are the folded benches) outwards until they form upright benches. Ensure they are securely in place before children begin to play.
- **Using the Benches:** The built-in benches provide seating for children or adults, with a weight capacity of up to 220 lbs per bench.
- **Closing the Sandbox:** To close, carefully fold each bench inwards until they meet in the middle, forming a complete cover over the sand. This protects the sand from external elements and animals.

No official product videos from the seller were available for embedding based on the provided criteria.

MAINTENANCE

- **Wood Care:** The cedar wood is heat-treated to resist damage and wear. To prolong its lifespan, consider applying a weather-resistant sealant annually, especially if exposed to harsh weather conditions.
- **Cleaning:** Periodically clean the wood surfaces with a damp cloth. Ensure sand is free from debris before closing the cover.
- **Sand Maintenance:** Regularly rake and aerate the sand to keep it fresh and prevent compaction. Replace sand as needed.
- **Winter Storage:** In regions with severe winters, it is advisable to cover the sandbox with a heavy-duty tarp or store it indoors to protect the wood and sand.

TROUBLESHOOTING

- **Loose Hinges/Screws:** If benches become wobbly or hinges appear loose, tighten all screws. If wood is stripped, consider using wood glue or larger screws for reinforcement.
- **Wood Warping/Splitting:** Ensure the sandbox is on a level surface. Apply wood sealant to protect against moisture and temperature changes.
- **Sand Contamination:** Always close the sandbox cover when not in use to prevent animals, leaves, and debris from entering.

SPECIFICATIONS

- **Product Dimensions:** 47.25"(L) x 47"(W) x 8.5"(H)
- **Item Weight:** 32.5 pounds
- **Material:** Cedar Wood
- **Bench Weight Capacity:** 220 lbs (each)
- **Recommended Age:** 3 years and up
- **Model Number:** SKY7685







PRODUCT DIMENSIONS



Image: A diagram illustrating the overall dimensions of the sandbox, including length, width, and height, both in its open and closed configurations.

WARRANTY AND SUPPORT

For warranty information, replacement parts, or customer support, please refer to the contact details provided in your original purchase documentation or visit the official Best Choice Products website. Keep your proof of purchase for any warranty claims.

	<p>Best Choice Products Foldable Wooden Adirondack Chair Assembly Instructions</p> <p>Comprehensive instruction manual for assembling the Best Choice Products SKY2253 Foldable Wooden Adirondack Chair. Includes parts list, tools required, hardware details, step-by-step assembly guide, safety notices, and warranty information.</p>
	<p>Best Choice Products Pretend Play Corner Kitchen Wooden Toy Set - SKY6910, 6911, 6912</p> <p>Overview of parts and components for the Best Choice Products Pretend Play Corner Kitchen Wooden Toy Set, models SKY6910, SKY6911, and SKY6912. This document outlines the various numbered parts and lettered components that make up the toy kitchen.</p>
	<p>Best Choice Products Kitchen Playset Instruction Manual</p> <p>Comprehensive assembly instructions and product information for the Best Choice Products Kitchen Playset. Includes safety warnings, parts list, hardware details, and assembly steps.</p>
	<p>Best Choice Products 6V Kids Ride-On Truck Instruction Manual</p> <p>Comprehensive instruction manual for the Best Choice Products 6V Kids Ride-On Truck, covering assembly, safety, specifications, charging, and troubleshooting. Includes model numbers SKY6794 through SKY6805.</p>
	<p>Best Choice Products 6V Kids Ride-On Truck Instruction Manual</p> <p>Comprehensive instruction manual for the Best Choice Products 6V Kids Ride-On Truck, covering assembly, safety, operation, charging, and troubleshooting. Features model numbers SKY6794-SKY6805.</p>
	<p>Best Choice Products Kids Electric Guitar Play Set Instruction Manual</p> <p>Official instruction manual for the Best Choice Products Kids Electric Guitar Play Set (SKY3017, SKY3018, SKY7142, SKY7143). Learn how to set up, operate, and maintain your toy guitar, amplifier, and microphone.</p>