KNQZE KH1

KNQZE Hand Massager KH1 User Manual

Model: KH1

Introduction

Thank you for choosing the KNQZE Hand Massager KH1. This device is designed to provide a comprehensive hand massage experience, incorporating heat, compression, kneading, and fan cooling functions. It aims to alleviate hand fatigue, stiffness, and discomfort. Please read this manual thoroughly before use to ensure proper operation and to maximize your experience with the product.



Image: The KNQZE Hand Massager KH1 in purple, with a hand inserted into the massage chamber, displaying its digital interface.

Important Safety Instructions

To reduce the risk of electric shock, burns, fire, or injury, please observe the following safety precautions:

- Always follow the instructions provided with the massager.
- Do not use the massager while sleeping or in the presence of flammable materials.
- Keep the massager away from water and moisture.
- To deflate, twist the safety device on the back of the massager. Do not forcefully inflate or deflate the massager.
- Charge the massager on a flat, stable surface and do not leave it unattended while charging.
- If the massager becomes hot during use, stop using it immediately and contact customer service.
- This device is not intended for medical use. Consult a physician before use if you have any pre-existing medical conditions.

Product Components

The KNQZE Hand Massager KH1 includes:

- KNQZE Hand Massager Unit
- USB Charging Cable (Type-C)
- User Manual

Getting Started (Setup)

1. Charging the Device

Before first use, fully charge the hand massager. A full charge takes approximately 2.5 hours and provides up to 2 hours of running time.

1. Connect the provided USB Type-C cable to the charging port on the massager.
2. Connect the other end of the USB cable to a compatible DC 5V/2A power adapter (not included) or a computer USB port.
3. The battery indicator on the display will show charging status. Once fully charged, the indicator will show a full battery icon.



Image: The KNQZE Hand Massager KH1 being charged via a USB cable connected to a laptop, illustrating its cordless and portable design.

2. Placing Your Hand

Insert your hand into the massage chamber, ensuring your palm and fingers are comfortably positioned. The adjustable wrist strap can be used to secure your wrist for optimal wrist massage.



Image: A hand inserted into the massager, highlighting the adjustable wrist strap for a secure and comfortable fit.

Operating the Massager

The KNQZE Hand Massager features an intuitive touch screen for easy operation.



Image: A detailed view of the massager's touch screen, showing icons for modes, intensity, heat, cooling, and timer settings.

1. Power On/Off

- Press the **Power Button** (usually a circular button) to turn the massager on.
- Press and hold the **Power Button** again to turn the massager off.

2. Selecting Massage Modes

The massager offers 6 distinct massage modes. Press the **Mode Indicator** button (often labeled 'M') on the touch screen to cycle through the available modes:

1. **Auto Massage**
2. **Circular Massage**
3. **Soothing Massage**
4. **With Kneading Massage**
5. **Hand Massage**
6. **Palm & Wrist Massage**



Image: A visual guide to the 6 intensity levels (Low, Mid, Deep) and 6 massage modes available on the device.

3. Adjusting Intensity Levels

There are 6 massage intensity levels. Press the**Intensity Indicator** button (often represented by vertical bars) to adjust the compression strength:

- Levels 1-2: Low Intensity (Soft Massage)
- Levels 3-4: Mid Intensity (Relaxing Massage)
- Levels 5-6: High Intensity (Deep Massage)

4. Using Heat Function

The massager includes an adjustable heating function with two levels:

- Press the **Heat Button** (often represented by wavy lines or a temperature icon) to activate the low heat setting (approximately 107.4°F).
- Press again for the high heat setting (approximately 118.6°F).
- Press a third time to turn the heat function off.



Image: An illustration demonstrating the two adjustable heating levels (Low and High) within the massager.

5. Using Cooling Fan

The built-in fan provides a cooling function for comfort, especially in warmer environments.

- Press the **Fan Cooling Button** (often represented by a fan icon) to activate the cooling function.
- Press again to turn the cooling function off.



Image: An illustration depicting the internal fan cooling mechanism, showing airflow within the massager for a dry and comfortable experience.

6. Setting the Timer

The massager features an auto-stop timer to prevent overuse and conserve battery life.

- Press the **Timer Button** (often represented by a clock icon) to select from 10, 15, or 20-minute massage sessions.
- The device will automatically shut off once the selected time has elapsed.



Image: The hand massager displaying its auto-stop timer function, with options for 15, 20, and 30-minute sessions.

7. Deflation Mechanism

A safety device on the back of the hand massager allows for easy deflation. In case you need to quickly release pressure or remove your hand, simply twist this device.

Care and Maintenance

- **Cleaning:** Disconnect the massager from the power source before cleaning. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the massager in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

Troubleshooting

If you encounter any issues with your KNQZE Hand Massager, please refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. If the battery is low, connect it to a power source using the provided USB cable.
- **No compression or kneading:** Check that your hand is properly inserted and that a massage mode is selected. Ensure the intensity level is not set to zero.
- **Heat function not working:** Verify that the heat function is activated on the touch screen. Allow a few minutes for the heating elements to warm up.
- **Unusual noise:** If you hear any abnormal noises, turn off the device immediately and contact customer support.
- **Device becomes hot:** Stop use immediately and allow the device to cool down. If the issue persists, contact customer support.

Product Specifications

Brand	KNQZE
Model Number	KH1
Product Dimensions	10.8 x 6.7 x 5.1 inches
Weight	3.7 Pounds
Power Source	Battery Powered (1 Lithium Ion battery included)
Battery Capacity	3000mAh
Charging Time	Approx. 2.5 hours
Running Time	Approx. 2 hours
Material	Plastic
Color	Purple

Warranty Information

KNQZE massagers come with a 1-year warranty. This warranty covers manufacturing defects and malfunctions under normal use. Free replacement is offered for any damage within one year from the date of purchase. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, concerns, or technical assistance, please contact KNQZE customer support. Refer to the product packaging or the official KNQZE website for the most current contact information.

© 2025 KNQZE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question