

SHARK FlexBreeze

Shark FlexBreeze Pedestal & Tabletop Fan User Manual

Model: FlexBreeze (732388811236)

INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your Shark FlexBreeze Pedestal & Tabletop Fan. The FlexBreeze fan is designed for versatile use, functioning as both a pedestal and tabletop fan, suitable for indoor and outdoor environments. It offers corded and cordless operation, powerful airflow, and quiet performance.

Please read this manual thoroughly before initial use and retain it for future reference.

PRODUCT FEATURES

- **Dual Functionality:** Easily transforms between pedestal and tabletop fan configurations.
- **Corded & Cordless Operation:** Provides continuous power when plugged in or up to 24 hours of cordless runtime on a single charge (based on fan speed 1, no oscillation).
- **BreezeBoost Mode:** Delivers powerful airflow, detectable from over 70 feet away.
- **Adjustable Settings:** Features 5 fan speeds, 180 degrees of side-to-side oscillation, and a 55-degree up-and-down tilt.
- **Remote Control:** Includes a magnetic remote for convenient operation, which docks on the fan.
- **Durable Design:** UV and water-resistant for outdoor use.
- **Quiet Operation:** Engineered for quiet performance, even at higher speeds.
- **Lightweight:** Weighs approximately 13 lbs for easy portability.

Get to know the Shark FlexBreeze™ High-Velocity Cordless & Corded Fan



Figure 1: Overview of Shark FlexBreeze fan components and features, including BreezeBoost, control panel, transformation mechanism, remote, and corded/cordless options.

SETUP

Unpacking

Carefully remove all components from the packaging. Ensure all parts listed in the packing contents are present. Retain packaging for storage or if return is necessary.

Assembly and Transformation

The Shark FlexBreeze fan can be configured as a pedestal fan or a tabletop fan. The transformation process is designed for ease of use.

1. Pedestal Fan Assembly:

- Attach the fan head to the pedestal pole.
- Secure the pedestal pole to the base.

2. Tabletop Fan Transformation:

- To convert from pedestal to tabletop mode, press the release button located on the fan head where it

connects to the pole.

- Lift the fan head off the pedestal pole.
- Attach the tabletop stand (if not already attached) to the bottom of the fan head.



Figure 2: Visual guide demonstrating the transformation of the fan from pedestal to tabletop configuration.



Figure 3: The Shark FlexBreeze fan shown in both its full-height pedestal and compact tabletop configurations.

OPERATING INSTRUCTIONS

Powering On/Off

Press the power button on the fan's control panel or the remote control to turn the fan on or off.

Fan Speed Adjustment

The fan offers 5 speed settings. Use the speed control buttons on the fan or remote to cycle through the available speeds. The LED display will indicate the current speed.

Oscillation Control

Press the oscillation button on the fan or remote to activate or deactivate the 180-degree side-to-side oscillation feature. This distributes airflow across a wider area.

Tilt Adjustment

Manually adjust the fan head's vertical angle up to 55 degrees to direct airflow precisely where needed.

BreezeBoost Mode

To activate BreezeBoost mode, hold down the fan icon button on the control panel. This mode provides an ultra-powerful breeze, effective from over 70 feet away.



Figure 4: The fan demonstrating its powerful airflow, capable of reaching over 70 feet in BreezeBoost mode.

Corded and Cordless Use

The fan can operate continuously when plugged into a power outlet. For cordless operation, ensure the internal battery is charged. A full charge provides up to 24 hours of runtime on the lowest speed setting without oscillation. The fan can also operate while charging.



Up to 24 hours of cordless runtime*.

Go cordless and bring serious power to any setting,
from patio to poolside.

*Based on fan speed 1, no oscillation.

Figure 5: The fan providing cooling comfort in an outdoor setting, highlighting its cordless capability.

Remote Control

The included remote control allows for convenient adjustment of power, speed, and oscillation from a distance. The remote features a magnetic backing for secure storage on the fan itself.



Keep your cool with full control

Want to customize your comfort? Grab the magnetic remote and take control from a distance.

Figure 6: The remote control for the Shark FlexBreeze fan, enabling convenient adjustments from a distance.

MAINTENANCE

Cleaning

- Always unplug the fan before cleaning.
- Use a soft, damp cloth to wipe down the exterior surfaces of the fan.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the fan's finish.
- For dust accumulation on the fan blades or grille, use a vacuum cleaner with a brush attachment or compressed air.
- Ensure the fan is completely dry before plugging it back in or operating it.

Storage

When not in use for extended periods, store the fan in its original packaging or a protective cover in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your Shark FlexBreeze fan, please refer to the following common solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply; battery depleted; power button not pressed.	Ensure the fan is plugged in securely or the battery is charged. Press the power button firmly.
Remote control not working.	Depleted battery in remote; obstruction; remote out of range.	Replace the remote control battery. Ensure no obstructions between remote and fan. Operate within effective range.
Reduced airflow.	Fan grille or blades are dirty; fan speed set too low.	Clean the fan grille and blades as described in the Maintenance section. Increase the fan speed setting.
Fan makes unusual noise.	Obstruction in fan blades; loose component.	Unplug the fan and check for any obstructions in the blades. If noise persists, contact customer support.

SPECIFICATIONS

Brand: SHARK

Model Name: Shark FlexBreeze

Item Model Number: 732388811236

Color: White

Electric Fan Design: Table Fan (convertible to Pedestal)

Power Source: AC/DC (Corded & Cordless)

Room Type: Bedroom, Dining Room, Kitchen, Living Room (Indoor/Outdoor)

Special Features: Adjustable Height, Adjustable Tilt, Water Resistant, Portable, Remote Controlled

Finish Type: Painted

Item Weight: 12.2 Pounds

Included Components: FlexBreeze Fan, Remote Control

Control Method: Remote, Touch

Number of Power Levels: 5

Manufacturer: SharkNinja

Product Dimensions: 13.77 x 13.77 x 37 inches (Pedestal configuration)

UPC: 732388811236

Date First Available: July 23, 2024

WARRANTY INFORMATION

Specific warranty details for the Shark FlexBreeze fan are typically provided with your product purchase or can be found on the official SharkNinja website. Please refer to the documentation included in your product packaging for the most accurate and up-to-date warranty terms and conditions.

SUPPORT

For further assistance, product registration, or to purchase replacement parts, please visit the official

SharkNinja website or contact their customer service department. Contact information can usually be found on the product packaging or the manufacturer's website.