

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Edifier](#) /

› [Edifier W800BT SE Wireless Over-Ear Bluetooth Headphones User Manual](#)

## Edifier W800BT SE

# Edifier W800BT SE Wireless Over-Ear Bluetooth Headphones User Manual

Model: W800BT SE

## INTRODUCTION

Thank you for choosing the Edifier W800BT SE Wireless Over-Ear Bluetooth Headphones. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your headphones to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.



Image: Edifier W800BT SE Wireless Over-Ear Bluetooth Headphones, showcasing the sleek white design.

## PACKAGE CONTENTS

Please check the contents of your package to ensure all items are present:

- Headset x 1
- Type-C Cable x 1
- User Manual x 1

## PRODUCT OVERVIEW AND CONTROLS

Familiarize yourself with the various parts and controls of your Edifier W800BT SE headphones.




Image: Detailed diagram illustrating the control buttons and ports on the Edifier W800BT SE headphones, including volume, play/pause, track skip, mode switch, and USB-C port.

### Control Functions:

- **Single press (Volume Up):** Increases volume.
- **Press and hold (Next Track):** Skips to the next audio track.
- **Single press (Play/Pause):** Plays or pauses audio.
- **Single press (Answer/End Call):** Manages phone calls.
- **Double press (Reject Call):** Declines an incoming call.
- **Triple press (Voice Assistant):** Activates your device's voice assistant.
- **Single press (Volume Down):** Decreases volume.
- **Press and hold (Previous Track):** Skips to the previous audio track.
- **Single press (Mode Switch):** Toggles between Music mode, Game mode, and Theatre mode.

## SETUP

### 1. Charging the Headphones

Before first use, fully charge your headphones. Connect the provided USB Type-C cable to the charging port on the headphones and the other end to a USB power adapter (not included) or a computer's USB port. The indicator light will show charging status.



Image: A user connecting the USB-C charging cable to the Edifier W800BT SE headphones. The headphones feature a USB-C port for convenient charging.

A 15-minute charge provides approximately 8 hours of playback, and a full charge offers up to 45 hours of continuous use.

## 2. Powering On/Off

- **Power On:** Press and hold the power button for approximately 3 seconds until the indicator light flashes.
- **Power Off:** Press and hold the power button for approximately 3 seconds until the indicator light turns off.

## 3. Bluetooth Pairing

The headphones support Bluetooth 5.4 for fast and stable connections.




Image: An illustration of the Bluetooth 5.4 chip, highlighting the advanced connectivity technology within the headphones.

- **Initial Pairing:**

1. With the headphones powered off, press and hold the power button for 5 seconds until the indicator light flashes red and blue alternately. This indicates pairing mode.
2. On your device (smartphone, laptop, etc.), enable Bluetooth and search for "EDIFIER W800BT SE" in the list of available devices.
3. Select "EDIFIER W800BT SE" to connect. Once connected, the indicator light will flash blue slowly.

- **Multipoint Connection:**

The W800BT SE supports connecting to two Bluetooth devices simultaneously. This allows you to seamlessly switch between audio sources, for example, from music on your laptop to a call on your phone.



Image: Illustration showing the Edifier W800BT SE headphones connected simultaneously to a smartphone and a laptop, demonstrating the multipoint connection feature.

1. Connect the headphones to the first device as described above.
2. Disconnect the headphones from the first device (or turn off Bluetooth on the first device). The headphones will re-enter pairing mode.
3. Connect the headphones to the second device.
4. Reconnect the headphones to the first device from its Bluetooth settings. The headphones will now be connected to both devices.

## 4. EDIFIER ConneX App

Enhance your experience by downloading the EDIFIER ConneX app from your device's app store. The app provides additional functions such as personalized control settings, preset EQ options, custom EQ adjustments, scheduling power off, and a "Find Your Product" feature.



Image: Screenshots of the EDIFIER ConneX mobile application, showing options for preset EQ, custom EQ, scheduled power off, and product location features.

## OPERATING INSTRUCTIONS

### 1. Audio Playback

- Use the volume up/down buttons to adjust audio levels.
- Press the multi-function button once to play or pause music.
- Press and hold the volume up button for the next track, and the volume down button for the previous track.

### 2. Call Management

The headphones feature AI Call Noise Reduction for clear conversations.

Image: A person wearing Edifier W800BT SE headphones while on a phone call, illustrating the AI Call Noise Reduction feature that separates voice from background noise.

- **Answer/End Call:** Single press the multi-function button.
- **Reject Call:** Double press the multi-function button.

### 3. Game Mode

Activate Game Mode for ultra-low latency (0.06s) and enhanced sound effects, providing perfect audio-visual synchronization for an immersive gaming experience.



Image: A person enjoying a mobile game while wearing Edifier W800BT SE headphones, highlighting the ultra-low latency (0.06s) for synchronized audio and visuals.

- **Activate Game Mode:** Single press the mode switch button until you hear the "Game Mode" prompt.
- **Switch Modes:** Continue pressing the mode switch button to cycle through Music mode, Game mode, and Theatre mode.

### MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your headphones.

- **Cleaning:**  
Wipe the headphones with a soft, dry cloth. Do not use abrasive cleaners, alcohol, or chemical solvents. Avoid getting moisture into any openings.
- **Storage:**  
When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. The foldable design allows for compact storage.
- **Battery Care:**  
To preserve battery life, avoid fully discharging the headphones frequently. If storing for an extended period, charge them to about 50% every few months.

### TROUBLESHOOTING

If you encounter any issues with your Edifier W800BT SE headphones, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from headphones	Headphones not powered on; Not paired; Volume too low; Device not playing audio.	Ensure headphones are powered on. Re-pair with your device. Increase headphone and device volume. Check audio playback on your device.
Cannot pair with device	Headphones not in pairing mode; Device Bluetooth off; Too far from device.	Ensure headphones are in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Move headphones closer to the device (within 10 meters).
Intermittent connection/audio drops	Interference; Too far from device; Low battery.	Move away from sources of interference (Wi-Fi routers, other Bluetooth devices). Reduce distance between headphones and device. Charge the headphones.
Microphone not working during calls	Microphone muted on device; App permissions; Poor signal.	Check microphone settings on your device. Ensure the app has microphone permissions. Move to an area with better signal.
Headphones not charging	Cable faulty; Power source issue; Charging port dirty.	Try a different USB-C cable and power source. Gently clean the charging port.

## SPECIFICATIONS

Detailed technical specifications for the Edifier W800BT SE Wireless Over-Ear Bluetooth Headphones:

**Model Name:** W800BT SE

**Connectivity Technology:** Wireless (Bluetooth)

**Wireless Communication Technology:** Bluetooth 5.4

**Audio Driver Type:** 40mm Dynamic Driver

**Battery Life:** Up to 45 Hours

**Fast Charging:** 15 minutes charge for 8 hours playback

**Bluetooth Range:** 10 Meters (33 feet)

**Control Method:** Buttons, App (EDIFIER ConneX)

**Earpiece Shape:** Round

**Form Factor:** Over Ear

**Headphones Jack:** USB-C (for charging)

**Item Weight:** 300 Grams (10.6 ounces)

**Product Dimensions:** 3.35 x 3.15 x 3.35 inches

**Compatible Devices:** Smartphones, Laptops, Tablets, Smart Speakers, Televisions, Gaming Consoles

**Special Features:** AI Call Noise Cancellation, Multipoint Connection, Game Mode (0.06s low latency), Foldable Design

**Manufacturer:** Edifier

**Country of Origin:** China

**Color:** White (for this specific model)

## WARRANTY AND SUPPORT


Edifier products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please visit the official Edifier website or contact their customer service directly.

**Official Edifier Website:** [www.edifier.com](http://www.edifier.com)

Please retain your proof of purchase for warranty claims.

© 2025 Edifier. All rights reserved.

### Related Documents - W800BT SE



#### [Edifier W800BT Pro Wireless ANC Headphones User Manual](#)

Comprehensive user manual for the Edifier W800BT Pro Wireless Over-Ear Headphones with Active Noise Cancellation. Learn about setup, pairing, controls, charging, and compliance information.

[EDIFIER W800BT Pro Wireless Over-Ear Headphones with Active Noise Cancellation - User](#)



W800BT Pro  
Wireless Over-Ear Headphones with Active Noise Cancellation  
Model: TDHSR W800BT Pro

— Manual — BC

EN 1. Power ON/OFF



Press and hold the power button to power on/off.

2. First pairing



1. Once powered on, the headphones will automatically enter Bluetooth pairing mode.  
2. Select 'TDHSR W800BT Pro' in your device setting to connect.

3. Pairing for new device



1. In ON state, press and hold the **1** button for about 3 seconds to enter pairing mode.

2. Select 'TDHSR W800BT Pro' in your device setting to connect.

4. Dual-device connection



1. Pair device A with device B successfully.  
2. Press and hold the **1** button for 3 seconds to enter Bluetooth pairing mode for device B.  
3. Select 'TDHSR W800BT Pro' in device B setting to connect.  
4. Device A and device B are connected via the dual-device connection is done.

5. Charging




Connect the headphones to a power source via the USB-C cable for charging.  
Input: 5V = 1A.

6. Controls

• Call



• Music



7. Reset



1. In ON state, press the **1** button 5 times to finish reset.  
2. The headphones will automatically enter Bluetooth pairing mode if successful.

8. Wired listening



Connect to the headphones via the USB-C cable. Wired listening will automatically disable Bluetooth mode.

## Manual

User manual for the EDIFIER W800BT Pro wireless over-ear headphones. Learn how to power on/off, pair devices (including dual-device connection), charge, use controls, reset, and switch to wired listening mode. Features active noise cancellation.



## [Edifier W800BT Pro Wireless Headphones User Manual](#)

User manual for the Edifier W800BT Pro Wireless Over-Ear Headphones with Active Noise Cancellation, covering power, pairing, dual-device connection, charging, controls, reset, and wired listening.



### [Edifier W800BT Pro Wireless Over-Ear Headphones User Manual](#)

Comprehensive user manual for the Edifier W800BT Pro wireless over-ear headphones with active noise cancellation. Learn about setup, pairing, controls, charging, wired listening, and compliance information.



### [Edifier W800BT SE Wireless Over-Ear Headphones User Manual](#)

This user manual provides comprehensive instructions for the Edifier W800BT SE wireless over-ear headphones. It covers unboxing, setup, Bluetooth pairing, multipoint connection, device controls, charging, wired listening, and important compliance and safety information.

### [Edifier W80 Wireless Noise Cancelling Over-Ear Headphones User Manual](#)

User manual for the Edifier W80 wireless noise-cancelling over-ear headphones, covering power on/off, Bluetooth pairing, call and music controls, volume adjustment, mode selection, multipoint connection, wired listening, resetting the device, and charging instructions.

 EDIFIER



W80

Wireless Noise Cancelling Open-Ear Headphones

Model EDIFIER W80

— Manual — 

EN 1. Power ON/OFF



Press and hold the power button to power on/off.

2. First pairing



- 1 Once powered on, the headphones will automatically enter Bluetooth pairing mode.
- 2 Select "EDIFIER W80" from your device list to connect.

3. Pairing for new device



- 1 In ON state, press and hold the "i" button for about 3 seconds to enter Bluetooth pairing mode.
- 2 Select "EDIFIER W80" from your device list to connect.

4. Controls

• Call



• Music



• Mode



5. Multipoint connection



6. Wired listening




Connect the AUX audio cable to the headphones.  
The wireless connection will automatically switch to Bluetooth mode.

7. Reset



- 1 In ON state, press the "i" and "v" buttons for 5 seconds, LED will turn white and the device will connect.
- 2 Then the headphones will automatically enter Bluetooth pairing mode.

8. Charging



Connect the headphones to a power source via the USB-C cable for charging.  
Note: You can use the USB-C port to connect to the laptop for charging.