

TSG001

Generic TSG001 Corner Floor TV Stand User Manual

Model: TSG001

INTRODUCTION

Thank you for choosing the Generic TSG001 Corner Floor TV Stand. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your new TV stand. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION AND IMPORTANT NOTES

- **VESA, Weight, and Size Compatibility:** Before purchasing or assembling, confirm that your television's VESA mounting pattern, weight, and size specifications are compatible with this stand.
- **Weight Limit:** The TV stand is designed to support televisions weighing less than 110 lbs (50 kg). Exceeding this weight limit may result in instability and damage.
- **VESA Standard:** Ensure your TV has four mounting holes on the back that match one of the following VESA patterns: 600x400mm, 600x200mm, 400x400mm, 400x300mm, 400x200mm, 300x300mm, 300x200mm, 200x200mm, 200x100mm, or 100x100mm.
- **TV Size:** This bracket is suitable for flat or curved screen TVs with a diagonal size between 32 inches and 65 inches.
- **Stability:** Always ensure the stand is placed on a stable, level surface. The adjustable feet can help maintain stability on uneven floors.
- **Children and Pets:** Keep children and pets away from the stand during assembly. Do not allow children to climb on the stand or shelves.
- **Overloading Shelves:** Do not overload the glass shelves. Distribute weight evenly.

PACKAGE CONTENTS

Please verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support.

- TV Stand Frame (Metal components)
- 3 x Tempered Glass Shelves
- TV Mounting Bracket (Swivel mechanism)
- All necessary assembly hardware (screws, washers, nuts, etc.)
- Tools for assembly (usually an Allen wrench or similar)
- Instruction Manual

2020 NEW Arrival Smart Choice

Large size, Thickened steel plate



- Fits TV Size 32"-65"
- VESA 600x400mm
- Supports TV up to 110 LBS

Image: Overview of the Generic TSG001 Corner Floor TV Stand, showing its main components including the TV mount, central column, and three glass shelves.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Generic TSG001 TV Stand is designed to be straightforward. Follow these steps carefully.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a soft, clean surface to prevent scratches. Identify each part using the provided parts list.
2. **Assemble the Base Frame:** Connect the metal frame components to form the base structure. Ensure all screws are tightened securely but do not overtighten.
3. **Install Glass Shelves:** Carefully place the tempered glass shelves onto the designated supports within the frame. Ensure they are seated properly and securely.
4. **Attach the Central Column:** Secure the central column to the base frame. This column will support the TV mounting bracket and facilitate cable management.
5. **Mount the TV Bracket:** Attach the TV mounting bracket to the central column. This bracket includes the swivel mechanism.

6. **Attach TV Mounting Arms to TV:** Secure the mounting arms to the back of your television using the appropriate screws and spacers from the hardware kit, matching your TV's VESA pattern. Ensure the screws are not too long or too short.
7. **Hang TV on Stand:** With assistance, carefully lift your TV and hook the mounting arms onto the TV bracket on the stand. Engage any safety locks or clips to secure the TV in place.
8. **Adjust Height (Optional):** The TV mounting bracket allows for height adjustment. Adjust the TV to your preferred viewing height before fully tightening all securing bolts.
9. **Cable Management:** Utilize the cable management system integrated into the central column to route and conceal TV and device cables for a tidy appearance.

Product Main Features




SAFETY LOCK



ADJUSTABLE UP&DOWN




THICKENED TEMPERED GLASS



SIMPLE SWIVEL



CABLE MANAGEMENT



ONE X-SHAPED BRACKET




Image: Diagram illustrating key features such as the safety lock for the TV, adjustable height mechanism, thickened tempered glass shelves, simple swivel function, integrated cable management, and the X-shaped bracket design.

OPERATING INSTRUCTIONS

- **Swivel Function:** The TV stand features a swivel bracket that allows the television to be rotated horizontally up to 30 degrees to the left or right. Gently push the TV to adjust its viewing angle.

Large Angle Horizontal Swivel

The TV screen can be rotated horizontally by 60° as needed



Image: Illustration demonstrating the TV stand's horizontal swivel capability, showing the TV rotating up to 30 degrees left and right from the center.

- **Height Adjustment:** The TV mounting bracket can be adjusted vertically to achieve optimal viewing height. Refer to the assembly section for details on how to adjust and secure the height.

ADJUSTABLE UP AND DOWN

Adapt to multiple apartment types




Image: Diagram showing the adjustable height feature of the TV stand, indicating 'Low', 'Mid', and 'High' positions for the television.

- **Shelf Usage:** The three tempered glass shelves provide space for A/V components, DVD players, gaming systems, and other media accessories. Distribute weight evenly across the shelves.

MAINTENANCE

- **Cleaning:** Use a soft, damp cloth to clean the metal frame and glass shelves. Avoid abrasive cleaners or harsh chemicals that could damage the finish or glass.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight and secure. Retighten if necessary.
- **Glass Care:** Avoid placing heavy or sharp objects directly on the glass shelves to prevent scratches or cracks.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
TV does not fit the mount.	Incorrect VESA pattern or TV size.	Verify your TV's VESA pattern and size against the specifications in this manual. This stand supports VESA up to 600x400mm and TVs from 32-65 inches.
Stand feels unstable.	Uneven floor; loose connections; overloaded shelves.	Ensure the stand is on a level surface. Adjust the feet for stability. Check all assembly screws and tighten if loose. Do not exceed the weight capacity of the shelves or the TV mount.
Difficulty swiveling the TV.	Connections too tight; obstruction.	Ensure the swivel mechanism is not overtightened during assembly. Check for any cables or objects obstructing the movement.
Missing parts or damaged components.	Manufacturing defect or shipping damage.	Do not proceed with assembly. Contact customer support immediately for replacement parts.

SPECIFICATIONS

Feature	Detail
Model Number	TSG001
Material	Tempered Glass, Metal
Color	Black
Maximum Screen Size	65 inches
Load Capacity (TV)	110 lbs (50 kg)
Tilt Range	±30° (Swivel)
Max VESA Mounting Pattern	600mm x 400mm
Product Dimensions (L x W x H)	44.1 x 15.75 x 43.31 inches (112.01 x 40.01 x 110.01 cm)
Product Weight	57.8 lbs (26.2 kg)

PRODUCT DIMENSION

Suitable for TV size **32"-65"**




Image: Detailed diagram showing the product dimensions: 44.1 inches length, 15.75 inches width, and 43.31 inches height, suitable for 32-65 inch TVs.

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, claims, or technical support, please refer to the warranty card included with your purchase or contact the seller directly. Please have your model number (TSG001) and purchase information ready when contacting support.

For further assistance, please visit the manufacturer's website or contact their customer service department.