

Soundcore A31X1

Soundcore Select 4 Go Bluetooth Shower Speaker User Manual

Brand: Soundcore

Model: A31X1

INTRODUCTION

Thank you for choosing the Soundcore Select 4 Go Bluetooth Shower Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Designed for durability and portability, the Select 4 Go offers powerful sound with IP67 waterproof and dustproof protection, making it ideal for various environments, including showers, outdoor adventures, and travel.



The Soundcore Select 4 Go speaker, showcasing its compact design and integrated strap.

WHAT'S IN THE BOX

Verify that all components are present upon unboxing:

- Soundcore Select 4 Go Bluetooth Shower Speaker (Blue)
- 30cm USB-A to USB-C Charging Cable
- Safety Card & Quick Start Guide

Note: A wall charger is not included and must be supplied separately.



Illustration of the Soundcore Select 4 Go speaker and its included accessories.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB-A to USB-C cable to the charging port on the speaker and a compatible USB power adapter (not included). The charging indicator light will illuminate during charging and turn off when fully charged. A full charge takes approximately 4.5 hours.

2. Powering On/Off

- To power on, press and hold the **Power button** for 2 seconds.
- To power off, press and hold the **Power button** for 2 seconds again.

3. Bluetooth Pairing

1. Power on the Soundcore Select 4 Go speaker. The Bluetooth indicator will flash blue, indicating it's in pairing mode.
2. On your mobile device, enable Bluetooth and search for "Soundcore Select 4 Go" in the list of available devices.
3. Select "Soundcore Select 4 Go" to connect. Once connected, the Bluetooth indicator will turn solid blue.

Small Size, Punchy Sound

Tiny yet mighty—perfect for outdoor adventures.



The control panel of the Soundcore Select 4 Go, highlighting the power and Bluetooth buttons.

4. True Wireless Stereo (TWS) Pairing

For a more immersive audio experience, you can pair two Soundcore Select 4 Go speakers together.

1. Ensure both Soundcore Select 4 Go speakers are powered on.
2. Connect one speaker to your smartphone via Bluetooth (this will be the primary speaker).
3. On both speakers, press and hold the **Bluetooth button** for 2 seconds. You will hear a tone, and the Bluetooth indicators will flash blue and white.
4. Once successfully paired, the Bluetooth indicator on the primary speaker will turn solid blue, and the secondary speaker's indicator will turn solid white.

Stereo Sound with TWS

Pair two speakers via TWS for an immersive stereo experience.



Two Soundcore Select 4 Go speakers paired for True Wireless Stereo sound.

OPERATING THE SPEAKER

Basic Controls

Button	Function
Power Button	Press and hold for 2 seconds to Power On/Off.

Button	Function
Volume +	Press to increase volume.
Volume -	Press to decrease volume.
Play/Pause	Press to Play/Pause music.
Next Track	Press and hold Volume + for 2 seconds.
Previous Track	Press and hold Volume - for 2 seconds.
Bluetooth Button	Press to enter Bluetooth pairing mode. Press and hold for 2 seconds (on two speakers) for TWS pairing.

IP67 Protection and Floatable Design

The Soundcore Select 4 Go is designed with an IP67 rating, making it highly resistant to water and dust. It can be immersed in up to 3.3 feet (1 meter) of water for up to 30 minutes. Its floatable design ensures it stays on the surface when used in water, preventing it from sinking. Always ensure the rubber cover over the charging port is securely sealed for effective waterproofing.

Built for Adventures

The IP67 rating ensures it's waterproof, dustproof, and even floats.

IP67



Note: The rubber cover needs to be sealed for effective waterproofing.

The Soundcore Select 4 Go speaker is fully waterproof and designed to float.

Battery Life

The speaker provides up to 20 hours of continuous playtime on a single charge. Actual battery life may vary based on volume level, audio content, and environmental factors.

20-Hour Long Battery

Non-stop music and vibrant vibes.



Note: Playback time tested at 40% volume with Balanced EQ in the Anker laboratory. Actual playtime may vary due to volume, audio source, EQ, and environmental conditions.

Enjoy extended listening sessions with up to 20 hours of battery life.

MAINTENANCE

Cleaning

- Wipe the speaker with a soft, damp cloth.
- Do not use any corrosive cleaner/oil to clean.
- After exposure to water, especially saltwater, rinse the speaker with fresh water and allow it to air dry completely before charging or using.

Storage

- Store the speaker in a cool, dry place away from extreme temperatures.
- Avoid prolonged exposure to direct sunlight or high humidity.

TROUBLESHOOTING

Cannot Power On

- Ensure the speaker is fully charged. Connect it to a power source and allow it to charge for at least 30 minutes before attempting to power on again.

Cannot Pair with Bluetooth Device

- Make sure the speaker is in Bluetooth pairing mode (blue indicator flashing).
- Ensure your device's Bluetooth is enabled and within range (up to 30 meters).
- Forget "Soundcore Select 4 Go" from your device's Bluetooth list and try pairing again.
- If multiple Bluetooth devices are nearby, turn them off to avoid interference.

No Sound or Low Volume

- Increase the volume on both the speaker and your connected device.
- Ensure the speaker is properly connected to your device.
- Check if the speaker's battery is low.

TWS Pairing Issues

- Ensure both speakers are Soundcore Select 4 Go models.
- Disconnect any existing Bluetooth connections from both speakers before attempting TWS pairing.
- Follow the TWS pairing steps precisely (press and hold Bluetooth button on both speakers for 2 seconds).

SPECIFICATIONS

Model Name	A31X1
Speaker Type	Outdoor
Connectivity Technology	Bluetooth
Bluetooth Range	30 Meters
Speaker Maximum Output Power	5 Watts
Battery Life	20 Hours
Charging Time	4.5 Hours
Water Resistance Level	IP67 Waterproof/Dustproof

Product Dimensions	3.23"D x 4.72"W x 1.89"H
Item Weight	9.3 Ounces
Material	PC+ABS

WARRANTY AND SUPPORT


Warranty Information

The Soundcore Select 4 Go speaker comes with a 24-month limited warranty, covering manufacturing defects from the date of purchase. This warranty ensures continuous playback for 5 days at 40°C with consistent sound quality and no performance degradation. The battery retains 95% performance after 300 cycles at max current, and buttons can be pressed up to 3,000 times without issues. Please retain your proof of purchase for warranty claims.

Customer Support

For technical support, warranty inquiries, or additional information, please visit the official Soundcore website or contact their customer service team. Refer to the Safety Card and Quick Start Guide included in your package for specific contact details and online resources. You can also find more information and support at the [Soundcore Store on Amazon](#).

Documents - Soundcore – A31X1



[Soundcore Select 4 Go Quick Start Guide](#)

Get started with your Soundcore Select 4 Go portable speaker. This guide provides quick setup, Bluetooth pairing, TWS connection, button controls, specifications, and safety information.

lang:en score:36 filesize: 3.39 M page_count: 18 document date: 2024-07-26

EU & UK Declaration of Conformity (EN)		Version:V1.0	
Name of the Manufacturer	Anker Innovations Limited		
Address of the Manufacturer	Unit 56, 8th Floor, Tower 2, Admiralty Centre, 18 Harcourt Road, Hong Kong		
EU Importer	Anker Innovations Deutschland GmbH		
UK Importer	Anker Technology (UK) Limited		
Name of the Product	soundcore Select 4 Go		
Trademark	soundcore		
Model No.	A31X1		
We declare under our responsibility that the above referenced product complies with the following recognized directives and standards, applicable in part or in whole:			
Standards			
EN IEC 62368-1:2020/A11:2020 ETSI EN 301 489-1 V2.2.3, ETSI EN 301 489-17 V2.2.4, EN 55032:2015/A1:2020, EN 55035:2017/A1:2020, EN IEC 61000-3-2:2019/A1:2021, EN 61000-3-3:2013/A2:2021 ETSI EN 300 328 V2.2.2 EN 62479:2019, EN 50632:2017 EN 10831-1:2024			
Directives			
2014/53/EU, 2011/65/EU and amendment (EU)2015/863			
I represent and warrant that: (i) I am a designated person of the manufacturer, (ii) I am responsible for the regulatory compliance of the product (including with the requirements mentioned in Anker Innovations Limited and this Declaration of Conformity) and (iii) the information I have provided in support of the safety and effectiveness of the product to be true and accurate and do not contain any material omissions.			
Title:	Testing and Compliance Director	Function:	Product Certification Compliance
Name:	Louis Qi	Date:	2025-07-15
City:	HongKong	Signature:	

[\[pdf\] Declaration of Conformity](#)

soundcore Select 4 Go A31X1 EU Declaration v 1753948917 cdn shopify s files 1 0515 5553 2976 |||

EU UK Declaration of Conformity EN Version:V1.0 Name of the Manufacturer Address of the Manufa ... 49 Clarendon Road, Watford, Hertfordshire, WD17 1HP, United Kingdom soundcore Select 4 Go soundcore **A31X1** We declare under our responsibility that the above referenced product complies with the follo...

lang:en score:34 filesize: 305.98 K page_count: 25 document date: 2025-07-15

EU & UK Declaration of Conformity (EN) Version:V1.0

Name of the Manufacturer	Anker Innovations Limited
Address of the Manufacturer	Unit 5B, 8th Floor, Tower 2, Admiralty Centre, 18 Harcourt Road, Hong Kong
EU Importer	Anker Innovations Deutschland GmbH, Georg-Meier-Strasse 3, 80807 Munich, Germany
UK Importer	Anker Technology (UK) Limited, QN818, 49 Clarendon Road, Watford, Hertfordshire, WD17 1HP, United Kingdom
Name of the Product	Soundcore Select 4 Go
Trademark	soundcore
Model No.	A31X1

We declare under our responsibility that the above referenced product complies with the following recognized directives and standards, applicable in part or in whole:

Standards
EN IEC 62368-1:2020+A11:2020 ETSI EN 301 489-1 V2.2.2, ETSI EN 301 489-17 V2.2.4, EN 55032:2015A1:2020, EN 55035:2017A11:2020, EN IEC 61000-3-2:2019A1:2021, EN 61000-3-2:2019A2:2021 ETSI EN 300 328 V2.2.2 EN 62479:2010, EN 50663:2017 EN 15851-1:2024
Directives
2014/53/EU, 2011/65/EU and amendment (EU/2015/863)

I represent and warrant that: (i) I am a designated person of the manufacturer, (ii) I am responsible for the regulatory compliance of the product (including with the requirements mentioned in Anker Innovations Limited and this Declaration of Conformity) and (iii) the information I have provided in support of the safety and effectiveness of the product to be true and accurate and do not contain any material omissions.

Title:	Testing and Compliance Director	Function:	Product Certification Compliance
Name:	Leung Qi	Date:	2025-07-15
City:	Hongkong	Signature:	

[pdf] Decleration of Conformity

soundcore Select 4 GoA31X1 Go EU Declarationcdn shopify s files 1 0917 4807 3750 A31X1 Declaration v 1753941677 |||

EU UK Declaration of Conformity EN Version:V1.0 Name of the Manufacturer Address of the Manufa ... 49 Clarendon Road, Watford, Hertfordshire, WD17 1HP, United Kingdom soundcore Select 4 Go soundcore **A31X1** We declare under our responsibility that the above referenced product complies with the follo...

lang:en score:34 filesize: 305.98 K page_count: 25 document date: 2025-07-15

Dom > Kotwica > ANKER A31X1 Soundcore Select 4 Go Bluetooth głośnik prysznicowy Instrukcja obsługi

ANKER A31X1 Soundcore Select 4 Go Głośnik prysznicowy Bluetooth

[pdf]

ANKER A31X1 Soundcore Select 4 Go Bluetooth głośnik prysznicowy Instrukcja obsługi 21 hours ago — Gdy jeden jest podłączony do smartfona naciśnij i przytrzymaj przycisk przez 2 sekundy na dwóch głośnikach aby przejść trybu parowania1mediaexpert.pl products files 73 7341384 obsługi SOUNDCORE Selekt |||

Dom Kotwica ANKER **A31X1** Soundcore Select 4 Go Bluetooth glonik prysznicowy Instrukcja obsługi ANKER **A31X1** Soundcore Select 4 Go Glonik prysznicowy Bluetooth Zawarto 1 Na pierwszy rzut oka 2 Ladowanie glonika 3 Wlczanie/wylczanie 4 Korzystanie z glonika 5 Sterowanie przyciskami 6 Aplikacja rdze...

lang:pl score:31 filesize: 1013.34 K page_count: 11 document date: 2025-08-07

内容

電源ボタン	充電ケーブルを接続
電源ボタン (長押し)	電源ボタンを長押し
Bluetoothボタン	Bluetoothを接続
電源ボタン (長押し)	電源ボタンを長押し

充電方法

充電ケーブルを、充電ポートに接続して充電します。

充電ケーブル	充電ケーブルを接続
充電ケーブル	充電ケーブルを接続
充電ケーブル	充電ケーブルを接続

充電のオン/オフ

電源ボタン	電源ボタンを長押し
電源ボタン	電源ボタンを長押し
電源ボタン	電源ボタンを長押し

2024年8月現在、この製品は中国で製造されています。本製品の製造元は中国にあります。

Soundcore Select 4 Go Portable Speaker User Manual

Comprehensive guide for the Soundcore Select 4 Go portable speaker, detailing its features, Bluetooth connectivity, TWS pairing, app integration, button controls, and technical specifications.

lang:pl score:29 filesize: 568.08 K page_count: 3 document date: 2024-10-16

soundcore

For more information, please visit : soundcore.com/support

soundcoreaudio soundcoreaudio soundcoreaudio **A31X1** 51005004946 V01

soundcore Select 4 Go Quick Start Guide soundcore Google Play and the Google Play logo are trademarks of Google Inc. Apple and the Apple logo are trademarks o...

[pdf] User Manual Quick Start Guide Frequently Asked Questions Guide

A31X1QSG Ip ankerjapan hubfs aaos manual |||

For FAQs and more information, please visit : soundcore.com/support SoundcoreAudio soundcoreaudio soundcoreaudio **A31X1** 51005004946 V01 soundcore Select 4 Go Quick Start Guide soundcore Google Play and the Google Play logo are trademarks of Google Inc. Apple and the Apple logo are trademarks o... lang:en score:28 filesize: 3.39 M page_count: 18 document date: 2024-07-31


Soundcore Select 4 Go		
Model	Product/Accessory	Technical Specifications
Model	What's in the box?	1. Soundcore Select 4 Go 2. USB-C charging cable 3. User manual 4. The speaker does not support AUX mode.
Model	Does the Select 4 Go support the soundcore App?	Yes, the Select 4 Go can be controlled via the soundcore App. Note: If you have the soundcore App installed on your smartphone, you can control it from the App. If you have the soundcore App installed on your smartphone, you can control it from the App. If you have the soundcore App installed on your smartphone, you can control it from the App.
Model	What is the playback time of Select 4 Go?	Select 4 Go supports up to 20 hours of playback at 40% volume in Stereo mode. Battery life will vary depending on the content being played, custom EQ, volume level, etc.
Model	What is the charging indicator light status?	The power indicator will be red when charging and blue when fully charged. When the power indicator is red, you can use the USB-C port to charge it.
Model	What are the different indicator light colors mean?	Select 4 Go indicator light will be red when charging, and when it is fully charged, the power indicator will be blue. You can also use the USB-C port to charge it.
Model	Is Select 4 Go waterproof?	Select 4 Go has IPX7 waterproofing, but it is not recommended to use it in water. Make sure to use the waterproof cover when using it in water.

[Soundcore Select 4 Go FAQ and User Information](#)

Comprehensive frequently asked questions and answers for the Soundcore Select 4 Go portable Bluetooth speaker, covering its features, connectivity, charging, waterproofing, and more.

lang:en score:28 filesize: 60.45 K page_count: 4 document date: 0000-00-00


Přehled



• Touch-sensitive	• Touch-sensitive
• LED indicator light	• Touch-sensitive
• Touch-sensitive	• Multiple port USB-C
• Touch-sensitive	

Nabíjení reproduktoru

• Používejte certifikovaný kabel A-C a nabíječku, aby nedošlo k poškození.



• Stisknutí tlačítka	• Tlačítko
• Stisknutí tlačítka	• Tlačítko
• Stisknutí tlačítka	• Tlačítko




[Anker Soundcore Select 4 Go Uživatelská příručka a specifikace](#)

Podrobný průvodce přenosným Bluetooth reproduktorem Anker Soundcore Select 4 Go, který pokrývá nastavení, funkce, párování TWS, integraci aplikace soundcore a technické specifikace.

lang:hr score:26 filesize: 748.74 K page_count: 6 document date: 2025-02-11


At a Glance



• Power Button	• Power Button
• Power/Bluetooth LED	• Volume Up Button
• Bluetooth Button	• USB-C Charging Port
• Volume Down Button	

Charging Your Speaker

• Use a certified A-C cable and charger to prevent any damage.




• Charging Red	• Low Battery
• Steady Red	• Being Charged
• Steady White	• Fully Charged

[Soundcore Select 4 Go User Manual - Anker](#)

User manual for the Soundcore Select 4 Go Bluetooth speaker by Anker. Learn about its features, charging, Bluetooth pairing, TWS mode, button controls, soundcore app integration, and specifications.


lang:en score:24 filesize: 787.73 K page_count: 5 document date: 2024-08-29



• Tactko napájení	• Tactko přehrávání/pauza
• LED dioda napájení/Bluetooth	• Tactko zrychlení/brzdění
• Tactko Bluetooth	• Nabíjecí port USB-C
• Tactko pro volání (Bluetooth)	

Nabíjení reproduktoru

• Používejte certifikovaný kabel A-C a nabíječku, aby nedošlo k poškození.




+	Střed červeně	Výbití baterie
+	Střed červeně	Plněná
○	Střed bílá	Plněná baterie



[pdf] User Manual

A31X1 V01 EN UM 20240815 1 cs DAGE0AMhaH0 BAGdZn37 RQ Kryštof Bárta Přehled Nabíjení reproduktoru F mobil czDva identické reproduktory soundcore lze vzájemně spárovat pro stereofonní zvuk Oba mohou přehrávat stejný jeden jako levý kanál a druhý anker select 4 go manual czmedia f cz document 151202 anker czAnker Soundcore Select Go MANUAL CZ 749kBDva druhý Anker Bluetooth reproduktor modrá czanker 151195 ||| ||| Pehled Tlactko napjen LED dioda napjen a Bluetooth Tlactko Bluetooth Tlactko pro snzen hlasitosti Tlactko pehrvn/pauzy Tlactko zvsen hlasitosti Nabjec port USB-C Nabjen reproduktoru Pouzvejte certifikovan kabel A-C a nabjecku, aby nedoslo k Pehled Tlactko napjen LED dioda napjen a Bluetooth Tlactko Bluetooth Tlactko pro snzen hlasitosti Tlactko pehrvn/pauzy Tlactko zvsen hlasitosti Nabjec port USB-C Nabjen reproduktoru Pouzvejte certifikovan kabel A-C a nabjecku, aby nedoslo k poskozen. Blik červen Stl červen Stl bl Vybit baterie...


lang:hr score:21 filesize: 748.74 K page_count: 6 document date: 2025-02-11



• 전원 버튼	• 충전 / 일시정지 버튼
• 전원 및 블루투스 LED	• 블루투스 버튼
• 블루투스 버튼	• USB-C 충전 포트
• 블루투스 버튼	

스피커를 충전하세요

• 인증된 USB-C 케이블과 충전기를 사용하여 충전을 완료하십시오.



+	작은 등 점등	배터리 부족
+	빨간색으로 점등	충전
○	스피커 점등	충전 완료

[pdf] User Manual

prieš 2 valandas — TWS A31X1 V01 KO UM 20240822 salesforce knowledge s3 us west amazonaws 000020904 en US ||| LED A-C . / USB-C / 2 . 2 20 . Bluetooth , 4 . PAIRING CONNECTED Select 4 Go Bluetooth 3 , . Bluetooth Bluetooth . . ,

lang:en score:14 filesize: 808.37 K page_count: 5 document date: 2024-08-29