

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Soundcore](#) /
- › [Soundcore Select 4 Go Bluetooth Shower Speaker Instruction Manual](#)

## Soundcore A31X1

# Soundcore Select 4 Go Bluetooth Shower Speaker Instruction Manual

Brand: Soundcore | Model: A31X1

## 1. INTRODUCTION AND OVERVIEW

The Soundcore Select 4 Go is a portable Bluetooth speaker designed for versatile use, featuring robust IP67 waterproof and dustproof protection, allowing it to float and withstand immersion up to 3.3 feet (1 meter) for 30 minutes. Enjoy up to 20 hours of continuous playback on a single charge, making it ideal for various activities such as showering, camping, hiking, beach outings, or poolside relaxation. Its lightweight design and integrated strap ensure effortless portability. For an enhanced audio experience, two Select 4 Go speakers can be wirelessly paired for True Wireless Stereo (TWS) sound.



Image: The Soundcore Select 4 Go speaker in its green color variant, showcasing its compact and portable design.

## 2. WHAT'S IN THE BOX

---

- Soundcore Select 4 Go Bluetooth Shower Speaker (x1)
- 30cm USB-A to C Cable (x1)
- Safety Card & Quick Start Guide (x1)
- Note: Wall charger not included.



Image: A visual representation of the Soundcore Select 4 Go speaker, USB-C cable, and documentation included in the product packaging.

### 3. PRODUCT FEATURES

- **IP67 Waterproof & Dustproof:** Designed to withstand harsh outdoor conditions, fully protected against dust ingress, and can be immersed in water up to 3.3 ft (1 meter) for 30 minutes. The speaker also floats.
- **20-Hour Playtime:** Enjoy extended music playback on a single charge, suitable for all-day use.
- **Portable Design:** Lightweight with an integrated strap for easy carrying and attachment to bags or bikes.
- **Powerful Sound:** Delivers 5W of audio output through a 45mm dynamic driver for clear and dynamic sound.
- **True Wireless Stereo (TWS) Pairing:** Connect two Soundcore Select 4 Go speakers wirelessly for a richer, more immersive stereo sound experience.
- **Customizable EQ:** Tune the audio to your preference using the Soundcore app.
- **Bluetooth 5.4:** Ensures stable and efficient wireless connectivity up to 30 meters.



### Select 4 Go Is Always Ready to Go

- Withstands continuous playback for 5 days at 40°C with consistent sound quality and no performance degradation.
- The battery retains 95% performance after 300 cycles at max current.
- Buttons can be pressed up to 3,000 times with no issues.

Note: Data sourced from the soundcore and Anker laboratories under controlled test conditions. Actual results may vary.

Image: The Soundcore Select 4 Go speaker floating on water, illustrating its IP67 waterproof and floatable features.

### Two Speakers, One Epic Soundtrack

Sync two speakers via TWS (True Wireless Stereo) for an immersive stereo experience.

Note: The latest version cannot be TWS paired with older versions.  
(Check the serial number to identify your version.)



Image: The Soundcore Select 4 Go speaker in a social setting, emphasizing its 20-hour battery life for extended enjoyment.

## 4. SETUP

### 4.1 Charging the Speaker

1. Open the rubber cover on the side of the speaker to reveal the USB-C charging port.
2. Connect the provided USB-A to C cable to the speaker's charging port and a compatible USB power adapter (not included).
3. The LED indicator will show charging status. A full charge takes approximately 4.5 hours.
4. Ensure the rubber cover is securely sealed after charging to maintain IP67 water resistance.

### 4.2 Powering On/Off

- To power on, press and hold the power button ( ) for 2 seconds. The LED indicator will light up.
- To power off, press and hold the power button ( ) for 2 seconds. The LED indicator will turn off.

### 4.3 Bluetooth Pairing

1. When powered on, the speaker will automatically enter Bluetooth pairing mode, indicated by a flashing blue LED.
2. On your smartphone or tablet, enable Bluetooth and search for

