

[Manuals.plus](#) /

› [Neugo](#) /

› Neugo NE055 Series Steam Mop Accessories Kit User Manual

Neugo NE055ACC

Neugo NE055 Series Steam Mop Accessories Kit User Manual

Model: NE055ACC | Brand: Neugo

PRODUCT OVERVIEW

This 3-piece brush accessories kit is designed exclusively for the **Neugo NE055 Series Steam Mop Handheld Steamer Cleaner**. It provides specialized brushes to enhance your whole home cleaning experience. Please note, this kit is **NOT compatible with other brands or models** of steam cleaners.

ONLY for

Neugo NE055

Steam Mop Cleaner



Image: The Neugo NE055 Steam Mop shown with the three accessory brushes, highlighting its exclusive compatibility.

Included Components:

- 1 x Brass Brush
- 1 x Nylon Brush
- 1 x Angle Nozzle



Image: A clear view of the three included accessories: the angle nozzle, the brass brush, and the nylon brush.

SETUP AND ATTACHMENT

Before attaching any accessory, ensure your Neugo NE055 Steam Mop is turned off and unplugged. Allow the unit to cool down if it has been recently used.

1. **Identify the Connection Point:** Locate the accessory connection point on the handheld steamer unit of your Neugo NE055.
2. **Select the Desired Accessory:** Choose the appropriate brush (Brass, Nylon) or the Angle Nozzle for your cleaning task.
3. **Attach the Accessory:** Align the accessory with the connection point and push firmly until it clicks securely into place. Do not force the attachment.
4. **Verify Secure Attachment:** Gently tug on the accessory to ensure it is firmly attached before operating the steam mop.

OPERATING INSTRUCTIONS

Once an accessory is securely attached, you can begin your cleaning task. Always refer to your main Neugo NE055 Steam Mop manual for general operating and safety instructions.

Using the Angle Nozzle:

The Angle Nozzle is ideal for directing steam into hard-to-reach areas, corners, crevices, and around fixtures. It provides a concentrated jet of steam for targeted cleaning.



Angle Nozzlen

Image: The Neugo NE055 Steam Mop utilizing the angle nozzle to clean the rim of a toilet bowl, demonstrating its ability to reach tight spaces.

- **Application:** Excellent for grout lines, toilet rims, sink edges, and other narrow or angled surfaces.
- **Technique:** Point the nozzle directly at the area to be cleaned. Activate steam and move slowly to allow the steam to penetrate and loosen dirt.

Using the Nylon Brush (Round Brush):

The Nylon Brush, also known as the Round Brush, features durable nylon bristles suitable for general scrubbing tasks on various surfaces without causing scratches. It combines steam with mechanical scrubbing action.



Round Brush

Image: The Neugo NE055 Steam Mop with the round nylon brush attachment being used to clean tiled shower walls, illustrating its effectiveness on larger, flat surfaces.

- **Application:** Ideal for bathroom tiles, sinks, stovetops, and general kitchen surfaces.
- **Technique:** Apply the brush to the surface and activate steam. Use gentle scrubbing motions to lift dirt and grime.

Using the Brass Brush:

The Brass Brush is equipped with sturdy brass bristles, designed for heavy-duty scrubbing on resilient surfaces. The brass bristles are effective at removing stubborn dirt, grease, and baked-on residue.



Brass Brush

Image: The Neugo NE055 Steam Mop with the brass brush attachment cleaning a greasy range hood filter, demonstrating its use for tough, caked-on grime.

- **Application:** Best for oven racks, BBQ grills, stubborn grout, and heavily soiled metal surfaces.
- **Caution:** Due to the abrasive nature of brass, test on an inconspicuous area first. Not recommended for delicate or

easily scratched surfaces.

- **Technique:** Apply moderate pressure and scrub while activating steam.

MAINTENANCE AND CARE

Proper maintenance of your accessories will ensure their longevity and continued effectiveness.

- **Cleaning Brushes:** After each use, allow the brushes to cool. Rinse them under running water to remove any loosened dirt or debris. For stubborn residue, a mild soap solution can be used.
- **Drying:** Allow all accessories to air dry completely before storing them to prevent mildew or odor.
- **Storage:** Store the accessories in a clean, dry place, away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the bristles for wear or damage. Replace accessories if bristles are severely worn or damaged to maintain optimal cleaning performance.

TROUBLESHOOTING

If you encounter issues while using your Neugo NE055 accessories, consider the following common solutions:

Problem	Possible Cause	Solution
Accessory not attaching securely	Incorrect alignment or debris in connection point.	Ensure correct alignment and clear any debris from the connection point on both the accessory and the steam mop. Push firmly until it clicks.
Reduced cleaning effectiveness	Worn bristles (Nylon/Brass brushes) or clogged nozzle (Angle Nozzle).	Inspect bristles for wear; replace if necessary. For the angle nozzle, ensure the opening is clear of mineral buildup or debris.
Steam not flowing through accessory	Accessory not fully seated or main steam mop issue.	Re-attach the accessory ensuring it is fully seated. Refer to your main Neugo NE055 Steam Mop manual for troubleshooting steam flow issues with the main unit.

SPECIFICATIONS

- **Product Name:** 3 Piece Brush Accessories Kit
- **Brand:** Neugo
- **Model Name:** NE055ACC
- **Compatibility:** Exclusively for Neugo NE055 Series Steam Mop Handheld Steamer Cleaner
- **Included Components:** 1 x Brass Brush, 1 x Nylon Brush, 1 x Angle Nozzle
- **Color:** Grey
- **Item Weight:** Approximately 0.1 Kilograms (3.52 ounces)
- **UPC:** 767461078787

SUPPORT AND WARRANTY

For further assistance, product inquiries, or warranty information regarding your Neugo NE055 Series Steam Mop or its accessories, please contact Neugo customer support or visit the official Neugo store.

Neugo Store: [Visit the Neugo Store on Amazon](#)

Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question