

[Manuals.plus](#) /

› [HUABAO](#) /

› HUABAO Karaoke Machine Model A101 User Manual

HUABAO A101

HUABAO Karaoke Machine Model A101 User Manual

Comprehensive instruction manual for the HUABAO Karaoke Machine Model A101, covering setup, operation, maintenance, and troubleshooting for optimal performance.

1. INTRODUCTION

Welcome to the HUABAO Karaoke Machine Model A101. This portable Bluetooth speaker system is designed to deliver clear and balanced sound for various entertainment and public speaking needs. Featuring a powerful 15W PA system with a 6.5-inch subwoofer, it offers versatile connectivity and user-friendly controls. This manual provides essential information for setting up, operating, and maintaining your device.



Figure 1: The HUABAO Karaoke Machine Model A101, showcasing the main unit, two wireless microphones, remote control, and various connecting cables.

2. WHAT'S IN THE BOX

Upon unboxing your HUABAO Karaoke Machine, please ensure all the following items are present:

- 1 x Speaker Unit
- 2 x Rechargeable Wireless Microphones
- 1 x Remote Control
- 1 x Adjustable Shoulder Strap
- 1 x AUX Cable
- 1 x Type-C Charging Cable
- 1 x User Manual (this document)

PLAY AND ENJOY NON-STOP

Built-in 3600mAh rechargeable battery keeps the party going. Dual rechargeable wireless microphones for added convenience.



Figure 2: All components included in the HUABAO Karaoke Machine package.

3. SETUP

3.1 Initial Charging

Before first use, fully charge the speaker and microphones. Connect the Type-C charging cable to the speaker's charging port and a suitable USB power adapter (not included). The speaker's battery indicator will show charging status. The wireless microphones are also rechargeable; use their respective charging cables.

3.2 Attaching the Shoulder Strap

For convenient portability, attach the adjustable shoulder strap to the designated hooks on the sides of the speaker unit.

BROAD RANGE OF APPLICATIONS

Can connect 6.5mm audio wired microphones and instruments, amplify your joy



Figure 3: The speaker is designed for portability, featuring a carrying handle and an adjustable shoulder strap for easy transport.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

Locate the power switch on the control panel. Toggle it to the "ON" position to power on the speaker. To power off, toggle it to the "OFF" position.

4.2 Mode Selection

Use the 'Mode' button on the control panel or remote control to switch between available input modes: Bluetooth, TF Card, USB, AUX, and FM Radio.

ADJUSTABLE TREBLE & BASS

Separately adjust treble and bass, to make your personalized sound experience.



Figure 4: Detailed view of the control panel, highlighting mode selection and audio adjustment features.

4.3 Bluetooth Mode

Select Bluetooth mode. The speaker will enter pairing mode, indicated by a blinking "BLUE" on the display. On your device (smartphone, tablet, laptop), search for "HUABAO A101" and connect. Once paired, the speaker will confirm with an audio prompt.

4.4 TF Card/USB Mode

Insert a TF card or USB flash drive (MP3 files only) into the respective slot. The speaker will automatically detect the media and begin playback.

4.5 AUX Input

Connect an external audio device using the 3.5mm AUX cable. The speaker will automatically switch to AUX mode.

4.6 FM Radio Mode

Select FM radio mode. Use the 'Play/Pause' button to auto-scan and save available radio stations. Use the 'Previous/Next Track' buttons to navigate through saved stations.

4.7 Microphone Usage

Power on the wireless microphones. They will automatically pair with the speaker. Adjust microphone volume and echo effect using the dedicated knobs on the control panel. The speaker also supports wired 6.5mm microphones and musical instruments via the 'MIC IN' and 'INST' jacks.

2 WIRELESS RECHARGEABLE MICS

Come with 2 wireless rechargeable mics for added convenience. Stable connection within 10 meters. Great for karaoke, speech, church and gatherings.



Figure 5: The two wireless rechargeable microphones for karaoke and speaking.

ADJUSTABLE VOLUME

When you turn the knob all the way up and it's still not loud enough, please turn the volume of the connected device to the maximum level at the same time.



Figure 6: The speaker can be used with wired microphones and musical instruments for amplification.

4.8 Volume Adjustment

The speaker's overall volume is controlled by the 'Volume' knob on the control panel. For optimal sound, ensure the volume on your connected device (phone, tablet, etc.) is also turned up to its maximum level.

ALL-IN-ONE KARAOKE MACHINE



Bluetooth 5.0



TF Card



USB



AUX



FM



Rechargeable Mics



Instrument



Treble & Bass

Figure 7: Adjusting both the speaker's volume knob and the connected device's volume for maximum output.

4.9 Bass & Treble Adjustment

Customize your audio experience using the dedicated 'Bass' and 'Treble' adjustment knobs on the control panel.

4.10 Remote Control

The included remote control allows for convenient operation from a distance, including power, mode selection, volume control, track skipping, and EQ adjustments.

5. MAINTENANCE

- Keep the device dry and away from direct sunlight or extreme temperatures.
- Clean the speaker and microphones with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Store in a cool, dry place when not in use for extended periods.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery is depleted.	Charge the speaker and microphones fully.
Low volume	Speaker volume or connected device volume is low.	Increase both the speaker's 'Volume' knob and the volume on your connected device.
Microphone not working	Microphone battery low or not paired.	Ensure microphones are charged and powered on. They should automatically pair. If not, try restarting both the speaker and microphones.
Bluetooth not connecting	Speaker not in pairing mode or device too far.	Ensure speaker is in Bluetooth pairing mode. Keep devices within 10 meters. Try restarting Bluetooth on both devices.

7. SPECIFICATIONS

Feature	Detail
Model Number	A101
Brand	HUABAO
Item Weight	4.4 pounds
Product Dimensions	9.1 x 5.8 x 13.35 inches
Batteries	1 Lithium Ion battery required (included)
Color	Black
Compatible Devices	Laptop, Musical Instruments, Smart TV, Smartphone, Tablet
Connector Type	3.5 mm Jack, USB Type C
Material Type	Plastic
Output Wattage	15 Watts
Special Features	Echo Effect, Lightweight, Portable, Rechargeable

8. PRODUCT VIDEOS

8.1 Portable Karaoke Machine Overview

Your browser does not support the video tag.

Video 1: A comprehensive overview of the portable karaoke machine, demonstrating its features and functionality.

8.2 Karaoke Speaker with Wireless Microphones Demonstration

Your browser does not support the video tag.

Video 2: A demonstration of the karaoke speaker in action, highlighting the use of its wireless microphones.

9. WARRANTY & SUPPORT

HUABAO offers a one-year warranty and lifetime technical support for every customer. For any questions or concerns regarding your product, please contact us through Amazon or directly via email.

Email Support: support@huabaosound.com

We are committed to delivering a pure and authentic auditory experience, combining cutting-edge technology with artistry in our product design.