

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [VECELO](#) /

› VECELO Full Size Metal Bed Frame Instruction Manual

VECELO WY-F38-BLK-BC12

VECELO Full Size Metal Bed Frame Instruction Manual

Model: WY-F38-BLK-BC12

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the VECELO Full Size Metal Bed Frame. This manual provides essential information for safe assembly, proper use, and maintenance of your new bed frame. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The VEGELO Full Size Metal Bed Frame, fully assembled and placed in a modern bedroom with a mattress and bedding.

2. SAFETY INFORMATION

- **Pinch Points:** Be cautious of pinch points when assembling the side legs and other moving parts.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 500 pounds for the Full size bed frame.
- **Assembly:** Ensure all parts and screws are firmly attached before use. Loose connections can lead to instability and potential injury.
- **Mattress:** This bed frame does not include a mattress. Ensure your mattress fits the Full size dimensions of the frame.
- **Children:** Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- **Tools:** Use only the provided tools or appropriate hand tools for assembly. Do not use power tools as they may overtighten screws and damage the frame.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer service.

- 1 x VECELO Full Size Metal Bed Frame (various metal components)
- 1 x Instruction Manual
- 1 x Assembly Kit (including screws, washers, and Allen wrenches)

Refer to the assembly video for a visual guide to all included parts and hardware.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to assemble the bed frame with two people.


Step-by-Step Assembly Video

Your browser does not support the video tag.

Video: A detailed assembly guide for the VECELO Metal Bed Frame, demonstrating each step from unboxing to final setup.

Key Assembly Details:

- **Headboard Attachment:** Securely attach the headboard components using the provided screws and washers.
- **Side Rails:** Connect the side rails to the headboard and footboard sections. Ensure all connections are tight to prevent wobbling.
- **Center Support Legs:** Install the center support legs and crossbars for added stability. These are crucial for distributing weight evenly.
- **Slat Installation:** Place the steel slats across the frame. The upgraded metal construction and anti-slip band help keep the mattress securely in place and reduce noise.
- **Final Tightening:** After all parts are assembled, re-check and tighten all screws to ensure maximum stability and a noise-free experience.



In order to ensure the stability of the whole structure, it is fixed with an L-shaped plate.

Image: A close-up view illustrating the L-shaped plate used to ensure the stability of the bed frame's structure.



Built-in design prevents mattress from sliding, more humanized





Image: A diagram comparing a correct built-in design that prevents mattress sliding with an incorrect design.

5. OPERATING INSTRUCTIONS

Once assembled, place your full-size mattress directly onto the steel slats. No box spring is needed. The frame's design, including the slightly raised bed edge and anti-slip band, will help keep your mattress in place.



Image: A view highlighting the 12.6-inch under-bed clearance, ideal for storage.

6. MAINTENANCE

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten as necessary to maintain stability and prevent noise.
- **Movement:** When moving the bed frame, lift it rather than dragging it to prevent damage to the frame or your flooring.

7. TROUBLESHOOTING

- **Squeaking Noise:** If the bed frame makes noise, check all connections and tighten any loose screws. Ensure the anti-slip band is correctly positioned.
- **Instability:** If the frame feels unstable, verify that all support legs are firmly on the ground and all bolts are securely fastened.

- **Mattress Sliding:** Ensure the mattress is properly seated within the frame's edges and the anti-slip features are engaged.

8. SPECIFICATIONS

Model Number	WY-F38-BLK-BC12
Size	Full
Material	Metal
Product Dimensions (L x W x H)	77.7" x 54.4" x 39.8"
Weight Capacity	500 lbs
Under-bed Clearance	12.6 inches
Special Features	Headboard, Steel Slats, No Box Spring Needed, Noise-Free, Under Bed Storage



Image: A diagram showing the dimensions (77.7"L x 54.4"W x 39.8"H) and weight capacity (600 lbs) of the Full size bed frame.

9. WARRANTY AND SUPPORT

VECELO is committed to providing quality products. For any issues, missing parts, or assembly questions, please contact our professional after-sales team. We are ready to assist you.

Contact information can typically be found on the product packaging or the retailer's website where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page
<https://manuals.plus/asin/B0DB1WX6VN>

More documents and user manuals: <https://manuals.plus/>