

manuals.plus /

- › [Logitech](#) /
- › [Logitech POP ICON Keys Wireless Bluetooth Keyboard User Manual](#)

## Logitech 920-013143

# Logitech POP ICON Keys Wireless Bluetooth Keyboard User Manual

Model: 920-013143

## INTRODUCTION

The Logitech POP ICON Keys Wireless Bluetooth Keyboard is designed to provide a comfortable and efficient typing experience across multiple devices. This compact keyboard features contoured, low-profile keys and customizable Action Keys for enhanced productivity. It supports connection to up to three wireless devices across various operating systems, allowing for seamless switching.



Image: The Logitech POP ICON Keys Wireless Bluetooth Keyboard, showcasing its compact design and Graphite Lime color scheme.

## SETUP

### 1. Battery Installation

The POP ICON Keys keyboard requires 2 AAA batteries, which are included. To install or replace batteries:

1. Locate the battery compartment on the underside of the keyboard.
2. Remove the battery cover.
3. Insert the 2 AAA batteries, ensuring correct polarity (+/-).

4. Replace the battery cover securely.

# In the box



**Responsible  
Packaging**

**Length:** 12.77 in (324.51 mm)

**Height:** 0.86 in (22mm)

**Width:** 5.39 in (136.96 mm)

**Weight:** 18.69 oz (530g) with batteries

Image: A diagram illustrating the Logitech POP ICON Keys keyboard and the placement of the two AAA batteries included in the box.

## 2. Connecting via Bluetooth

The POP ICON Keys keyboard can connect to up to three devices simultaneously using Bluetooth. Follow these steps to pair your keyboard:

1. Turn on the keyboard using the power switch located on the back or side.
2. Press and hold one of the Easy-Switch keys (F1, F2, or F3) for 3 seconds until the LED indicator above the key starts blinking rapidly. This indicates the keyboard is in pairing mode.
3. On your device (laptop, tablet, smartphone), go to Bluetooth settings.
4. Select "Logitech POP ICON Keys" from the list of available devices.
5. Follow any on-screen prompts to complete the pairing process.
6. Once connected, the LED indicator will glow solid for a few seconds before turning off.

To connect additional devices, repeat the process using a different Easy-Switch key (F1, F2, or F3).

70%  
Recycled  
Plastic\*



Connect up to  
3 devices

Shortcuts and  
media keys



Comfy, quiet typing  
on contoured keys

Customizable Action Keys  
with Logi Options+ App<sup>[2]</sup>

Works with macOS, iPadOS, iOS



Image: An overview diagram of the Logitech POP ICON Keys keyboard highlighting its ability to connect to up to 3 devices and its various shortcut and media keys.

## OPERATING THE KEYBOARD

### Switching Between Devices

To switch between paired devices, simply press the corresponding Easy-Switch key (F1, F2, or F3) for the device you wish to use. The keyboard will instantly connect to the selected device.

# Device-hopping made easy



Image: A desk setup featuring the Logitech POP ICON Keys keyboard and mouse, demonstrating the ease of switching between multiple devices.

## Action Keys and Customization

The POP ICON Keys keyboard features customizable Action Keys on the right side (Home, End, Page Up, Page Down, and a star key). These keys can be programmed to perform various functions using the Logi Options+ App.

- **Default Functions:** The keys have default functions for navigation (Home, End, Pg Up, Pg Dn). The star key typically opens the emoji menu or can be customized.
- **Customization with Logi Options+ App:** Download and install the Logi Options+ App (available for recent versions of Windows and macOS) to personalize the Action Keys. You can assign them to launch applications, perform specific shortcuts, or switch between work and break modes.



# Switch modes in less than 1 second<sup>[4]</sup>



## Access your favorite apps with just one press<sup>[2]</sup>

Image: A close-up view of the Logitech POP ICON Keys keyboard, highlighting the dedicated action keys on the right side.

# Life is easier with shortcuts



## Action Keys save you time with Logi Options+ App[2]

Image: A user interacting with the Logitech POP ICON Keys keyboard, with a monitor in the background showing the Logi Options+ App interface for customizing shortcuts.

### Media and Function Keys

The top row of keys (F1-F12) also serves as media and function keys. You can access these functions directly or by holding the **Fn** key, depending on your operating system's settings.

# Shortcuts just a tap away



Image: A detailed view of the function and media keys on the Logitech POP ICON Keys keyboard, located on the top row.

## MAINTENANCE

To ensure the longevity and optimal performance of your Logitech POP ICON Keys keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe down the keys and surface. Avoid harsh chemicals or abrasive materials.
- **Dust Removal:** Use compressed air to remove dust and debris from between the keys.
- **Storage:** When not in use for extended periods, store the keyboard in a cool, dry place.
- **Battery Life:** The keyboard has a 3-year battery life and a power-saving auto-sleep mode. Replace batteries when the low battery indicator appears.

## TROUBLESHOOTING

If you encounter issues with your Logitech POP ICON Keys keyboard, try the following troubleshooting steps:

- **Keyboard Not Connecting:**
  - Ensure the keyboard is turned on and batteries are properly installed.
  - Make sure Bluetooth is enabled on your device.
  - Re-enter pairing mode on the keyboard by holding an Easy-Switch key (F1, F2, or F3) for 3 seconds.
  - Remove the keyboard from your device's Bluetooth list and attempt to re-pair.
  - Try connecting to a different device to rule out device-specific issues.
- **Keys Not Responding:**
  - Check battery level and replace if necessary.
  - Ensure the keyboard is connected to the correct device (check the Easy-Switch key LED).
  - Restart your computer or device.
- **Lag or Disconnections:**
  - Ensure the keyboard is within the recommended Bluetooth range of your device.
  - Minimize interference from other wireless devices.
  - Update your device's Bluetooth drivers.

SPECIFICATIONS

Feature	Detail
Brand	Logitech
Model Number	920-013143
Connectivity	Bluetooth
Compatible Devices	Laptop, Personal Computer, Tablet, Smartphone (Windows, macOS, iPadOS, iOS, ChromeOS, Android)
Power Source	Battery Powered (2 AAA batteries included)
Battery Life	Up to 3 years (may vary based on user and computing conditions)
Item Weight	1.17 pounds (approx. 530g with batteries)
Dimensions (L x W x H)	12.77 x 5.39 x 0.86 inches (324.51 x 136.96 x 22 mm)
Material	Plastic parts include between 37% and 70% recycled plastic (depending on color, excluding printed wiring assembly and packaging)
Country of Origin	China



# Designed for a positive future



MADE WITH  
RECYCLED PLASTIC



RESPONSIBLE  
PACKAGING

Image: The Logitech POP ICON Keys keyboard, emphasizing its construction with recycled plastic and responsible packaging.







## WARRANTY AND SUPPORT

Logitech products are designed with quality and reliability in mind. For warranty information and technical support, please visit the official Logitech support website or refer to the warranty card included with your product.

**Logi Options+ App:** For advanced customization of your keyboard's Action Keys and other settings, download the Logi Options+ App from the official Logitech website. This application enhances your keyboard's functionality and allows for personalized shortcuts.

For further assistance, you may contact Logitech customer support through their website or the contact information provided in your product packaging.

Related Documents - 920-013143

	<p><a href="#">Logitech POP Icon Combo: Setup and Easy Switch Guide</a></p> <p>A concise guide to setting up your Logitech POP Icon Combo keyboard and mouse using Bluetooth and the Logi App, including instructions for the Easy Switch feature.</p>
	<p><a href="#">Logitech MX Keys Advanced Wireless Illuminated Keyboard</a></p> <p>Discover the Logitech MX Keys, an advanced wireless illuminated keyboard designed for efficiency, stability, and precision. Featuring perfect-stroke keys, smart illumination, and multi-device connectivity for a seamless workflow.</p>
	<p><a href="#">Logitech MX Keys Mini Keyboard: Bluetooth Pairing &amp; Setup Guide</a></p> <p>Comprehensive user manual for the Logitech MX Keys Mini Keyboard, covering Bluetooth pairing, setup, software installation, multi-device connectivity, and feature details for creators.</p>
	<p><a href="#">Logitech POP Keys and POP Mouse Setup and Customization Guide</a></p> <p>A comprehensive guide to setting up, pairing, and customizing your Logitech POP Keys keyboard and POP Mouse, including multi-device setup and emoji key customization.</p>
	<p><a href="#">Logitech MX Mechanical Mini: Getting Started Guide</a></p> <p>A concise guide to setting up and using the Logitech MX Mechanical Mini keyboard, covering connection methods, software, smart backlighting, and Logitech Flow.</p>
	<p><a href="#">Logitech K750 SOLAR Wireless Keyboard - Solar Powered, Eco-Friendly</a></p> <p>Discover the Logitech K750 SOLAR Wireless Keyboard. Features solar charging, long battery life, eco-friendly design, and reliable wireless connectivity for Windows users. Explore its benefits and specifications.</p>