Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > XIAOMI /
- > Xiaomi Redmi Pad SE 8.7 4G LTE User Manual

XIAOMI VHU5346EU

Xiaomi Redmi Pad SE 8.7 4G LTE User Manual

Model: VHU5346EU

Brand: XIAOMI

1. SETUP GUIDE

1.1 Unboxing and Initial Inspection

Carefully unpack your new Xiaomi Redmi Pad SE 8.7. Ensure all components are present and undamaged. The package typically includes:

- Xiaomi Redmi Pad SE 8.7 Tablet
- Fast Car Dual USB 16W Charger
- Wall Adapter
- USB Cable



Image: Xiaomi Redmi Pad SE 8.7 tablet in Aurora Green, showcasing its sleek design and display.

1.2 SIM Card and MicroSD Installation

The Redmi Pad SE 8.7 supports Dual SIM cards and a MicroSD card for expanded storage. Locate the SIM tray on the side of the device. Use the provided SIM ejector tool to open the tray. Insert your activated SIM cards and/or MicroSD card into the designated slots, ensuring correct orientation. Gently push the tray back into the device until it clicks into place.

1.3 Initial Power On and Basic Setup

Press and hold the power button until the Xiaomi logo appears. Follow the on-screen prompts to complete the initial setup, including:

- Language selection
- · Wi-Fi network connection
- · Google account sign-in
- Setting up screen lock (PIN, pattern, or password)
- · Reviewing and accepting terms and conditions

The device runs on Android 14 with Xiaomi's HyperOS, providing a user-friendly interface. You may be prompted to download and install software updates during the initial setup; it is recommended to do so for optimal performance and security.

1.4 Charging the Device

Before first use, fully charge your tablet using the provided 16W Fast Car Dual USB charger, wall adapter, and USB cable. Connect the USB cable to the tablet's charging port and the adapter, then plug the adapter into a power outlet. The battery indicator on the screen will show charging progress.

2. OPERATING INSTRUCTIONS

2.1 Display Features and Interaction

The Redmi Pad SE 8.7 features an 8.7-inch LCD display with a resolution of 1340x800 pixels and a 90Hz refresh rate for smoother visuals. It offers typical brightness of 500 nits, with an outdoor mode boosting it to 600 nits for better visibility in bright conditions. The display is TÜV Rheinland Low Blue Light and Flicker Free certified, incorporating DC dimming and a reading mode to reduce eye strain during prolonged use.

Navigate the device using gestures (swipe up for home, swipe from edge to go back) or traditional 3-button navigation, which can be configured in settings. Swipe down from the left for notifications and from the right for the control panel.

2.2 Performance and Software Experience

Powered by a MediaTek Helio G85 Octa-Core processor clocked at 2.0GHz and equipped with 6GB of RAM (for this variant), the tablet delivers reliable performance for daily tasks, web browsing, and light gaming. The HyperOS interface provides features like split-screen and floating windows for multitasking.

2.3 Connectivity and Audio

The tablet supports 4G LTE connectivity with Dual SIM capability, ensuring you stay connected on the go. It also features 802.11ad Wi-Fi for fast wireless internet. For audio, it includes dual speakers with Dolby Atmos support for an immersive sound experience, and a 3.5mm headphone jack for private listening.

2.4 Camera Functionality

The Redmi Pad SE 8.7 is equipped with an 8MP rear camera (f/2.0) and a 5MP front camera (f/2.2). Both cameras can record video at 1080P resolution at 30 frames per second. The camera app offers basic modes like Photo, Video, and Document scanning.

3. MAINTENANCE

3.1 Battery Care

The tablet is powered by a 6650mAh Lithium Polymer battery. To maximize battery lifespan:

- Avoid extreme temperatures.
- Do not let the battery completely drain frequently.
- Use the original charger and cable for optimal charging.
- · Adjust screen brightness to a comfortable level to conserve power.

3.2 Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Xiaomi typically provides 2 major Android software updates and 3 years of security updates for this model. You can check for updates in the 'Settings' menu under 'About tablet' or 'System apps updater'.

3.3 Storage Management

Your tablet comes with 128GB of internal storage. If you require more space, you can expand it using a MicroSD card. Regularly clear unnecessary files, cache data, and uninstall unused applications to maintain optimal performance. You can monitor storage usage in 'Settings' under 'Storage space'.

4. TROUBLESHOOTING

4.1 Common Issues and Solutions

- **Device not powering on:** Ensure the battery is charged. Connect to the charger and wait a few minutes before attempting to power on again.
- Apps crashing or freezing: Close and restart the app. Clear the app's cache in 'Settings > Apps'. If the issue persists, uninstall and reinstall the app.
- Wi-Fi or cellular connectivity issues: Restart the tablet. Toggle Wi-Fi/cellular data off and on. Check your router or network provider for service interruptions.
- Slow performance: Close background apps. Clear cache. Check available storage space. Restart the device.
- **Screen not responding:** Restart the device by holding down the power button. If unresponsive, force restart (refer to manufacturer's specific instructions for force restart).

5. Specifications

Model Name	Redmi Pad SE 8.7
Model Number	VHU5346EU
Brand	XIAOMI
Screen Size	8.7 Inches
Screen Resolution	1340x800
Refresh Rate	Up to 90Hz
Brightness	500 nits (typ), 600 nits (Outdoor mode)
Processor	MediaTek Helio G85, Octa-Core 2.0GHz
RAM	6GB
Internal Storage	128GB
Expandable Storage	MicroSD (up to 2TB)
Operating System	Android 14, HyperOS
Rear Camera	8MP f/2.0
Front Camera	5MP f/2.2

Battery Capacity	6650mAh
Charging	16W Fast Charging
Wireless Connectivity	4G LTE, Dual SIM, 802.11ad Wi-Fi
Audio	Dual speakers, Dolby Atmos, 3.5mm headphone jack
Dimensions (LxWxH)	8.33 x 4.94 x 0.35 inches
Item Weight	1.34 pounds

6. WARRANTY AND SUPPORT

6.1 Product Warranty

Warranty information for your Xiaomi Redmi Pad SE 8.7 is typically included with the product packaging. Please refer to the warranty card or documentation provided at the time of purchase for details regarding coverage, terms, and conditions.

6.2 Customer Support

For further assistance, technical support, or service inquiries, please visit the official XIAOMI website or contact their customer service. Contact details and support resources can usually be found on the manufacturer's website or in the product documentation.

© 2025 Xiaomi. All rights reserved.