

## RYGHT R484543

# RYGHT OPEN Extra-Auricular Wireless Earbuds User Manual

MODEL: R484543

## 1. Introduction

Thank you for choosing the RYGHT OPEN Extra-Auricular Wireless Earbuds. These earbuds are designed with Open Ear Technology, allowing you to enjoy high-quality audio while remaining aware of your surroundings. They are ideal for sports and daily activities, offering comfort, durability, and clear sound.

This manual provides essential information on how to set up, operate, maintain, and troubleshoot your RYGHT OPEN earbuds. Please read it carefully before use.



Image: RYGHT OPEN Extra-Auricular Wireless Earbuds and their charging case.

## 2. What's Included

Your RYGHT OPEN package includes the following components:

- RYGHT OPEN Earbuds (Left and Right)
- Wireless Charging Case
- USB-C Charging Cable
- User Manual

## 3. Setup

### 3.1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB-C cable to the charging port on the case and the other end to a USB power source (e.g., wall adapter, computer USB port).

- The charging case adds 15 hours of battery life to the earbuds' 5 hours, for a total of 20 hours.
- Charging indicators on the case will show the charging status.



Image: The earbuds and charging case, highlighting the 20-hour total battery life.

### 3.2. Bluetooth Pairing

1. Ensure the earbuds are charged and placed in the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), go to Bluetooth settings.
4. Search for new devices and select "RYGHT OPEN" from the list.
5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.



Image: The RYGHY OPEN earbuds and case next to a smartphone showing Bluetooth pairing options.

### 3.3. Wearing the Earbuds

The RYGHY OPEN earbuds feature an extra-auricular design with Open Ear Technology. This means the speakers are positioned in front of your ear canal without obstructing it, allowing you to hear your audio while maintaining awareness of your surroundings.

- Gently place the earbud over your ear, ensuring the speaker rests comfortably in front of your ear canal.
- Adjust the ear hook for a secure and comfortable fit. The design is optimized to adapt perfectly to your ear, making them ideal for sports.

# S'adapte à votre oreille




Image: A diagram showing the proper placement of the RYGHT OPEN earbud on the ear.

## 4. Operating the Earbuds

### 4.1. Intuitive Touch Controls

The RYGHT OPEN earbuds are equipped with intuitive touch controls on each earbud, allowing you to manage your music and calls easily.



Image: A close-up view of the RYGHT OPEN earbud, indicating the touch-sensitive control area.

#### 4.2. Music Playback

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.

#### 4.3. Call Management

The earbuds feature dual microphones with ENC (Environmental Noise Cancellation) technology, which reduces ambient noise during calls, ensuring your voice is heard clearly by the person on the other end.

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

- **Activate Voice Assistant:** Press and hold either earbud for 3 seconds (when not on a call).

## 5. Maintenance

### 5.1. Cleaning

To ensure optimal performance and hygiene, regularly clean your earbuds and charging case:

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Avoid getting moisture in any openings.

### 5.2. Water Resistance (IPX4)

The RYGHT OPEN earbuds are IPX4 rated, meaning they are resistant to splashing water from any direction. This makes them suitable for workouts and outdoor activities where they might be exposed to sweat or light rain.

- Do not submerge the earbuds in water.
- Do not expose them to pressurized water or high-velocity water, such as showering or swimming.
- Ensure the earbuds are dry before placing them back into the charging case to prevent damage.

### 5.3. Storage

When not in use, store the earbuds in their charging case to protect them from dust, dirt, and physical damage.

## 6. Troubleshooting

If you encounter any issues with your RYGHT OPEN earbuds, please refer to the following common solutions:

### 6.1. Earbuds Not Pairing

- Ensure both earbuds are charged.
- Make sure Bluetooth is enabled on your device.
- Place the earbuds back into the charging case, close the lid, wait a few seconds, then open the lid to re-enter pairing mode.
- Forget/delete

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question