

[manuals.plus](#) /› [Samsung](#) /› [SAMSUNG Galaxy Tab S10+ Book Cover Keyboard AI Key User Manual](#)

Samsung EF-DX825UBEGUJ

SAMSUNG Galaxy Tab S10+ Book Cover Keyboard AI Key User Manual

Model: EF-DX825UBEGUJ

1. INTRODUCTION

This manual provides instructions for the proper use and care of your SAMSUNG Galaxy Tab S10+ Book Cover Keyboard AI Key. This accessory combines protection with enhanced productivity, offering a PC-like experience and quick access to AI assistance.

Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. PRODUCT OVERVIEW

2.1 Package Contents

- Book Cover Keyboard
- Detachable Back Cover
- Magnetic Platform

2.2 Key Features

- **AI Key Access:** A dedicated key provides quick access to AI assistance (Bixby or Gemini).
- **PC-Like Experience:** Full-size keycaps, function keys, and a trackpad, combined with DeX Mode, offer a desktop computing experience.
- **Detachable Design:** The magnetic design allows for easy attachment and detachment of the back cover and keyboard.
- **Adjustable Viewing Angles:** The hinge on the back cover allows for adjustment up to 150 degrees for comfortable viewing.
- **Wireless Keyboard Sharing:** Connect to compatible Galaxy devices to type or navigate seamlessly.



Figure 2.1: The SAMSUNG Galaxy Tab S10+ Book Cover Keyboard AI Key, shown with a tablet and S-Pen.

On-the-go flexibility



Figure 2.2: The detachable keyboard and back cover components, illustrating the modular design.

Your key to instant AI access



Figure 2.3: A close-up view of the dedicated AI Key on the keyboard, designed for quick access to AI functions.

3. SETUP INSTRUCTIONS

3.1 Attaching the Book Cover Keyboard

1. Align the back cover with the back of your Galaxy Tab S10+. The cover will magnetically snap into place.
2. Ensure the camera cutouts on the cover align perfectly with your tablet's cameras.
3. Attach the keyboard portion by aligning its POGO pins with the corresponding connectors on the tablet's side. The keyboard will magnetically connect.



Figure 3.1: The Galaxy Tab S10+ with the Book Cover Keyboard fully attached, viewed from the side.

3.2 S-Pen Storage

The back cover features a dedicated slot for secure S-Pen storage. Simply place your S-Pen into the designated area on the back cover. The magnetic attachment will hold it in place.



Figure 3.2: The back of the Book Cover, showing the integrated slot for S-Pen storage.

3.3 Initial AI Key Setup

To utilize the AI Key functionality, ensure your Galaxy Tab S10+ is connected to a network and you are logged into your Samsung Account for Bixby, or your Google Account for Gemini. You may need to download or update the Google Gemini app to the latest version for full functionality.

4. OPERATING INSTRUCTIONS

4.1 Using the Keyboard and Trackpad

Once the keyboard is attached, it functions like a standard PC keyboard. Use the full-size keycaps for typing and the integrated trackpad for navigation. The keyboard automatically activates when connected.



Figure 4.1: A user demonstrating the PC-like typing experience on the Book Cover Keyboard.

4.2 Activating the AI Key

Press the dedicated AI Key on the keyboard to instantly access Bixby or Gemini. You can then input voice commands or type prompts for various tasks, such as web searches, scheduling, and more.

4.3 Adjusting Viewing Angles

The back cover's integrated hinge allows you to adjust the tablet's viewing angle up to 150 degrees. Simply fold the back cover to your desired position to achieve optimal comfort for various activities.

Versatile viewing comfort




Figure 4.2: The tablet positioned at an adjustable viewing angle using the integrated kickstand.

4.4 Wireless Keyboard Sharing

To use Wireless Keyboard Sharing, ensure your Galaxy Tab S10+ and the compatible Galaxy smartphone (running One UI 3.1 or above) are logged into the same Samsung account. Up to 3 mobile devices can be connected for seamless typing and navigation.

Enhance your productivity with wireless sharing




Figure 4.3: Demonstrating Wireless Keyboard Sharing, where the tablet's keyboard is used to control a connected Galaxy smartphone.

4.5 DeX Mode

When the keyboard is attached, you can activate DeX Mode on your Galaxy Tab S10+ for a full desktop-like interface, optimizing your productivity with multiple windows and a familiar PC layout.

5. MAINTENANCE

5.1 Cleaning

- Gently wipe the surface of the Book Cover Keyboard with a soft, lint-free cloth.
- For stubborn marks, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not use harsh chemicals, solvents, or abrasive materials, as these can damage the finish.

5.2 Storage

When not in use, keep the Book Cover Keyboard attached to your tablet to protect both devices. Store in a cool, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

6.1 Keyboard Not Responding

- Ensure the keyboard is securely attached to the tablet via the POGO pins.
- Detach and reattach the keyboard to reset the connection.
- Restart your Galaxy Tab S10+.
- Check for any software updates for your tablet.

6.2 AI Key Not Functioning

- Verify that your tablet has an active internet connection.
- Confirm you are logged into your Samsung Account (for Bixby) or Google Account (for Gemini).
- Check if the Bixby or Gemini app is updated to the latest version.
- Restart your tablet and try again.

6.3 Wireless Keyboard Sharing Issues

- Ensure both devices (tablet and smartphone) are logged into the same Samsung account.
- Verify that the connected smartphone is running One UI 3.1 or above.
- Check Bluetooth settings on both devices to ensure they are discoverable and paired correctly.
- Restart both devices.

7. SPECIFICATIONS

Feature	Detail
Brand	Samsung
Model Number	EF-DX825UBEGUJ
Item Weight	1.13 pounds
Product Dimensions (LxWxH)	7.61 x 11.26 x 0.58 inches
Color	Black
Compatible Devices	Galaxy Tab S10+
Form Factor	Cover with integrated keyboard
Shell Type	Hard
Power Source	Battery Powered (via tablet connection)

8. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the official Samsung website or contact Samsung customer service directly. Keep your proof of purchase for warranty claims. Official Samsung Support: www.samsung.com/us/support/

