

[Manuals.plus](#) /

> [Accutime](#) /

> Minions Kids Watch – Flashing Dial Lights, LCD Display, Adjustable Comfortable Strap, Collectible Tin – Perfect for Boys and Girls User Manual

## Accutime DMF4063AZ

# Minions Kids Watch Instruction Manual

Model: DMF4063AZ

## 1. INTRODUCTION

Thank you for choosing the Minions Kids Watch. This watch is designed to be a fun and practical accessory for children, featuring a clear LCD display, exciting multi-colored flashing dial lights, and durable construction with vibrant Minions artwork. This manual will guide you through the setup, operation, and care of your new watch.



Image 1.1: Front view of the Minions Kids Watch, showcasing its vibrant design and LCD display.

## Key Features:

- Fun Flashing Dial Lights: Multi-colored lights activate to add excitement.
- Easy-to-Read LCD Display: Clear digital display for simple time-telling.
- Durable and Stylish Design: Metallic gradient colored plastic case with Minions artwork.
- Comfortable Adjustable Strap: Printed plastic strap designed for a secure and comfortable fit.
- Safe and Kid-Friendly: Crafted from child-safe materials with a secure buckle.

## 2. SETUP

### 2.1 Unboxing

Your Minions Kids Watch comes packaged in a collectible tin. Carefully open the tin to retrieve the watch and any accompanying documentation.



Image 2.1: The Minions Kids Watch presented within its collectible tin packaging.

## 2.2 Initial Battery Check

The watch includes 1 Lithium Ion battery, pre-installed. The watch should be ready for immediate use upon unboxing. If the display is dim or unresponsive, refer to the Troubleshooting section.

## 2.3 Adjusting the Strap

The plastic strap is adjustable to fit various wrist sizes. To adjust, simply thread the strap through the silver metal buckle and secure it using the colored plastic keepers. Ensure the fit is snug but comfortable.



Image 2.2: Close-up view of the watch strap and buckle, illustrating the adjustable design.

### **3. OPERATING INSTRUCTIONS**

#### **3.1 Reading the Time**

The watch features a clear LCD display that shows the time in a digital format (HH:MM). The time is continuously displayed.

#### **3.2 Activating Flashing Dial Lights**

The Minions Kids Watch is equipped with multi-colored flashing dial lights. To activate these lights, press the button located on the side of the watch case. The lights will flash for a short duration and then automatically turn off.





Image 3.1: The watch face with its multi-colored flashing dial lights illuminated.

### **3.3 Setting the Time**

Specific instructions for setting the time are typically found on a small insert within the packaging or can be inferred from the watch's buttons. Generally, digital watches have one or more buttons for setting. Look for a recessed button that may require a small pointed object (like a pen tip) to press, or a combination of side buttons. Pressing and holding a button usually enters time-setting mode, then subsequent presses adjust hours/minutes.

## **4. MAINTENANCE**

### **4.1 Cleaning**

To clean the watch, gently wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish and artwork. Do not submerge the watch in water.

### **4.2 Battery Replacement**

The watch uses 2 x LR41 (1.5V) batteries. When the display becomes dim or the lights stop flashing, it may be time to replace the batteries. Battery replacement should ideally be performed by an adult. Locate the battery compartment on the back of the watch, typically secured by small screws. Use a small screwdriver to open, replace the batteries, and securely close the compartment.



Image 4.1: The back of the Minions Kids Watch, indicating the location of the battery compartment and product information.

## 5. TROUBLESHOOTING

### 5.1 Watch Not Displaying Time / Lights Not Flashing

- Check Battery: The battery may be depleted. Replace with new LR41 (1.5V) batteries.
- Battery Orientation: Ensure batteries are inserted with the correct polarity.

### 5.2 Time Not Keeping Accurate

- Reset Time: Re-set the time following the instructions in Section 3.3.
- Accidental Button Presses: For young children, buttons may be accidentally pressed, altering the time. Ensure the child understands not to press the setting buttons frequently.
- Low Battery: A low battery can sometimes affect timekeeping accuracy. Replace the batteries.

## 6. SPECIFICATIONS

Attribute	Detail
-----------	--------

Model Number	DMF4063AZ
Brand	Accutime
Display Type	LCD Digital
Battery Type	2 x LR41 (1.5V) Lithium Ion (included)
Case Material	Metallic Gradient Colored Plastic
Strap Material	Printed Plastic
Department	Unisex Kids
Package Dimensions	3.86 x 3.19 x 3.11 inches
Weight	4 ounces

## 7. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Minions Kids Watch, please contact the manufacturer, Accutime. While specific warranty details are not provided in this manual, Accutime typically offers support for their products. Please retain your proof of purchase for any warranty claims. You can visit the Accutime Store for more information:[Accutime Store on Amazon](#)