

Mattel JGB97

Mattel Jurassic World Rebirth Tyrannosaurus Rex Micro Adventure Playset

Model: JGB97

INTRODUCTION

The Mattel Jurassic World Rebirth Tyrannosaurus Rex Micro Adventure Playset offers a portable and interactive play experience. This playset is designed as a Tyrannosaurus Rex head that opens to reveal a miniature world inspired by the Jurassic World Rebirth movie settings. It features multiple interactive elements and includes micro figures for imaginative play.

This manual provides instructions for the proper setup, operation, and care of your playset.

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

- Keep small parts away from young children to prevent choking.
- Adult supervision is recommended during play.
- Inspect the playset regularly for any damage or loose parts. Discontinue use if damage is found.

WHAT'S IN THE BOX

- 1 Jurassic World Micro Adventure Tyrannosaurus Rex Playset
- 3 Micro Figures

Colors and decorations of the playset and figures may vary.

SETUP

1. **Unpack the Playset:** Carefully remove all components from the packaging.
2. **Open the T. Rex Head:** The playset is designed as a T. Rex head. Gently prop open the T. Rex head to a 90-

degree angle to reveal the miniature playset environment inside.



Image: The T. Rex head opens to reveal the playset environment.

3. **Place Micro Figures:** The included micro figures can be securely placed on various pegs located throughout the playset environment. This allows for creative storytelling and interaction within the miniature world.



Image: Placing a micro figure onto a peg inside the playset.

OPERATING THE PLAYSET

The playset features several finger-activated interactive elements to enhance play.

1. **Interactive Features:** Explore the four environmental features spread throughout the T. Rex playset. These features are activated by finger interaction, allowing you to create dynamic scenarios for your micro figures.



Move skeleton to trap mini dinosaur inside!

Image: Activating a skeleton trap feature within the playset.



Slide the dino head down the waterfall!

Image: Interacting with the waterfall slide feature.

2. **Chomping Action:** When the playset is folded up, a tab at the back of the T. Rex head can be pressed to activate a chomping action, adding another layer of fun.




Image: Activating the T. Rex chomping feature when the playset is closed.

MAINTENANCE

- **Cleaning:** To clean the playset, wipe it with a damp cloth. Do not submerge in water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, fold the playset neatly and store it in a dry, cool place away from direct sunlight. Ensure all micro figures are stored safely to prevent loss.

TROUBLESHOOTING

- **Missing Micro Figures:** Due to their small size, micro figures can be easily misplaced. Ensure they are stored securely after each play session. Replacement figures are not typically available separately.
- **Features Not Functioning:** If an interactive feature is not working, check for any obstructions or debris. Ensure the playset is fully open or closed as required for specific actions.
- **Playset Not Closing Properly:** Ensure all micro figures and any movable parts are correctly positioned within the playset before attempting to close it. Do not force the playset shut.

SPECIFICATIONS

Feature	Detail
Brand	Mattel
Model Name	Mattel Jurassic World Micro Compact Assortment T rex
Model Number	JGB97
UPC	194735310074
Item Dimensions (L x W x H)	4.5"L x 4"W x 3.66"H
Item Weight	9.6 ounces
Material Type	Plastic
Recommended Age	4 years and up
Number of Pieces	3 (Playset + 3 Micro Figures)
Operation Mode	Manual

WARRANTY AND SUPPORT

This product comes with no manufacturer warranty. For any product-related inquiries or support, please visit the official Mattel website or contact their customer service department.

You can find more information and contact details at:www.mattel.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question