

[Manuals.plus](#) /

> [Hot Wheels](#) /

> Hot Wheels Monster Trucks Remote-Control Vehicle: Rageasaur RC Instruction Manual

Hot Wheels JBH03

Hot Wheels Monster Trucks Remote-Control Vehicle: Rageasaur RC Instruction Manual

Model: JBH03

INTRODUCTION

This manual provides essential information for the safe and optimal use of your Hot Wheels Monster Trucks 1:15 Scale Rageasaur RC vehicle. Please read these instructions thoroughly before operating the product.



Image: The Hot Wheels Monster Trucks Rageasaur RC vehicle, a green dinosaur-themed truck with large orange and black wheels, is shown alongside its black remote control.

SETUP

1. Unpacking

Carefully remove all components from the packaging. Ensure you have the Hot Wheels Monster Trucks Rageasaur RC vehicle and the remote control.

2. Remote Control Battery Installation

The remote control requires 2 AAA batteries (not included). To install:

1. Locate the battery compartment on the back of the remote control.
2. Open the battery compartment cover.
3. Insert 2 new AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

3. Vehicle Charging

The Rageasaur RC vehicle features a built-in rechargeable battery. To charge:

1. Locate the charging port or compartment on the underside of the vehicle.
2. Open the compartment to access the integrated USB charging cable.
3. Connect the USB cable to a standard USB power source (e.g., computer, USB wall adapter).
4. The charging indicator light will illuminate. Charging typically takes approximately 30 minutes.
5. Once fully charged, disconnect the USB cable and securely store it back in the vehicle's compartment.



Image: The underside of the Rageasaur RC vehicle is shown, highlighting the battery compartment and the integrated USB charging cable.

4. Pairing the Remote Control

The vehicle and remote control are designed to pair automatically upon powering on. Ensure both the vehicle and remote control have fresh batteries or are fully charged before use.

1. Power On/Off

Turn on the vehicle using the power switch, usually located on the underside. Turn on the remote control. The indicator lights on both devices should confirm they are active.

2. Basic Controls

- **Forward/Backward:** Use the left joystick or button on the remote to move the vehicle forward or backward.
- **Turning:** Use the right joystick or button to steer the vehicle left or right.

3. Special Features: Wheelie Stunt

The Rageasaur RC vehicle is capable of performing an impressive wheelie stunt. Press the designated stunt button on the remote control to activate this feature. The vehicle will momentarily lift onto its rear wheels and spin.

4. Driving Environment

The vehicle's Grip Action Tires are designed to perform on a variety of surfaces, both indoors and outdoors. For optimal performance and to prevent damage, avoid driving in water, mud, or excessively dusty conditions.

MAINTENANCE

1. Cleaning

To clean the vehicle, wipe it with a soft, dry cloth. Do not use water or chemical cleaners, as this may damage the electronic components.

2. Battery Care

- Always ensure the vehicle's built-in battery is fully charged before extended play.
- For the remote control, remove AAA batteries if the toy will not be used for a prolonged period to prevent leakage and corrosion.
- Do not attempt to replace the vehicle's built-in battery.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Vehicle does not respond to remote control.	Low batteries in vehicle or remote; vehicle/remote not powered on; pairing issue.	Ensure vehicle is charged and remote has fresh AAA batteries. Verify both are powered on. Turn both off and on again to re-establish connection.
Vehicle moves slowly or inconsistently.	Low vehicle battery.	Recharge the vehicle's built-in battery.
Limited range of operation.	Interference; low remote control batteries.	Operate in an open area away from other electronic devices. Replace remote control batteries.

SPECIFICATIONS

- **Brand:** Hot Wheels
- **Model:** JBH03 (Rageasaur RC)
- **Scale:** 1:15
- **Product Dimensions:** 12.99 x 7.87 x 9.06 inches
- **Item Weight:** 1.72 pounds
- **Recommended Age:** 4 years and up
- **Vehicle Battery:** Built-in rechargeable (charged via integrated USB cable)
- **Remote Control Batteries:** 2 AAA batteries (not included)

WARRANTY AND SUPPORT

Specific warranty details are not provided within this instruction manual. For warranty information, product support, or to contact the manufacturer, please refer to the official [Hot Wheels brand store](#) or the contact information provided on the product packaging. The manufacturer of this product is Mattel.