



Manuals.plus /

› Skullcandy /

› Skullcandy Crusher ANC 2 Wireless Over-Ear Bluetooth Headphones User Manual

## Skullcandy S6CAW-S986

# Skullcandy Crusher ANC 2 Wireless Over-Ear Bluetooth Headphones

Model: S6CAW-S986 | Brand: Skullcandy

## INTRODUCTION

---

The Skullcandy Crusher ANC 2 headphones offer a comprehensive audio experience with patented Multi-Sensory Bass, adjustable Active Noise Cancelling, and hands-free voice control. Designed for immersive sound, these headphones provide comfort and advanced features for various listening environments.

## WHAT'S IN THE BOX

---

- Crusher® ANC 2 Wireless Headphones
- USB-C Charging Cable
- Back-up AUX Cable
- Protective Travel Bag
- Quick Start & User Guides



Image: The Skullcandy Crusher ANC 2 headphones displayed with their included accessories, including cables and a travel bag.

## KEY FEATURES

---

- **Patented Crusher Sensory Bass Technology:** Delivers immersive, adjustable bass that can be felt, enhancing music and movie experiences.
- **Active Noise Cancellation (ANC):** Advanced adjustable 4-mic digital ANC allows users to control ambient sound levels for focused listening.
- **Extended Battery Life:** Up to 50 hours of battery life with ANC on, with Rapid Charge providing 4 hours of listening from a 10-minute charge.
- **Skull-iQ App and Hands-Free Voice Control:** Enables voice commands for calls, volume, track control, and access to advanced features via the Skull-iQ App.

- **Multipoint Pairing:** Connect to multiple devices simultaneously for seamless switching.
- **Personal Sound by Mimi@:** Customizes audio profiles to individual hearing preferences for an optimized listening experience.

# CRUSHER<sup>®</sup> ANC 2



**50 HOURS BATTERY +  
RAPID CHARGE**



**CRUSHER ADJUSTABLE  
SENSORY BASS**



**ADJUSTABLE 4-MIC  
ACTIVE NOISE  
CANCELING**



**PERSONAL SOUND BY  
MIMI<sup>®</sup>**



**MULTIPOINT PAIRING**



**HANDS-FREE VOICE  
CONTROL**

Image: A visual representation highlighting the main features of the Crusher ANC 2 headphones, including battery life, bass, ANC, and voice control.

## SETUP

### Charging Your Headphones

Before first use, fully charge your Crusher ANC 2 headphones. Connect the included USB-C charging cable to the USB-C port on the headphones and the other end to a compatible USB power source. The LED indicator will show charging status.

### Bluetooth Pairing

1. Ensure your headphones are powered off.

2. Press and hold the main power button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, computer, etc.), enable Bluetooth and search for "Crusher ANC 2" in the list of available devices.
4. Select "Crusher ANC 2" to connect. The LED indicator will turn solid blue when successfully paired.



Image: A side view of the Skullcandy Crusher ANC 2 headphones, showing the power button and charging port.

## OPERATING INSTRUCTIONS

---

### Controls Overview

The Crusher ANC 2 headphones feature intuitive controls located on the earcups. Familiarize yourself with the button layout for optimal use.

- **Power Button:** Power on/off, pairing mode.
- **Volume Up/Down:** Adjust audio volume.

- **Multi-function Button:** Play/pause, answer/end calls, track control (double-press for next, triple-press for previous).
- **Crusher Bass Slider:** Adjust the intensity of the sensory bass.
- **ANC Button:** Toggle Active Noise Cancellation modes (ANC On, Ambient Mode, ANC Off).



Image: A front view of the Skullcandy Crusher ANC 2 headphones, highlighting the various control buttons on the earcup.

### Active Noise Cancellation (ANC) and Ambient Mode

Press the ANC button to cycle through the noise cancellation modes:

- **ANC On:** Blocks out most ambient noise for an immersive listening experience.
- **Ambient Mode:** Allows you to hear your surroundings while still enjoying your audio, useful for awareness.
- **ANC Off:** Disables noise cancellation.

### Crusher Bass Adjustment

Use the dedicated slider on the earcup to increase or decrease the intensity of the Crusher Sensory Bass. Adjust it to your preference for a subtle rumble or a powerful, bone-rattling experience.

### Hands-Free Voice Control (Skull-iQ App)

Download the Skull-iQ App to unlock full voice control capabilities. Once set up, you can use voice commands to manage playback, calls, and activate other features without touching your device.

Your browser does not support the video tag.

Video: Official product video demonstrating the features and immersive experience of the Skullcandy Crusher ANC 2 headphones, including the adjustable bass and noise cancellation.

## MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the headphones in the provided protective travel bag to prevent scratches and damage.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in constant use.
- **Water Resistance:** These headphones are not water resistant. Avoid exposure to moisture, rain, or sweat.

## TROUBLESHOOTING

---

### Headphones not pairing:

Ensure headphones are in pairing mode (flashing blue/red LED). Check your device's Bluetooth settings and try forgetting the device and re-pairing. Make sure headphones are charged.

### No sound or low volume:

Check volume levels on both headphones and the connected device. Ensure the headphones are properly connected via Bluetooth or AUX cable. Try restarting both devices.

### ANC not working effectively:

Ensure ANC is activated (not in Ambient Mode or Off). Check that the earcups form a good seal around your ears. Adjust the fit if necessary.

### Crusher Bass not felt:

Adjust the Crusher Bass slider to increase the intensity. Ensure the audio source has sufficient bass content.

## SPECIFICATIONS

---

<b>Model Name</b>	Crusher ANC 2
<b>Model Number</b>	S6CAW-S986
<b>Connectivity Technology</b>	Wireless (Bluetooth 5.0)
<b>Noise Control</b>	Active Noise Cancellation
<b>Battery Life</b>	Up to 50 Hours (with ANC on)
<b>Charging Time</b>	Approx. 1 Hour (for full charge)
<b>Headphones Jack</b>	3.5 mm Jack (for wired connection)
<b>Impedance</b>	32 Ohm
<b>Frequency Response</b>	20 KHz (Note: This is likely the upper limit, typical range is 20Hz-20kHz)
<b>Item Weight</b>	0.33 Kilograms (11.7 ounces)
<b>Dimensions</b>	7.87 x 6.3 x 9.37 inches
<b>Material</b>	Plastic
<b>Water Resistance Level</b>	Not Water Resistant

## WARRANTY AND SUPPORT

---

The Skullcandy Crusher ANC 2 headphones come with a 1-Year Limited Warranty. For warranty claims, technical support, or additional assistance, please visit the official Skullcandy support website or contact their customer service.

For more information and detailed support, please visit: [Skullcandy Support](#)