

Logitech 910-007409

Logitech POP Mouse User Manual

Model: 910-007409

1. INTRODUCTION

The Logitech POP Mouse is a compact and portable wireless Bluetooth mouse designed for versatile use across multiple devices. It features programmable buttons, quiet clicks, and a Smartwheel for efficient scrolling. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your POP Mouse.



Image: The Logitech POP Mouse in Rose color, showcasing its compact and contoured design.

2. WHAT'S IN THE BOX

Upon unboxing your Logitech POP Mouse, ensure all the following items are present:

- Logitech POP Mouse
- 1 x AA battery (pre-installed)
- User documentation
- Sticker

In the box



**Responsible
Packaging**

Image: The Logitech POP Mouse and a single AA battery, representing the contents of the product packaging.

3. SETUP

3.1. Battery Installation

The Logitech POP Mouse comes with one AA battery pre-installed. To access or replace the battery:

1. Gently pull the top cover of the mouse upwards from the rear to detach it. The cover is held by magnets.
2. Locate the AA battery compartment.

3. Insert or replace the AA battery, ensuring correct polarity.
4. Align the top cover and gently press it back into place until it snaps magnetically.





Image: A diagram illustrating the internal components of the Logitech POP Mouse, including the battery compartment and the USB receiver slot.

3.2. Initial Device Pairing (Bluetooth)

The POP Mouse connects wirelessly via Bluetooth. Follow these steps to pair it with your device:

1. Turn on the mouse using the On/Off switch located on the bottom.
2. Press and hold the Easy-Switch button (circular button on the bottom of the mouse) for 3 seconds until the indicator light starts blinking rapidly. This indicates pairing mode.
3. On your computer, tablet, or smartphone, open Bluetooth settings.
4. Select "Logitech POP Mouse" from the list of available devices.
5. Follow any on-screen prompts to complete the pairing process. The indicator light will turn solid for 5 seconds when connected.



Works with macOS, iPadOS, iOS



Image: The underside of the Logitech POP Mouse, highlighting the Easy-Switch button and the three indicator lights for multi-device pairing.

4. OPERATING THE MOUSE

4.1. Basic Functions

- **Left Click:** Standard selection and interaction.
- **Right Click:** Accesses contextual menus.
- **Smartwheel:** The scroll wheel offers two modes: precise, line-by-line scrolling for accuracy, and a faster, free-spinning mode for quickly navigating long documents or web pages.
- **Quiet Clicks:** The mouse features Silent Touch Technology, reducing click noise by over 90% compared to traditional mice, ideal for quiet environments.

Make a big impression on the quiet




With Silent Touch Technology

Image: A hand resting on the Logitech POP Mouse, demonstrating its comfortable grip and highlighting the quiet click feature.

4.2. Easy-Switch Between Devices

The POP Mouse can be paired with up to three different devices and allows for seamless switching between them:

1. Ensure the mouse is paired with all desired devices (refer to Section 3.2).
2. Press the Easy-Switch button on the bottom of the mouse to cycle through the connected devices. The indicator light will show which channel (1, 2, or 3) is currently active.



Works with macOS, iPadOS, iOS



Image: The underside of the Logitech POP Mouse, illustrating the Easy-Switch button and its corresponding indicator lights for managing multiple device connections.

5. CUSTOMIZATION WITH LOGI OPTIONS+ APP

Unlock the full potential of your POP Mouse by customizing its top button and other settings using the Logi Options+ App. This application is available for recent versions of Windows and macOS.

5.1. Customizable Top Button

The top button, by default, can be set to open an emoji menu. However, it can be reprogrammed to perform various actions:

- Launch applications (e.g., Spotify, Netflix)
- Access AI tools
- Perform system shortcuts (e.g., copy, paste, show desktop)
- Adjust brightness or volume

To customize:

1. Download and install the Logi Options+ App from the official Logitech website.
2. Open the app and select your POP Mouse.
3. Navigate to the 'Buttons' section and select the top button.
4. Choose your desired action from the available options.

Life is easier with shortcuts



Action Buttons save you time
with Logi Options+ App^[2]

Image: A user interacting with a computer, demonstrating the customizable action buttons of the Logitech POP Mouse via the Logi Options+ App.

6. MAINTENANCE

6.1. Battery Replacement

The Logitech POP Mouse is powered by a single AA battery, offering up to 2 years of battery life depending on usage. To replace the battery, follow the steps outlined in Section 3.1.

6.2. Cleaning

To maintain optimal performance and appearance, clean your mouse regularly:

- Use a soft, lint-free cloth slightly dampened with water or isopropyl alcohol.
- Avoid harsh chemicals or abrasive materials.
- Ensure no liquid enters the mouse's openings.

7. TROUBLESHOOTING

7.1. Connectivity Issues

- **Mouse not connecting:** Ensure the mouse is turned on and the battery has sufficient charge. Re-enter pairing mode by holding the Easy-Switch button for 3 seconds. Check your device's Bluetooth settings to ensure it's discoverable and try re-pairing.
- **Intermittent connection:** Move the mouse closer to your device. Ensure there are no large metal objects or other wireless devices causing interference.

7.2. Cursor Movement Issues

- **Erratic cursor:** Clean the optical sensor on the bottom of the mouse with a soft, dry cloth. Ensure you are using the mouse on a suitable surface; highly reflective or transparent surfaces may affect tracking.
- **No cursor movement:** Check battery level. Ensure the mouse is connected to the correct device channel via the Easy-Switch button.

8. SPECIFICATIONS

Feature	Detail
Model Number	910-007409
Connectivity	Bluetooth
Multi-Device Support	Up to 3 devices (Easy-Switch)
Movement Detection Technology	Optical
DPI Range	1000 to 4000
Battery Type	1 x AA (included)
Battery Life	Up to 2 years (may vary)
Item Weight	4.6 ounces
Package Dimensions	4.88 x 3.5 x 1.77 inches
Compatible Operating Systems	Chrome OS, Windows, iPadOS, macOS, Linux







Special Features	Lightweight, Portable, Soundless (Silent Touch Technology), Customizable Button
Material	Plastic (37% to 68% recycled plastic, depending on color)



Image: A diagram illustrating the physical dimensions of the Logitech POP Mouse.

9. WARRANTY AND SUPPORT

For warranty information, technical support, and additional resources, please visit the official Logitech support website. The user documentation included in the box also contains specific warranty details for your region. You can find further assistance and product information at the [Logitech Store](#).

	<p>Logitech POP Keys and POP Mouse Setup and Customization Guide</p> <p>A comprehensive guide to setting up, pairing, and customizing your Logitech POP Keys keyboard and POP Mouse, including multi-device setup and emoji key customization.</p>
	<p>Logitech G403 HERO Gaming Mouse Setup and Features</p> <p>A comprehensive guide to setting up and customizing the Logitech G403 HERO gaming mouse, covering installation, button programming, RGB lighting effects with LIGHTSYNC technology, and weight customization.</p>
	<p>Logitech G402 Hyperion Fury Gaming Mouse Setup Guide</p> <p>Setup guide for the Logitech G402 Hyperion Fury gaming mouse. Learn how to connect, customize buttons, and configure settings using Logitech Gaming Software.</p>
	<p>Logitech MX Master 3S for Mac: Getting Started and Features Guide</p> <p>Get started with your Logitech MX Master 3S for Mac wireless mouse. This guide covers detailed setup, Bluetooth and Easy-Switch pairing, MagSpeed scroll wheel functionality, thumb wheel and gesture button customization, app-specific settings, Logitech Flow for multi-computer use, battery charging and status, and cleaning instructions.</p>
	<p>Logitech MX Master 3S for Business: Performance Wireless Mouse - Datasheet</p> <p>Discover the Logitech MX Master 3S for Business, a performance wireless mouse designed for enhanced productivity, comfort, and security. Features include 8000 DPI tracking, MagSpeed scrolling, Logi Bolt connectivity, and ergonomic design. View specifications and compatibility.</p>
	<p>Logitech Pop Combo Mouse and Keyboard: Installation and Setup Guide</p> <p>Comprehensive guide to installing, setting up, and customizing your Logitech Pop Combo Mouse and Keyboard, including multi-device pairing and emoji keycap personalization.</p>