Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweiko WX000125AAK-1

Sweiko Bunk Bed with Ladder, 90x200cm, White Metal Frame - Instruction Manual

Model: WX000125AAK-1

Introduction

This manual provides comprehensive instructions for the assembly, safe use, and maintenance of your Sweiko Bunk Bed, model WX000125AAK-1. This white metal bunk bed features a ladder and is designed for mattresses measuring 90x200cm. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

WARNING: Failure to follow these safety instructions could result in serious injury.

- Do not exceed the maximum weight capacity of**120 kg** for the entire bed structure.
- Exercise caution during assembly and handling due to potential sharp edges on metal components.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten fasteners as needed.
- Only use mattresses of the recommended thickness (10-15 cm) and size (90x200cm) to ensure proper fit and safety rail effectiveness.
- The top bunk is not suitable for children under 6 years of age.
- Always use the ladder for access to the top bunk. Do not jump on or off the bed.
- Prohibit horseplay on or under the bed.
- Ensure the bed is placed on a level surface.

Product Specifications

Feature	Specification
Brand	Sweiko
Model Number	WX000125AAK-1

Color	White
Material	Metal
Overall Dimensions (L x W x H)	203 x 94.5 x 140 cm
Product Weight	38.1 kg
Maximum Weight Capacity	120 kg
Recommended Mattress Size	90x200cm (Twin)
Recommended Mattress Thickness	10-15 cm
Number of Packages	2
Assembly Required	Yes

Components List

Before assembly, please ensure all parts are present and undamaged. Refer to the included assembly diagram for specific part identification. The bed is shipped in two packages; both may not arrive on the same day.

- Bed Frame Components (various metal tubes and connectors)
- Ladder Components
- Slatted Bed Bases (for both upper and lower bunks)
- Hardware Pack (screws, bolts, nuts, Allen key)
- Instruction Manual

Setup and Assembly Instructions

Assembly requires self-installation. It is recommended to have two adults for assembly. Clear a spacious area for assembly and lay out all components. Follow the numbered steps in the provided assembly diagram.



Image: An assembled Sweiko Bunk Bed in a white metal frame, featuring a ladder and ready for use with mattresses and bedding. This provides an overview of the final product.

Step 1: Unpacking and Inspection

Carefully unpack all components from both packages. Verify that all parts listed in the components list are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer service for assistance.



Image: Overview of the bed frame components, showing the metal structure before full assembly. This image helps identify the main parts.

Step 2: Assembling the Lower Bunk Frame

Begin by connecting the side rails and end frames for the lower bunk. Ensure all bolts are finger-tightened initially. Do not fully tighten until the entire frame is assembled.

Step 3: Assembling the Upper Bunk Frame

Repeat the process for the upper bunk frame, connecting its side rails and end frames. Again, only finger-tighten bolts at this stage.

Step 4: Connecting Upper and Lower Bunks

Carefully lift the upper bunk frame and align it with the designated connection points on the lower bunk frame. Secure them using the provided bolts. This step may require two people.



Image: Close-up view of the metal frame connections, illustrating how the upper and lower bunk sections are joined. This highlights the sturdy construction.

Step 5: Attaching the Ladder

Attach the ladder to the designated side of the bunk bed. Ensure it is securely fastened at both the top and bottom connection points. Verify that the ladder is stable and does not wobble.




Image: Detail of the ladder attached to the bunk bed, showing its integration with the frame. This image confirms the ladder's position and design.

Step 6: Installing the Slatted Bases

Place the metal slatted bases onto the support rails of both the upper and lower bunks. Ensure they are evenly distributed and securely seated. These slats provide mattress support.



Image: Close-up of the metal slatted base, demonstrating the support structure for the mattress. This shows the individual slats and their attachment points.

Step 7: Final Tightening and Inspection

Once all components are in place, systematically tighten all bolts and screws using the provided Allen key. Do not overtighten. Perform a final inspection to ensure all connections are secure, the bed is stable, and there are no loose parts or sharp edges exposed.




Image: Technical drawing of the Sweiko Bunk Bed with detailed dimensions in centimeters. This provides a clear visual reference for the overall size and key measurements.

Operating Instructions (Proper Use)

- Ensure mattresses are correctly sized (90x200cm) and placed within the bed frame.
- Always use the ladder to access the top bunk. Do not climb on the side rails or end frames.
- Do not allow more than one person on the top bunk at a time.
- Avoid hanging items from the bed frame that could pose a strangulation hazard.
- Regularly check the stability of the bed and the tightness of all fasteners.

Maintenance

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Fasteners:** Periodically (e.g., every 3-6 months) check all bolts and screws and re-tighten them as necessary to maintain structural integrity.
- **Inspection:** Regularly inspect the bed for any signs of wear, damage, or loose components. Address any issues

promptly.

- **Moving the Bed:** If you need to move the bed, lift it rather than dragging it to prevent damage to the frame or flooring. For significant moves, partial disassembly may be required.

Troubleshooting

Problem	Possible Cause	Solution
Bed feels wobbly or unstable	Loose fasteners; uneven floor surface.	Check and tighten all bolts and screws. Ensure the bed is on a level surface; use shims if necessary.
Squeaking noises	Loose connections; friction between metal parts.	Tighten all fasteners. Apply a small amount of silicone spray or lubricant to connection points if squeaking persists.
Missing parts during assembly	Parts shipped in separate packages; oversight during unpacking.	Verify both packages have arrived. Double-check all packaging materials. Contact customer service if parts are genuinely missing.

Warranty and Support

While specific warranty details are not provided in this manual, Sweiko products are typically covered by a manufacturer's warranty against defects in materials and workmanship. Please retain your proof of purchase for any warranty claims. For further assistance, missing parts, or warranty inquiries, please contact Sweiko customer service through your retailer or the official Sweiko website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DB5MFMTL

More documents and user manuals: **https://manuals.plus/**