

PARTPHONER STR-FP-0149

PARTPHONER Industrial Floor Lamp User Manual

Model: STR-FP-0149

1. INTRODUCTION

Thank you for purchasing the PARTPHONER Industrial Floor Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read these instructions carefully before assembly and operation, and retain them for future reference.

This adjustable floor lamp features a rustic farmhouse design with an aged brown finish, suitable for various interior styles. It includes a dimmable LED bulb with multiple color temperatures and is controllable via a rotary switch or a remote control.

2. SAFETY INFORMATION

- Ensure the power is off before installation, cleaning, or replacing the bulb.
- Do not connect the electricity until your lamp is fully assembled.
- This lamp is designed for indoor use only. Do not expose to water or high humidity.
- Use only the specified bulb type and wattage (E26 base, 8W LED included, max 60W incandescent equivalent).
- Keep the lamp away from flammable materials.
- Do not attempt to modify or repair the lamp yourself. Contact qualified personnel for service.
- Ensure the base is stable on a flat surface to prevent tipping.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before assembly.

- Lamp Base
- Multiple Pole Sections
- Lamp Head with Shade
- 8W Dimmable LED Bulb (E26)
- Remote Control (AAA batteries not included)

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your floor lamp:

1. **Step 1:** Place the pole into the base and screw it tight.
2. **Step 2:** Screw the remaining pole sections together one by one, ensuring they are securely fastened.
3. **Step 3:** Tighten the screw to fix the assembled poles.
4. **Step 4:** Remove the wire protection cover, then pass the wire through the hole to tighten the pole.
5. **Step 5:** Fix the lampshade to the lamp head.
6. **Step 6:** Install the included LED bulb into the E26 socket.




Figure 4.1: Lamp Assembly Steps



Figure 4.2: Key Components: Rotary Switch, Height Adjustable Knob, Solid Metal Base

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Rotary Switch:** Turn the rotary switch located on the lamp head clockwise to turn the lamp on, and counter-clockwise to turn it off.
- **Remote Control:** Press the power button (**On/Off**) on the remote control to turn the lamp on or off.

5.2 Adjusting Height and Shade Angle

The lamp's height can be adjusted between 52 inches and 65.32 inches. Loosen the height adjustable knob on the pole, slide the upper section to your desired height, and then tighten the knob securely. The lamp head can swivel 220° to direct light as needed.



Flexible Standing Lamp-Adjustable lamp Height and rotatable lampshade.

Figure 5.1: Flexible Height and Shade Adjustment

5.3 Dimmable LED Bulb and Color Temperatures

The included 8W LED bulb offers 1000 lumens of brightness and features 3 color temperatures (3000K, 4000K, 5000K-6500K) and 6 light levels. It also includes 5 scene light modes.

- **Brightness Adjustment:** Use the brightness increase key (+) and decrease key (-) on the remote control.
- **Color Temperature Change:** Use the color temperature switch (K) on the remote control to cycle through 3000K (Warm light), 4000K (Natural white), and 5000K-6500K (Daylight white).
- **Scene Modes:** The remote control includes buttons for various scene modes such as Small Night Mode, Reading Mode, and Operating Mode.

Dimmable Color Temperatures & Brightness Bulb Include



Figure 5.2: Dimmable Color Temperatures



Figure 5.3: Diversified Lighting Modes

5.4 Remote Control Functions

The remote control allows for convenient operation of the lamp. It requires AAA batteries (not included).

- **Timing:** Set a timer for the lamp to turn off automatically.
- **On/Off:** Power the lamp on or off.
- **Brightness Increase/Decrease:** Adjust light intensity.
- **Color Temperature Increase/Decrease:** Fine-tune color temperature.
- **Color Temperature Switch (K):** Cycle through preset color temperatures.
- **Scene Modes:** Small Night Mode, Reading Mode, Operating Mode, etc.



Figure 5.4: Remote Control Functions

5.5 Timer Setting

Use the timer button on the remote control to set the lamp to turn off after a specified duration, typically 1 hour.



Figure 5.5: 1 Hour Timer Setting

6. MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Wipe the lamp with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Ensure the lamp is unplugged and cool before replacing the bulb. Use an E26 base LED bulb, not exceeding 60W equivalent.
- **Remote Control Batteries:** Replace AAA batteries in the remote control when its range or responsiveness decreases.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lamp does not turn on	1. Power cord not plugged in. 2. Bulb is loose or faulty. 3. Power outlet is not working. 4. Remote control batteries are dead.	1. Ensure the power cord is securely plugged into a working outlet. 2. Tighten or replace the bulb. 3. Test the outlet with another device. 4. Replace AAA batteries in the remote control.
Remote control not working	1. Batteries are dead or incorrectly inserted. 2. Remote is too far from the lamp. 3. Obstruction between remote and lamp.	1. Replace AAA batteries, ensuring correct polarity. 2. Operate the remote within its effective range. 3. Remove any objects blocking the signal path.
Lamp flickers or dims unexpectedly	1. Loose bulb connection. 2. Incompatible bulb. 3. Power fluctuations.	1. Tighten the bulb. 2. Ensure you are using the provided LED bulb or a compatible E26 LED bulb. 3. Check other devices on the same circuit for power issues.

8. SPECIFICATIONS

Feature	Detail
Model Number	STR-FP-0149
Brand	PARTPHONER
Product Dimensions	9.2"D x 10.2"W x 66.1"H (Adjustable height: 52" to 65.32")
Base Diameter	10 Inches
Material	Metal
Finish Type	Painted (Aged Brown)
Shade Material	Metal
Light Source Type	LED (Bulb Included)
Bulb Base	E26
Wattage	8 Watts
Connectivity Technology	IR (for Remote Control)
Switch Type	Rotary Switch, Remote Control
Indoor/Outdoor Usage	Indoor
Special Features	Dimmable, 3 Color Temperatures, 5 Scene Modes, Adjustable Height, Rotatable Shade

9. WARRANTY AND SUPPORT

PARTPHONER provides a 24-month quality service for this product. If you encounter any quality issues or require assistance, please do not hesitate to contact us. Our customer support team is committed to resolving any concerns within 24 hours.

You can reach us via the Amazon message box or the email address provided in the original product packaging or documentation.