

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [mifasol](#) /
- › [Mifasol Stainless Steel Warm Mist Humidifier User Manual](#)

mifasol MFS-JSQ-01

Mifasol Stainless Steel Warm Mist Humidifier User Manual

Model: MFS-JSQ-01 | Brand: mifasol

INTRODUCTION

Thank you for choosing the Mifasol Stainless Steel Warm Mist Humidifier. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new humidifier. Please read it thoroughly before first use and retain it for future reference.



Image: The Mifasol Stainless Steel Warm Mist Humidifier, showcasing its design and the removable stainless steel tank.

The Mifasol Warm Mist Humidifier is designed to improve indoor air quality by releasing clean, warm steam. It features a 3.3L/0.87Gal water tank, adjustable mist levels, and constant humidity settings, suitable for large rooms up to 1000 sq. ft. Its 304 stainless steel tank is hygienic and easy to clean, being dishwasher safe and filter-free.

IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in fire, electric shock, injury, or damage to the product or property.

- Always place the humidifier on a firm, flat, water-resistant surface at least 12 inches (30 cm) away from walls and appliances.
- Due to the production of hot steam (water boils to 212°F / 100°C), keep the humidifier out of reach of children and individuals with cognitive impairments. Direct contact with steam can cause burns.
- Do not place the humidifier near heat sources such as stoves, radiators, or direct sunlight.

- Ensure the power cord is not pinched or placed under heavy objects. Do not use with a damaged cord or plug.
- Unplug the humidifier before filling, cleaning, or moving it.
- Do not add essential oils or other additives directly into the water tank, as this may damage the unit or void the warranty.
- The unit is equipped with a triple-lock system (child lock, lid open button, lid locking bar) and an automatic shut-off function when water runs out. Do not attempt to bypass these safety features.
- Avoid placing the humidifier directly on carpet or rugs, as this may obstruct airflow and cause overheating.

	mifasol Steam Humidifier	Other Ultrasonic Humidifier	
Healthy warm steam	Mist Output	Minerals / slimy cool mist	
Boiling sterilization	Sterilization	Cannot sterilize	
Sturdy 304 stainless steel	Water Tank	Fragile & leaking plastic	
Clean thoroughly, dishwasher safe	Clean	Slimy & moldy tank	
Filterless design, save money	Maintenance	Disposable filter, replaced monthly	

Image: Safety features including child lock, double lock, and waterless auto-off.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Mifasol Humidifier:

- **Main Unit:** Houses the heating element and control panel.
- **Water Tank:** 3.3L/0.87Gal capacity, made of food-grade 304 stainless steel.
- **Inner Lid:** Removable lid for the water tank.
- **Sealing Ring:** Ensures a tight seal for the water tank.
- **Control Panel:** Touch-sensitive buttons for operation.
- **Mist Outlet:** Where the warm mist is released.
- **Power Cord:** For connecting to an electrical outlet.

Hassle-Free Cleaning

*Effortless maintenance with
easy-to-clean removable design*



**304 Stainless
Steel Tank**



Dishwasher Safe



Filterless Design



Image: Exploded view of the humidifier components for easy cleaning and assembly.

SETUP

1. **Unpack:** Carefully remove all packaging materials and ensure all components are present.
2. **Placement:** Place the humidifier on a flat, stable, and water-resistant surface. Ensure it is at least 12 inches (30 cm) away from walls, furniture, and other appliances.

3. Fill Water Tank:

- Open the lid of the main unit.
- Remove the stainless steel water tank.
- Fill the tank with clean tap water. Do not exceed the "MAX" fill line indicated inside the tank.
- Place the inner lid and sealing ring back onto the tank, ensuring they are properly seated.
- Carefully place the filled water tank back into the main unit. Close the main unit lid securely.

4. Connect Power: Plug the power cord into a standard 120V AC electrical outlet.



Image: Steps for filling the water tank and placing it into the humidifier.

OPERATING INSTRUCTIONS

Your Mifasol Humidifier features a touch control panel for easy operation.



Image: Control panel and mist output levels.

Power On/Off

- Press the **Power Button** to turn the unit on or off.
- After activating, allow 15-30 minutes for the water to heat up to boiling before mist generation begins.

Adjusting Mist Levels

The humidifier offers three adjustable mist levels:

- Press the **Mist Level Button** to cycle through Low (300mL/h), Medium (500mL/h), and High (800mL/h) settings.

Setting Constant Humidity

You can set the desired humidity level:

- Press the **Humidity Setting Button** to choose between 50%, 60%, and 70% relative humidity. The unit will automatically maintain the selected level.

Customize Constant Humidity

Three humidity levels for any need



Image: Recommended humidity levels for different needs.

Sleep Mode & Timer

- **Sleep Mode:** Press the **Sleep Mode Button** to turn off the display screen for an undisturbed environment.
- **Timer:** Press the **Timer Button** to set the operating time from 1 to 9 hours. The unit will automatically shut off after the set time.

Sleep Deeply with Comfort Warm Mist



Sleep Mode



1-9H Timer



Up to 9H Runtime



Image: Humidifier in a bedroom, illustrating sleep mode and timer functions.

MAINTENANCE

Regular cleaning is essential for optimal performance and hygiene. The Mifasol Humidifier is designed for easy maintenance.

Daily Maintenance

- Empty any remaining water from the tank and main unit if the humidifier will not be used for an extended period.
- Wipe down the exterior of the unit with a soft, damp cloth.

Weekly Cleaning (Recommended)

1. **Unplug:** Always unplug the humidifier from the power outlet before cleaning.
2. **Disassemble:** Open the lid and remove the stainless steel water tank, inner lid, and sealing ring.
3. **Clean Tank:** The 304 stainless steel water tank is dishwasher safe. Alternatively, wash it by hand with warm water and mild dish soap. Rinse thoroughly.
4. **Clean Inner Lid & Sealing Ring:** Wash these parts with warm water and mild dish soap. Ensure no residue remains.
5. **Clean Main Unit:** Gently wipe the inside of the main unit with a damp cloth to remove any mineral deposits. Do not immerse the main unit in water.
6. **Descaling (if necessary):** If mineral deposits accumulate in the tank or on the heating element, fill the tank with a mixture of equal parts white vinegar and water. Let it soak for 30 minutes, then scrub gently with a brush and rinse thoroughly.
7. **Dry:** Allow all parts to air dry completely before reassembling.

Note: This humidifier features a filterless design, eliminating the need for filter replacement and simplifying maintenance.



Image: The stainless steel water tank is dishwasher safe for convenient cleaning.

TROUBLESHOOTING

If you experience issues with your humidifier, please consult the following table before contacting customer support.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No mist is being produced.	Water tank is empty or low. Unit has not had enough time to heat up. Lid is not properly closed. Mineral buildup on heating element.	Refill water tank. Allow 15-30 minutes for heating after turning on. Ensure lid is securely closed and locked. Clean the heating element as per maintenance instructions.
Humidifier shuts off unexpectedly.	Water tank is empty (auto shut-off activated). Unit is overheating. Timer function is active.	Refill water tank. Ensure proper ventilation; do not block air vents. Check timer settings and adjust if necessary.
Unresponsive control panel.	Child lock is activated. Temporary electronic glitch.	Deactivate child lock by pressing and holding the child lock button. Unplug the unit for 5 minutes, then plug back in.
Unpleasant odor from humidifier.	Stagnant water or mineral buildup.	Clean the water tank and main unit thoroughly as per maintenance instructions. Use fresh water daily.

SPECIFICATIONS

Feature	Detail
Brand	mifasol
Model Name	Warm Steam Humidifier
Model Number	MFS-JSQ-01
Operation Mode	Steam
Water Tank Capacity	3.3 Liters / 0.87 Gallons
Coverage Area	Up to 1000 sq. ft.
Max Spray Output	800 mL/h
Adjustable Humidity	50%, 60%, 70%
Timer	1-9 Hours
Voltage	120 Volts
Control Method	Touch
Special Features	Adjustable Humidity Control, Child Lock, Timer, Removable Tank, Dishwasher Safe, Filterless Design, Automatic Shut-off

Feature	Detail
Product Dimensions	11.5"D x 11"W x 10"H
Item Weight	9 Pounds

WARRANTY AND SUPPORT

Mifasol stands behind the quality of its products. For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official Mifasol website.

Please note that some retailers may offer extended warranty registration. Keep your purchase receipt as proof of purchase for any warranty claims.

For direct inquiries, you may contact Mifasol customer support via the email address provided in your product's original documentation.