Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bealife BF44-D-EU

Bealife Upholstered Bed Frame 90 x 200 cm Instruction Manual

Model: BF44-D-EU | Brand: Bealife

Introduction

Thank you for choosing the Bealife Upholstered Bed Frame. This manual provides essential information for the safe assembly, operation, and maintenance of your new bed frame. Please read these instructions carefully before beginning assembly and retain them for future reference.

Safety Information

WARNING:

- When assembling and using the bed, be sure to follow the instructions carefully to ensure the stability of the bed and avoid injury from the headboard.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not allow children to play on or under the bed frame.
- Use only the recommended mattress size (90x200cm) to ensure proper fit and safety.

Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Upholstered Headboard
- Side Rails (2)
- Footboard
- Center Support Bar
- Slatted Frame (15 sturdy slats)
- Support Legs (for frame and center bar)
- Hardware Pack (screws, bolts, Allen wrench)



Figure 1: Overview of bed frame dimensions (94cm headboard width, 121.5cm headboard height, 208cm total length, 90.5cm width).

Assembly Instructions

Assembly typically requires two people and can be completed in less than an hour. Follow the numbered steps below.

1. **Unpack Components:** Carefully remove all parts from the carton and lay them out on a clean, soft surface to prevent scratching. Identify all components against the package contents list.
2. **Attach Side Rails to Headboard:** Connect the side rails to the headboard using the provided bolts and Allen wrench. Do not fully tighten yet.
3. **Attach Footboard:** Connect the footboard to the other end of the side rails. Ensure all connections are aligned.
4. **Install Center Support Bar:** Secure the center support bar to the designated points on the headboard and footboard. Attach any support legs to the center bar.
5. **Insert Slatted Frame:** Place the 15 sturdy slats into the designated slots or supports on the side rails. Ensure they are evenly spaced and securely seated.

6. **Tighten All Fasteners:** Once all components are in place and aligned, securely tighten all bolts and screws. Do not overtighten.
7. **Attach Support Legs:** Screw in the main support legs to the bed frame. Ensure they are firm and stable.



Figure 2: Illustration of the durable metal frame and stable leg structure, designed for noise-free operation.

Operating and Usage

Your Bealife Upholstered Bed Frame is designed for comfort and stability. Once assembled, place your mattress directly onto the slatted frame.

- **Mattress Compatibility:** This bed frame is compatible with a mattress size of 90 x 200 cm.
- **Headboard Comfort:** The padded headboard provides a comfortable backrest for reading or relaxing.
- **Underbed Storage:** The design allows for ample storage space underneath the bed, suitable for storage boxes or for easy cleaning by a sweeping robot.



Figure 3: Detail of the comfortable padded headboard and the practical underbed storage area.




Figure 4: The Bealife Upholstered Bed Frame fully assembled and dressed in a bedroom environment.

Maintenance

Proper care will extend the life and appearance of your bed frame.

- **Cleaning:** Wipe the bed frame with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Fastener Check:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten if necessary to maintain stability and prevent noise.
- **Avoid Excessive Weight:** Do not place excessive weight on the bed frame beyond its intended use.

Troubleshooting

Problem	Possible Cause	Solution
Bed frame is wobbly or unstable.	Loose fasteners; uneven floor; incorrect assembly.	Ensure all bolts and screws are securely tightened. Check that the bed is on a level surface. Review assembly steps.
Squeaking or noise from the bed frame.	Loose connections; friction between parts; slats not properly seated.	Tighten all fasteners. Ensure slats are correctly positioned and not rubbing against the frame. Apply felt pads if necessary at contact points.
Slats falling out of place.	Improper installation of slats; excessive movement.	Ensure each slat is fully seated in its designated slot. Avoid jumping on the bed.

Specifications

Feature	Detail
Model Number	BF44-D-EU
Brand	Bealife
Size	90 x 200 cm
Material	Iron frame, Upholstery (Headboard)
Product Dimensions (L x W x H)	81.89" x 35.63" x 47.83" (approx. 208cm x 90.5cm x 121.5cm)
Item Weight	22.2 Kilograms
Style	Modern
Special Feature	Upholstered headboard, Underbed storage option
Required Assembly	Yes
Product Care Instructions	Wipe with Damp Cloth

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or contact the retailer where the product was acquired. You may also visit the official Bealife website for further assistance.
Bealife Store Link: Bealife Official Store

© 2026 Bealife. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DB61DYRF

More documents and user manuals: **https://manuals.plus/**