

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Bealife](#) /

› [Bealife BF24 25 26 -P Wood Bed Frame with Upholstered Headboard, Grey, 90x200 cm - Instruction Manual](#)

Bealife BF24 25 26 -P

Bealife BF24 25 26 -P Wood Bed Frame with Upholstered Headboard, Grey, 90x200 cm

Instruction Manual

1. INTRODUCTION

Thank you for choosing the Bealife BF24 25 26 -P Wood Bed Frame. This manual provides essential information for the safe assembly, operation, and maintenance of your new bed frame. Please read these instructions carefully before beginning assembly and retain them for future reference.

This bed frame features a robust metal and wood construction, an upholstered headboard with integrated storage, and a slatted base designed for mattress support without the need for a box spring. The specific model covered in this manual is the Grey 90x200 cm variant.



Figure 1: Fully assembled Bealife bed frame, showcasing the grey upholstered headboard and rustic wood accents.

2. SAFETY INSTRUCTIONS

- **Read All Instructions:** Ensure you understand all assembly steps and safety warnings before proceeding.
- **Two-Person Assembly:** Assembly is recommended for two adults to ensure safety and ease of construction.
- **Keep Small Parts Away:** Small parts can be a choking hazard. Keep them away from children and pets during assembly.
- **Assemble on a Soft Surface:** To prevent scratching or damage to the product or your floor, assemble the bed frame on a soft, clean surface like a carpet or blanket.
- **Do Not Overtighten:** Tighten all bolts and screws firmly, but do not overtighten to avoid stripping threads or damaging components.
- **Regular Checks:** Periodically check all connections to ensure they remain tight and secure.
- **Weight Capacity:** The bed frame is designed to support a maximum weight of 136 kg (including mattress and occupants). Do not exceed this limit.
- **Proper Mattress Size:** Use a mattress that fits the bed frame dimensions (90 x 200 cm) to ensure proper

support and safety.

3. PACKAGE CONTENTS

Before assembly, verify that all parts and hardware are present. If any items are missing or damaged, please contact customer support.



Figure 2: Assembly guide indicating included tools (screwdriver) and recommended tools (electric screwdriver, not included).

Tools Required:

- Screwdriver (included)
- Electric screwdriver (recommended for efficiency, not included)

Before You Start:

- Check all packages and components.
- Prepare a clear workspace and count all components.
- Wear gloves for safety.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your Bealife bed frame. Refer to the included assembly diagram for detailed illustrations of each part and connection.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on your prepared soft surface. Identify each part using the provided parts list in your package.

2. **Assemble the Headboard:** Attach the upholstered headboard section to the metal frame components. Ensure all bolts are finger-tightened initially.
3. **Attach Side Rails:** Connect the side rails to the headboard and footboard sections. Ensure the rustic wood panels are facing outwards.
4. **Install Center Support:** Secure the central support bar and its legs to the bed frame. These provide crucial stability.
5. **Place Slats:** Lay the wooden slats across the bed frame, ensuring they are evenly spaced and securely fitted into their designated positions.
6. **Final Tightening:** Once all components are in place and aligned, systematically tighten all bolts and screws using the provided screwdriver. Do not overtighten.
7. **Inspect:** After assembly, gently shake the bed frame to ensure it is stable and all connections are secure.



Figure 3: The bed frame structure without a mattress, illustrating the metal slat support system.



Figure 4: Detail of the durable metal frame and wooden slats, designed for noise-free and stable support.

5. OPERATING INSTRUCTIONS

Mattress Placement:

Place your 90 x 200 cm mattress directly onto the wooden slats. A box spring is not required for this bed frame.

Headboard Storage Shelf:

The integrated headboard shelf provides convenient storage for small items such as alarm clocks, books, or personal devices. Ensure items placed on the shelf do not obstruct your sleeping area or pose a falling hazard.



Figure 5: The headboard features an integrated storage shelf. The bed also offers ample under-bed storage space.

6. MAINTENANCE AND CARE

- **Cleaning:** Wipe the metal and wood surfaces with a soft, damp cloth. For the upholstered headboard, use a fabric cleaner suitable for the material, testing on an inconspicuous area first. Avoid harsh chemicals or abrasive cleaners.
- **Fastener Checks:** Periodically (e.g., every 3-6 months) check all bolts and screws to ensure they are still tight. Retighten if necessary to maintain stability and prevent noise.
- **Avoid Excessive Moisture:** Keep the bed frame away from excessive moisture or direct sunlight to prevent damage to the wood and upholstery.

7. TROUBLESHOOTING

Noise or Squeaking:

- **Solution:** Check all bolts and screws. Loose connections are a common cause of noise. Tighten any loose fasteners. Ensure slats are properly seated.

Instability or Wobbling:

- **Solution:** Verify that all components are correctly assembled according to the instructions. Ensure the central support legs are firmly on the floor and all connections are tight.

Missing Parts or Assembly Difficulty:

- **Solution:** If you encounter missing parts, delayed delivery, or difficulties during assembly, please contact customer support for assistance within 24 hours.

8. SPECIFICATIONS




Figure 6: Detailed dimensions of the bed frame, including length, width, height, and headboard depth, with a maximum load capacity of 136 kg.

| Attribute | Detail |
|--------------|---------------|
| Brand | Bealife |
| Model Number | BF24 25 26 -P |
| Color | Grey |

| | |
|--------------------------------|--|
| Material | Iron, Wood, Upholstery Fabric |
| Overall Dimensions (L x W x H) | 204.4 cm x 90 cm x 111 cm (approximate for 90x200 variant) |
| Compatible Mattress Size | 90 x 200 cm |
| Maximum Weight Capacity | 136 kg |
| Features | Upholstered Headboard, Integrated Storage Shelf, Metal Slat Support, Noise-Free Design |

9. WARRANTY AND SUPPORT

Specific warranty information is not provided in the product details. For any inquiries regarding warranty, missing parts, delivery issues, or assembly assistance, please contact Bealife customer support directly. They aim to provide assistance within 24 hours.

Please refer to your purchase documentation or the retailer's website for contact details and the most up-to-date warranty information.